



REF NO.	PART NUMBER	DESCRIPTION
1	16587D	Support Bracket: Bagger
2	16592	Support Tube Assembly
3	664-04017	Grass catcher Cover Assy. (includes Ref. 37 - 48)
4	710-0597	Screw 1/4-20 x 1"
5	710-0751	Hex Head Screw 1/4-20 x .62
6	710-1260A	Self-Tap. Screw 5/16-18 x .75
7	710-3005	Hex Hd. Screw, 3/8-16 x 1.25
8	710-3008	Hex Hd. Screw, 5/16-18 x .75
9	711-0309A	Clevis Pin, .62 Dia.
10	711-0310	Clevis Pin, .50 x 1.18
11	711-04069	Grass Catcher Pin 1/4-20
12	711-1421	Clevis Pin, 3/8 x .75
13	712-04064	Hex Flange Lock Nut, 1/4-20
14	712-04065	Hex Flange Lock Nut, 3/8-16
15	712-3004A	Hex Flg. Lock Nut, 5/16-18
16	714-0117	Hairpin Clip
17	714-0145	Click Pin
18	723-04008A	Chute Strap
19	731-04153	Discharge Chute 38"/42" Dk.
	731-04159	Discharge Chute 46" Deck
20	731-0899E	Chute Tube 38"/42" Deck
	731-0926B	Chute Tube 46" Deck
21	736-0331	Bell Washer
22	736-3092	Flat Washer
23	738-04058	Shoulder Spacer
24	783-04919	Mounting Bracket, LH

REF NO.	PART NUMBER	DESCRIPTION
25	783-04968	Mounting Bracket, RH
26	783-0601	Mounting Bracket
27	783-0673B	Mounting Bracket RH
28	783-0764B	Mounting Bracket LH
29	783-0765	Bracket: Cross Support
30	764-0221	Catcher Bag Assembly (Includes Ref. 31 - 36)
31	16591A	Bag Hanger Bracket
32	710-0473	Machine Screw, , #10-24 x .5
33	710-0604A	Self-tap. Scr., 5/16-18 x .625
34	712-0272	Hex Sems Nut, #10-24
35	749-0701A	Grass Bag Frame
36	764-0221	Grass Catcher Bag
37	16595B	Screen Mounting Bracket
38	16596	Hinge Assembly
39	710-1652	Self-Tap. Screw 1/4-20 x .625
40	720-04017	Grass catcher Sceen
41	726-0233	Push Nut, .25 x .50
42	726-0258	Zip Twist Fastener
43	728-0123	Pop Rivet, 3/16 x .450
44	731-04167	Double Grassbag Cover
45	731-04189	Grassbag Hopper Seal
46	731-0824A	Plastic Plate, 1/8 x 5.6
47	735-04020	Grassbag Hopper Seal
48	736-0400	Flat Washer, .194 x .62 x .063
49	742-0644*	2-in-1 Blade 16.28" 46" Deck
50	742-0645*	2-in-1 Blade 14.88" 46" Deck

\* Blades included with 46" cutting deck bagger kits only!