


REPAIR PARTS
ENGINE, LCT

SNOW THROWER - - MODEL NUMBER 944.520620
COMPLETE ENGINE-429064



REPAIR PARTS
ENGINE, LCT

SNOW THROWER - - MODEL NUMBER 944.520620
COMPLETE ENGINE-429064

KEY NO.	PART NO.	DESCRIPTION	KEY NO.	PART NO.	DESCRIPTION
1	429206	HEATER BOX ASSEMBLY-SNOW	23	429233	VALVE COVER
3	429208	MUFFLER ASSEMBLY-SNOW	25	429234	FUEL PETCOCK, SNOW
4	429209	FUEL TANK ASSEMBLY-SNOW	26	429288	FLYWHEEL ASSEMBLY, ELECTRIC START-SNOW
5	429211	FUEL TANK CAP-OVERSIZED (CLICK STYLE)-SNOW	26A	429289	FLYWHEEL ASSEMBLY, MANUAL START-SNOW
6	429215	CARBURETOR ASSEMBLY-SNOW	27	429237	HIGH OIL FILL ASSY KIT, SOW
7	429216	CHOKE LEVER, CARBURETOR -SNOW	28	429238	FLYWHEEL FAN
8	429218	PRIMER BULB ASSEMBLY W/HOSE-SNOW	29	429240	IGNITION COIL ASSY
10	429220	ELECTRIC STARTER ASSEMBLY-SNOW	30	429241	CRANKCASE COVER ASSY
11	429221	KEY SWITCH ASSEMBLY-SNOW	31	429242	NON-REMOVABLE OIL PLUG
12	429222	CDI BOX ASSEMBLY-SNOW	32	429243	CHARGING COIL AC/DC
13	429223	SWITCH OFF/ON-SNOW	33	429290	ELECTRIC STARTER BRACKET
15	429224	CHOKE KNOB-SNOW	34	429291	SPARK PLUG BOOT
16	429225	GOVERNOR LINKAGE SHIELD PLATE-SNOW	36	429248	GOVERNOR ARM ASSY
17	429226	RECOIL STARTER ASSEMBLY-SNOW	37	429250	GOVERNOR SHAFT
18	429227	STARTER CUP SMALL-SNOW	38	429292	GOVERNOR GEAR ASSEMBLY
19	429228	STARTER GRIP-SNOW	39	429253	CAMSHAFT
20	429229	BLOWER HOUSING ASSEMBLY, ELECTRIC START-SNOW	40	429254	CYLINDER HEAD ASSY
21	429231	SHIELD, CYLINDER	41	429255	SPARK PLUG
22	429232	SHIELD, UNDER FLYWHEEL CHARGING SYSTEM-SNOW	42	429257	CDI BOX BRACKET-SNOW
			44	429258	PISTON AND ROD ASSY
			46	429213	VAPOR SHIELD
			47	429283	SEAL KIT
			48	429284	WIRE HARNESS
			49	429285	CRANKSHAFT
			50	429286	TOP SHIELD
			51	429287	FUEL TANK SKIRT

NOTE: All component dimensions given in U.S. inches. 1 inch = 25.4 mm
IMPORTANT: Use only Original Equipment Manufacturer (O.E.M.) replacement parts.
Failure to do so could be hazardous, damage your snow thrower and void your warranty.