


ROTARY LAWN MOWER -- MODEL NUMBER 961340001 (96134000100)



ROTARY LAWN MOWER - - MODEL NUMBER 961340001 (96134000100)

KEY NO.	PART NO.	DESCRIPTION	KEY NO.	PART NO.	DESCRIPTION
1	194177X428	Control Bar	37	189483	Wheel & Tire Assembly
2	194179X479	Upper Handle	39	83923	Flanged Locknut
3	169708X479	Lower Handle	40	188813	Frame, Grass Bag
4	179585	Rope Guide	41	88652	Hinge Screw
5	132004	Nut, Hex	42	165766	Spring, Left
6	191574	Handle Bolt	43	165767	Spring, Right
7	66426	Wire Tie	44	184193	Bolt, Rear Skirt
11	176556	Engine Zone Control Cable	45	150406	Hex Head Thread Rolling Screw 3/8-16 x 1
12	750634	Hex Washer Head Screw	46	141846	Danger Decal
13	86899X004	Up-Stop Bracket	48	186575X004	Axle Arm Assembly, Rear, RH
14	189713X428	Handle Knob	50	194711	Grass Bag
15	51793	Hairpin Cotter	52	189215	Housing Assembly
17	165946X479	Support Bracket			(Includes Key Numbers 17, 18 and 46)
18	851856	Screw	53	851084	Hex Head Screw 3/8-24 x 1-3/8 Grade 8
19	186577X004	Axle Arm Assembly, Front, LH	54	850263	Helical Lockwasher
20	186578X004	Axle Arm Assembly, Front, RH	55	851074	Hardened Washer
21	188987	Rear Skirt	56	189028	21" Blade
22	168360X004	Selector Spring, Front	57	851514	Blade Adapter
23	186612	Rear Door Kit (Includes Springs)	59	- - -	Engine, Briggs & Stratton, Model Number 10M902 (for engine service and replacement parts, call Briggs & Stratton at 1-800-233-3723)
24	73930500	Locknut 5/16-18			Clip, Cable
25	166111X479	Handle Bracket Assembly, LH	67	192770	Warning Decal (not shown)
26	166112X479	Handle Bracket Assembly, RH	- -	161058	Operator's Manual, English
27	17600406	Screw 1/4-20 x 3/8	- -	193732	Operator's Manual, Spanish
28	160835X007	Wheel Adjusting Bracket, Front	- -	193735	Repair Parts Manual
30	183901	Spacer	- -	195593	
32	169421X004	Selector Spring, Rear			
33	87877	Selector Knob			
34	186576X004	Axle Arm Assembly, Rear, LH			
36	160828	Shoulder Bolt 5/16-18			

NOTE: All component dimensions given in U.S. inches.
1 inch = 25.4 mm