


ROTARY LAWN MOWER -- MODEL NUMBER HU600L (96143006800) PRODUCT NUMBER 961 43 00-68




ROTARY LAWN MOWER - - MODEL NUMBER HU600L (96143006800) PRODUCT NUMBER 961 43 00-68

KEY PART NO.	DESCRIPTION	KEY PART NO.	DESCRIPTION
1	532 42 76-58 Upper Handle Assembly (Includes Foam Grip)	44	532 43 84-84 Kit, Lawn Mower Housing
2	532 42 09-51 Cable, Engine Zone Control	46	532 42 17-82 Blade Adapter / Pulley
3	532 43 00-34 Bracket, Upstop	47	532 43 76-01 Blade, 22"
6	532 18 23-98 Handle Knob, Star	48	532 85 10-74 Washer, Hardened
7	532 75 06-34 Screw #10-24 x 1/2	49	532 85 02-63 Washer, Helical
8	532 43 34-30 Control Bar	50	532 85 10-84 Screw, Machine, Hex Head 3/8-24 x 1-3/8 Grade 8
9	532 43 13-90 Rear Door Assembly	51	532 43 71-31 Front Baffle
11	532 42 55-75 Hairpin, Door/Handle Pivot	53	532 43 73-45 Screw
12	532 19 19-38 Handle Knob, Standard	56	817 41 13-12 Screw, Hex Washer Head #13 x 3/4
13	532 43 75-16 Plug, Lower Handle Bar	57	532 15 53-77 Nut, Hex
17	532 43 12-38 Rear Baffle	58	532 44 11-97 Lower Handle
18	532 13 20-04 Keps Locknut 1/4-20	59	532 19 15-74 Handle Bolt
19	532 19 47-88 Rope Guide	62	532 42 57-11 Belt Retainer
20	532 42 91-57 Rear Skirt	64	- - - Engine, Kohler, Model Number XT149-0217-ED (For engine service and replacement parts, call Kohler at 1-800-544-2444)
21	532 41 99-49 Spring, Rear Door, LH, Black	70	532 18 27-48 Grip, Foam
22	532 14 18-41 Screw, Panhead, Torx #20	83	532 75 00-97 Screw, Hex Washer Head
24	532 41 99-48 Spring, Rear Door, RH, Grey	84	532 42 81-24 Fastener, Push
26	532 41 99-45 Screw, Rear Door/Handle Pivot	85	532 43 45-30 Mounting Bracket, Rear Skirt
28	872 25 05-05 Bolt, Carriage 5/16-18 x 5/8	96	532 19 79-91 Clip, Cable
30	532 43 85-84 Grassbag	97	532 43 48-93 Belt Keeper
31	532 41 99-51 Frame, Grass Catcher	99	532 43 73-89 Front Shroud Assembly
34	532 43 81-34 Bracket, Grassbag	- -	532 43 81-38 Operator's Manual, English / French
37	817 00 05-10 Screw		
39	532 44 05-25 Handle Bracket, LH		
40	532 44 05-26 Handle Bracket, RH		
41	532 15 04-06 Screw, Dogpoint 3/8-16 x 1-1/8		

NOTE: All component dimensions given in U.S. inches. 1 inch = 25.4 mm. **IMPORTANT:** Use only Original Equipment Manufacturer (O.E.M.) replacement parts. Failure to do so could be hazardous, damage your lawn mower and void your warranty.

ROTARY LAWN MOWER -- MODEL NUMBER HU600L (96143006800) PRODUCT NUMBER 961 43 00-68



ROTARY LAWN MOWER - - MODEL NUMBER HU600L (96143006800) PRODUCT NUMBER 961 43 00-68

KEY NO.	PART NO.	DESCRIPTION	KEY NO.	PART NO.	DESCRIPTION
1	532 43 09-72	Drive Control Assembly (Includes Cable)	31	532 40 48-45	Pawl, Drive
9	532 43 16-50	Cable, Drive	32	532 44 14-08	Wheel & Tire Assembly, Rear
10	532 43 27-90	Mounting Bracket, Drive Control	33	532 40 91-48	Nut, Flangelock 3/8-16
11	817 06 04-08	Screw	34	532 19 74-80	O-Ring
12	873 94 08-00	Nut, Hex	35	532 43 05-98	Axle, Rear
13	532 43 45-64	Gearcase Assembly, Complete	36	532 44 13-29	Axle, Front
14	532 19 41-28	Pulley, Drive	37	532 16 34-09	Screw, Hi-Lo Thread, 12 x 5/8
15	532 08 83-48	Washer, Flat	38	532 19 17-30	Nut, Hex
16	532 43 00-30	Rod, Connecting	39	532 40 70-59	Bolt
17	532 75 11-53	Nut, Hex	40	532 44 12-98	Wheel & Tire Assembly, Front
18	532 43 85-36	Selector Assembly	41	532 40 48-35	Pinion
19	532 43 39-96	Knob, Wheel Adjuster	44	532 42 15-27	Belt, Drive
20	532 42 70-23	Debris Shield	47	532 06 77-25	Washer, Flat
21	532 43 52-42	Anchor	48	532 42 11-14	Kit, Water Washout Assembly
23	532 43 78-70	Wheel Axle Assembly, LH	49	532 41 97-35	Fitting, Water Washout
24	532 43 35-11	Bracket, Height Adjustment	50	532 41 55-85	Washer, Lock, Internal Tooth
25	532 42 60-65	Mounting Bracket, Debris Shield	51	532 41 55-86	Locknut, Hex, with O-Ring
26	532 42 60-66	Belt Keeper	55	532 40 65-58	Spring, Tension
28	812 00 00-58	E-Ring 7/16	58	532 43 52-41	Bolt, Shoulder
29	532 18 94-03	Cover, Dust, Wheel	59	532 44 21-13	Support Bracket
30	817 00 05-10	Screw, Hex Head	61	532 18 16-98	Screw
			62	532 19 79-91	Clip, Cable
			63	532 42 81-24	Fastener, Push

NOTE: All component dimensions given in U.S. inches. 1 inch = 25.4 mm. **IMPORTANT:** Use only Original Equipment Manufacturer (O.E.M.) replacement parts. Failure to do so could be hazardous, damage your lawn mower and void your warranty.