


HUSQVARNA ROTARY LAWN MOWER - MODEL NO. HD800HW (96143008800) PRODUCT NO. 961 43 00-88




HUSQVARNA ROTARY LAWN MOWER - MODEL NO. HD800HW (96143008800) PRODUCT NO. 961 43 00-88

KEY PART NO.	DESCRIPTION	KEY PART NO.	DESCRIPTION
1	532 18 62-96 Upper Handle Assembly (Includes Foam Grip)	41	532 15 04-06 Screw, Dogpoint 3/8-16 x 1-1/8
2	532 44 03-86 Cable, Engine Zone Control	44	532 43 85-35 Kit, Lawn Mower Housing
3	532 43 00-34 Bracket, Upstop	46	532 42 17-82 Blade Adapter / Pulley
6	532 18 23-98 Handle Knob, Star	47	532 42 18-25 Blade, 22"
7	532 17 88-48 Screw #10-16 x 5/8	48	532 85 10-74 Washer, Hardened
8	532 42 68-12 Control Bar	49	532 85 02-63 Washer, Helical
9	532 43 13-90 Rear Door Assembly	50	532 85 10-84 Screw, Machine, Hex Head 3/8-24 x 1-3/8 Grade 8
11	532 42 55-75 Hairpin, Door/Handle Pivot	51	532 43 71-31 Front Baffle
12	532 19 19-38 Handle Knob, Standard	53	532 43 73-45 Screw
13	532 43 75-16 Plug, Lower Handle Bar	56	817 41 13-12 Screw, Hex Washer Head #13 x 3/4
14	532 43 71-32 Clipping Deflector	57	532 15 53-77 Nut, Hex
15	532 43 72-73 Handle, Clipping Deflector	58	532 44 11-97 Lower Handle
17	532 43 12-38 Rear Baffle	59	532 19 15-74 Handle Bolt
18	532 13 20-04 Keps Locknut 1/4-20	62	532 43 50-59 Belt Retainer
19	532 19 47-88 Rope Guide	64	- - - Engine, Honda, Model Number GCV160-LAOS3A (For engine service and replacement parts, call Honda Engines at 1-800-426-7701)
20	532 44 45-37 Rear Skirt	70	532 18 27-48 Grip, Foam
21	532 41 99-49 Spring, Rear Door, LH, Black	83	532 75 00-97 Screw, Hex Washer Head
22	532 14 18-41 Screw, Panhead, Torx #20	84	532 42 81-24 Fastener, Push
24	532 41 99-48 Spring, Rear Door, RH, Grey	85	532 43 45-30 Mounting Bracket, Rear Skirt
26	532 41 99-45 Screw, Rear Door/Handle Pivot	96	532 19 79-91 Clip, Cable
28	872 25 05-05 Bolt, Carriage 5/16-18 x 5/8	97	532 43 48-93 Belt Keeper
30	532 43 85-84 Grassbag	99	532 43 73-89 Front Shroud Assembly
31	532 41 99-51 Frame, Grass Catcher	- -	532 44 59-28 Operator's Manual, English / French
34	532 43 81-34 Bracket, Grassbag		
37	817 00 05-10 Screw, Hex Head 1/4-20		
39	532 44 25-31 Handle Bracket, LH		
40	532 44 05-26 Handle Bracket, RH		

NOTE: All component dimensions given in U.S. inches. 1 inch = 25.4 mm. **IMPORTANT:** Use only Original Equipment Manufacturer (O.E.M.) replacement parts. Failure to do so could be hazardous, damage your lawn mower and void your warranty.

HUSQVARNA ROTARY LAWN MOWER - MODEL NO. HD800HW (96143008800) PRODUCT NO. 961 43 00-88



HUSQVARNA ROTARY LAWN MOWER - MODEL NO. HD800HW (96143008800) PRODUCT NO. 961 43 00-88

KEY NO.	PART NO.	DESCRIPTION	KEY NO.	PART NO.	DESCRIPTION
1	532 43 09-95	Drive Control Assembly (Includes Cable)	33	532 40 91-48	Nut, Flangelock 3/8-16
9	532 43 16-50	Cable, Drive	34	532 19 74-80	O-Ring
10	532 43 27-90	Mounting Bracket, Drive Control	35	532 43 05-98	Axle, Rear
11	817 41 13-12	Screw	36	532 44 22-07	Axle, Front
12	873 94 08-00	Nut, Hex	37	532 16 34-09	Screw, Hi-Lo Thread, 12 x 5/8
13	532 43 45-64	Gearcase Assembly, Complete	38	532 19 17-30	Nut, Hex
14	532 19 41-28	Pulley, Drive	39	532 40 70-59	Bolt
15	532 08 83-48	Washer, Flat	40	532 44 28-22	Wheel & Tire Assembly, Front
16	532 43 00-30	Rod, Connecting	41	532 42 87-83	Pinion
17	532 75 11-53	Nut, Hex	44	532 42 15-27	Belt, Drive
18	532 44 14-20	Kit, Selector Assembly	48	532 43 84-89	Kit, Water Washout Assembly
19	532 43 39-96	Knob, Wheel Adjuster	49	532 43 49-94	Fitting, Water Washout
20	532 42 70-23	Debris Shield	50	532 41 55-85	Washer, Lock, Internal Tooth
21	532 43 52-42	Anchor	51	532 41 55-86	Locknut, Hex, with O-Ring
23	532 43 78-65	Wheel Axle Assembly, LH	55	532 40 65-58	Spring, Tension
24	532 43 35-11	Bracket, Height Adjustment	56	532 44 13-33	Hubcap
25	532 42 60-65	Mounting Bracket, Debris Shield	57	532 40 91-49	Nut, Flangelock 3/8-16
26	532 42 60-66	Belt Keeper	58	532 43 52-41	Bolt, Shoulder
28	812 00 00-58	E-Ring 7/16	59	532 44 21-13	Support Bracket
29	532 42 87-81	Cover, Dust, Wheel	61	532 18 16-98	Screw
30	817 00 05-10	Screw, Hex Head	62	532 19 79-91	Clip, Cable
31	532 40 48-45	Pawl, Drive	63	532 42 81-24	Fastener, Push
32	532 44 28-24	Wheel & Tire Assembly, Rear	84	532 41 64-05	Adapter, Quick-Connect Coupler
			85	532 43 90-77	Support Bracket, Front Axle

NOTE: All component dimensions given in U.S. inches. 1 inch = 25.4 mm. **IMPORTANT:** Use only Original Equipment Manufacturer (O.E.M.) replacement parts. Failure to do so could be hazardous, damage your lawn mower and void your warranty.