


# REPAIR PARTS

## GRASS CATCHER FOR SIDE DISCHARGE MOWER -- MODEL NUMBER GC190BR



# REPAIR PARTS

## GRASS CATCHER FOR SIDE DISCHARGE MOWER-- MODEL NUMBER GC190BR

KEY NO.	PART NO.	DESCRIPTION	KEY NO.	PART NO.	DESCRIPTION
1	120120X	Cover-Grass Catcher	31	86543	Pin-Support Bracket
2	86578	Bracket-Hinge	32	120203X	Stud-Latch
3	110441X	Strip-Foam	33	73680500	Lock Nut 5/16 - 18
4	106815X	Strip-Foam	34	57734	Washer-Formed
5	123420X	Container, 30 Gal.	35	74291008	Screw-Truss Head 10-24 x 1/2
6	72110505	Bolt	36	73680400	Nut-Lock 1/4-20
7	104389X	Plug-End	37	72140400	Bolt
8	83553	Clamp-Elbow	38	123198X	Wingnut-Plastic
9	86558	Retainer-Elbow	39	2029J	Nut-Weld
10	4939M	Spring-Retainer	41	122129X	Bar
11	120097X	Latch Pin	42	120107X	Handle-Chute Tube
13	110254X	Post Support Assembly	43	10071000	Washer-Lock #10
14	62361	Bolt-Shoulder	44	107339X	Decal-Danger
15	120245X	Bracket-Mounting	45	74780412	Bolt-Hex 1/4-20 x 3/4
16	19131610	Washer 13/32 x 1 x 10 Ga.	46	109808X	Latch
17	73680600	* Nut-Lock 3/8-16	47	120108X	Assembly Frame R.H.
18	86626	U-Bolt 1/4-20	48	120109X	Assembly-Frame, L.H.
19	73350400	* Nut - Hex 1/4-20	49	19070818	Washer-Flat
20	19091016	Washer - Flat 9/32	50	110255X	Shield-Elbow
21	110257X	Elbow	51	60867	Nut-Acorn #10-24
22	19091408	Washer	52	19111212	Washer
23	122185X	Tube-Chute	53	72110508	Bolt
24	122146X	Extension Chute	57	120263X	* Plate, Reinforcing
25	123490X	Deflector Brace	--	104419X	Bag-Trash, 30 Gal., 1.5 Mil
26	104752X	Decal, Instruction Caution	--	122171X	Owner's Manual (English)
			--	123500X	Owner's Manual (French)

\*STANDARD HARDWARE--PURCHASE LOCALLY

\*\* USED ON MODEL NUMBERS L1910AR, L1930BT, L1950BR, L1960AR, L1970AR

