

REPAIR PARTS

12.5 HP 38" LAWN TRACTOR-MODEL NO. LT120 (HA125R38B), PRODUCT NO. 954 00 04-92

ELECTRICAL


KEY NO.	PART NO.	DESCRIPTION
1	873510400	Nut, Hex, Keps 1/4-20
2	532108423	Assembly, Cable
3	532133909	Battery
5	532108236	Bracket, Switch
6	532104445	Switch, Interlock, 2 Terminal
7	532109553	Switch, Interlock, 4 Terminal
8	817021008	Screw, Hex Head, Self-Tapping #10-24 x 1/2
9	532122147	Key, Molded
10	532123620	Cover, Ignition Key
11	532124211	Nut, Ignition
12	532125104	Switch, Ignition
14	532124756	Tie, Cable
15	532121305	Switch, Plunger
16	873510500	Nut, Hex, Keps 5/16-18
17	532108824	Fuse
18	532128353	Assembly, Cable
19	532132222	Harness, Ignition
20	873350400	Nut, Hex, Jam 1/4-20
21	810090400	Washer, Lock 1/4
22	874780408	Bolt, Hex, Fin. 1/4-20 UNC x 1/2 Grade 5
23	811050400	Washer, Lock, External Tooth 1/4
24	532131563	Cover, Terminal
25	532138406	Solenoid
26	874760412	Bolt, Hex Head 1/4-20 UNC x 3/4
27	819091016	Washer 9/32 x 5/8 x 16 Gauge
28	810040400	Washer, Lock 1/4
29	532121264	Cap, Battery
30	873220400	Nut, Hex, Fin. 1/4-20 UNC
31	532131078	Harness, Headlight
32	532004152	Bulb, Light
33	532110712	Switch, Light
35	811050600	Washer, Lock, External Tooth 3/8
36	811150400	Washer, Lock, Internal Tooth 1/4

NOTE: All component dimensions given in U.S. inches
1 inch = 25.4 mm

HARDWARE SHOWN LARGER FOR EASIER IDENTIFICATION

REPAIR PARTS

12.5 HP 38" LAWN TRACTOR-MODEL NO. LT120 (HA125R38B), PRODUCT NO. 954 00 04-92
FENDER/CHASSIS




KEY NO.	PART NO.	DESCRIPTION	KEY NO.	PART NO.	DESCRIPTION
1	532125434	Fender/Foostrest	17	532127880	Drawbar
2	532109238	Tube, Battery Drain	18	532125142	Plate Assembly, Battery
3	532109596	Clamp, Hose	19	532124181	Spring, Compression, Seat
4	532129965	Case, Battery	20	819132012	Washer 13/32 x 1-1/4 x 12 Gauge
5	532126700	Pad, Foostrest	21	817490612	Screw, Hex Washer Head, Thd., Roll. 3/8-16 x 3/4
6	817490516	Screw, Hex Washer Head, Thd., Roll. 5/16-18 x 1	22	532124346	Nut, Self-Threading, Washer Head 3/16
7	532131318	Latch, Hood	23	532126470	Clip, Insulated
8	532131053	Hood/Grill Assembly (Includes Key Numbers 21 and 22)	24	532124307	Bar, Shift Lock
9	532130986	Lens, L.H.	25	532126995	Console, Shift Control
10	532130985	Lens, R.H.	26	819091413	Washer 9/32 x 7/8 x 13 Gauge
11	532128449	Pivot Bracket Assembly, L.H.	27	532126938	Bumper, Hood
12	532128808	Pivot Bracket Assembly, R.H.	29	532132562	Plate, Depth Stop
13	532137097	Assembly, Frame	30	817490508	Screw, Thd., Roll. 5/16-18 x 1/2
14	873680500	Nut, Hex, Crownlock 5/16-18	31	872110506	Bolt, Carriage 5/16-18 x 3/4
15	873510400	Nut, Hex, Keps 1/4-20 UNC	NOTE: All component dimensions given in U.S. inches		
16	874760512	Bolt, Hex Head 5/16-18 UNC x 3/4	1 inch = 25.4 mm		

HARDWARE SHOWN LARGER FOR EASIER IDENTIFICATION

REPAIR PARTS

12.5 HP 38" LAWN TRACTOR-MODEL NO. LT120 (HA125R38B), PRODUCT NO. 954 00 04-92
SEAT



KEY NO.	PART NO.	DESCRIPTION
1	872050411	Bolt, Carriage 1/4-20 x 1-3/8
2	532127398	Seat
3	874641008	Screw, Slotted Pan Head #10-32 x 1/2
4	873680500	Nut, Hex, Crownlock 5/16-18
5	532105529	Bolt, Shoulder 5/16-18 UNC
6	532124967	Clip, Insulated
7	873951000	Nut, Hex, Keps #10-32 UNF
8	874760612	Bolt, Hex, Fin. 3/8-16 UNC x 3/4
9	532126656	Bracket, Pivot, Seat
10	532126471	Clip, Insulated
11	819133210	Washer 12/32 x 2 x 10 Gauge
12	873680600	Nut, Hex, Crownlock 3/8-16 UNC

KEY NO.	PART NO.	DESCRIPTION
13	532120068	Knob, Seat
15	819171912	Washer 17/32 x 1-3/16 x 12 Gauge
16	532127018	Bolt, Shoulder
17	532121251	Strip, Foam
18	532123976	Nut, Hex, Large, Flange Lock
19	532121248	Bushing, Snap
20	532121250	Spring, Compression
21	532134300	Spacer, Split, Large .28 Id. x .96
22	532121246	Bracket, Switch Mounting
23	532131451	Pan, Seat


NOTE: All component dimensions given in U.S. inches
1 inch = 25.4 mm

HARDWARE SHOWN LARGER FOR EASIER IDENTIFICATION

REPAIR PARTS

12.5 HP 38" LAWN TRACTOR-MODEL NO. LT120 (HA125R38B), PRODUCT NO. 954 00 04-92

DASH



KEY NO.	PART NO.	DESCRIPTION
1	532132735	Cap, Fuel Tank
2	532138395	Assembly, Dash & Fuel Tank
3	532123487	Clamp, Hose
4	532008544	Line, Fuel
5	532008548	Line, Fuel
6	873510400	Nut, Hex, Keps 1/4-20
7	532124996	Clip, Fuel Line
8	819091216	Washer 9/32 x 3/4 x 16 Gauge


KEY NO.	PART NO.	DESCRIPTION
17	872110404	Bolt, Carriage 1/4-20 x 1/2 Grade 5
18	532131886	Support Assembly, Dash
19	532134744	Brace, Cross
20	817060408	Screw, Self-Tapping 1/4-20 x 1/2
21	532134014	Plug, Dome, Black

NOTE: All component dimensions given in U.S. inches
1 inch = 25.4 mm

HARDWARE SHOWN LARGER FOR EASIER IDENTIFICATION

REPAIR PARTS

12.5 HP 38" LAWN TRACTOR-MODEL NO. LT120 (HA125R38B), PRODUCT NO. 954 00 04-92
STEERING WHEEL



KEY NO.	PART NO.	DESCRIPTION
1	532124416	Insert, Steering Wheel
2	532124701	Locknut 3/8-24 UNF
3	819133808	Washer 12/32 x 2-3/8 x 8 Gauge
4	532124415	Steering Wheel
5	532127396	Sleeve, Steering
6	817431008	Screw, Hex Head #10-16 x 1/2
7	532102803	Bushing, Steering
8	532123651	Shaft, Steering


KEY NO.	PART NO.	DESCRIPTION
9	532124210	Clip, Steering
10	532123438	Bushing, Lower, Steering
11	812000045	Ring, Retaining
12	819211616	Washer 21/32 x 1 x 16 Gauge
13	532104820	Adaptor, Steering Wheel

NOTE: All component dimensions given in U.S. inches
1 inch = 25.4 mm

HARDWARE SHOWN LARGER FOR EASIER IDENTIFICATION

REPAIR PARTS

12.5 HP 38" LAWN TRACTOR-MODEL NO. LT120 (HA125R38B), PRODUCT NO. 954 00 04-92
SECTOR GEAR / AXLE SUPPORT



KEY NO.	PART NO.	DESCRIPTION
1	532132566	Link, Drag
2	874780828	Bolt, Hex, Fin. 1/2-13 x 1-3/4
5	532121926	Gear, Sector
6	532121927	Bushing
7	873030800	Nut, Heavy Hex, Top Lock 1/2-13 UNC
8	532126472	Clip, Insulated
9	873680800	Nut, Crownlock 3/8-16
10	876020412	Pin, Cotter 1/8 x 3/4
11	819131316	Washer 13/32 x 13/16 x 16 Gauge
12	532126847	Bushing

KEY NO.	PART NO.	DESCRIPTION
13	874760516	Bolt, Hex Head 5/16-18 UNC x 1
14	819111416	Washer 11/32 x 7/8 x 16 Gauge
15	872110606	Bolt, Carriage 3/8-16 UNC x 3/4
16	872140622	Bolt, Carriage
17	532121912	Support, Front Axle
18	873220600	Nut, Hex, Fin. 3/8-16 UNC
19	873930600	Nut, Hex, Centerlock 3/8-16 UNC
20	873680600	Nut, Hex, Crownlock 3/8-16 UNC
21	873680500	Nut, Hex, Crownlock 5/16-18


NOTE: All component dimensions given in U.S. inches
1 inch = 25.4 mm

HARDWARE SHOWN LARGER FOR EASIER IDENTIFICATION

REPAIR PARTS

12.5 HP 38" LAWN TRACTOR-MODEL NO. LT120 (HA125R38B), PRODUCT NO. 954 00 04-92

FRONT AXLE



KEY NO.	PART NO.	DESCRIPTION
1	532121232	Cap, Spindle
2	812000029	Ring, Clip
3	532121748	Washer 25/32 x 1-5/8 x 16 Gauge
4	532121922	Nyliner
5	532121914	Axle, Front
6	532124931	Bearing, Thrust
7	532121919	Spindle Assembly, R.H.
8	532121749	Washer 25/32 x 1-1/4 x 16 Gauge


KEY NO.	PART NO.	DESCRIPTION
9	876020412	Pin, Cotter 1/8 x 3/4
10	819131316	Washer 13/32 x 13/16 x 16 Gauge
11	532126847	Bushing
12	532121924	Tie Rod
13	532121916	Spindle Assembly, L.H.

NOTE: All component dimensions given in U.S. inches
1 inch = 25.4 mm

HARDWARE SHOWN LARGER FOR EASIER IDENTIFICATION

REPAIR PARTS

12.5 HP 38" LAWN TRACTOR-MODEL NO. LT120 (HA125R38B), PRODUCT NO. 954 00 04-92
ENGINE



KEY NO.	PART NO.	DESCRIPTION
1	817060408	Screw, Hex Head, Thread Cutting 1/4-20 x 1/2
2	532133025	Control, Throttle
3	---	Engine, Briggs & Stratton, 12.5 HP, Model #286707, Type #0441-01
4	871070512	Screw, Hex Cap Hd. 5/16-18 x 3/4
5	810040500	Washer, Lock, Heavy Helical Spring 5/16
6	532125593	Gasket, Exhaust
9	819101216	Washer 5/16 x 3/4 x 16 Gauge
10	810040400	Washer, Lock, Heavy Helical Spring 1/4


KEY NO.	PART NO.	DESCRIPTION
11	874760412	Bolt, Hex, Fin. 1/4-20 UNC x 3/4
12	532137437	Muffler
15	532137180	Arrester, Spark (Optional Equipment)
17	817490624	Screw, Hex Washer Head, Thd., Roll. 3/8-16 x 1-1/2
18	532126636	Keeper, Ground Drive Belt
19	532127951	Stop, Throttle
20	873510600	Nut, Hex, Keps 3/8-16
21	532124996	Clip, Fuel Line

NOTE: All component dimensions given in U.S. inches
1 inch = 25.4 mm

HARDWARE SHOWN LARGER FOR EASIER IDENTIFICATION

REPAIR PARTS

12.5 HP 38" LAWN TRACTOR-MODEL NO. LT120 (HA125R38B), PRODUCT NO. 954 00 04-92
GROUND DRIVE



KEY NO.	PART NO.	DESCRIPTION	KEY NO.	PART NO.	DESCRIPTION
1	873680500	Nut, Crownlock 5/16-18	13	819131316	Washer 13/32 x 13/16 x 16 Gauge
2	874760512	Bolt, Hex Head 5/16-18 UNC x 3/4	14	873930600	Nut, Hex, Centerlock 3/8-16 UNC
3	532132946	Keeper, Mower Drive, R.H.	15	873680600	Nut, Hex, Crownlock 3/8-16 UNC
4	532135036	Pulley, Engine	16	532126471	Clip, Insulated
5	810040700	Washer, Lock 7/16	17	532122052	Spacer, Retainer
6	871130748	Bolt, Hex Hd. 7/16-20 UNF Grade 8	18	532131459	Spring, Extension
7	532126520	Traction, V-Belt Drive	19	873510500	Nut, Hex, Keps 5/16-18 UNC
8	532123405	Keeper, T/A, Ground Drive Belt	20	532123891	Keeper, T/A, Ground Drive Belt
9	872140612	Bolt, Carriage 3/8-16 UNC x 1-1/2	21	819111016	Washer 11/32 x 5/8 x 16 Gauge
10	532123396	Keeper, Ground Drive Belt Idler	22	532123404	Keeper, Frame Ground Drive Belt
11	532123395	Arm, Ground Drive Clutch			
12	532004859	Idler, Flat			


NOTE: All component dimensions given in U.S. inches
1 inch = 25.4 mm

HARDWARE SHOWN LARGER FOR EASIER IDENTIFICATION

REPAIR PARTS

12.5 HP 38" LAWN TRACTOR-MODEL NO. LT120 (HA125R38B), PRODUCT NO. 954 00 04-92

TRANSAXLE



KEY NO.	PART NO.	DESCRIPTION
1	532123385	Pulley
2	812000028	Ring, Retainer
3	532127054	Transaxle, Peerless, 6 Speed, Model Number 930-028
4	532125096	Key, Woodruff #9
5	873680500	Nut, Crownlock 5/16-18
6	872140506	Bolt, Carriage 5/16-18 UNC x 3/4
7	532123378	Strap, Torque
8	817490512	Screw 5/16-18 x 3/4
9	532110422	Spring, Brake
10	532121749	Washer 25/32 x 1-1/4 x 16 Gauge
11	532123583	Key, Square
12	874760540	Bolt, Hex, Fin. 5/16-18 x 2-1/2
15	819171616	Washer 17/32 x 1 x 16 Gauge
17	532126293	Link, Shift
18	871040412	Bolt, Hex, Fin. 1/4-28 UNF x 3/4 Grade 8

KEY NO.	PART NO.	DESCRIPTION
19	810040400	Washer, Lock 1/4
20	819091210	Washer 9/32 x 3/4 x 10 Gauge
21	532126292	Arm, Shift
22	532105701	Washer, Shift Plate
23	532122011	Knob, Golfclub
24	532128202	Handle Assembly, Shift
25	876020416	Pin, Cotter 1/8 x 1
26	873810500	Locknut 5/16-24 UNF
27	873510500	Nut, Hex, Keps 5/16-18
28	532128085	Extension, Spring
30	532123692	Retainer Knob
32	819111116	Washer 11/32 x 11/16 x 16 Gauge
34	811050500	Washer, External Tooth 5/16
35	812000001	E-Ring


NOTE: All component dimensions given in U.S. inches
1 inch = 25.4 mm

HARDWARE SHOWN LARGER FOR EASIER IDENTIFICATION

REPAIR PARTS

12.5 HP 38" LAWN TRACTOR-MODEL NO. LT120 (HA125R38B), PRODUCT NO. 954 00 04-92

BRAKE / REAR MOWER LIFT ASSEMBLY



KEY NO.	PART NO.	DESCRIPTION	KEY NO.	PART NO.	DESCRIPTION
1	532071673	Cap, Plunger	16	819251816	Washer 25/32 x 1-1/8 x 16 Gauge
2	532123436	Rod, Parking Brake	17	812000034	Ring, Klip
3	532123437	Bracket, Parking Brake	18	532106888	Spring, Brake Rod
4	532008156	Cover, Pedal	19	873350600	Nut, Hex, Jam 3/8-16 UNC
5	532132205	Bracket, Clutch/Brake Pedal, L.H.	20	873800600	Locknut, Hex, with Washer Insert 3/8-16 UNC
6	876020312	Pin, Cotter 3/32 x 3/4	21	532131460	Rod, Brake, Rear
7	819131016	Washer 13/32 x 5/8 x 16 Gauge	25	532124961	Spring, Retainer
8	817490508	Screw, Hex Head, Thd., Roll. 5/16-18 x 1/2	27	532136780	Link, Lift, Rear
9	876020412	Pin, Cotter 1/8 x 3/4	28	532136779	Assembly, Rear Mower Lift
10	819131316	Washer 13/32 x 13/16 x 16 Gauge	29	872110506	Bolt, Carriage 5/16-18 UNC x 3/4
11	532123543	Rod, Brake, Front	30	873510500	Nut, Hex, Keps 5/16-16 UNC
12	532136263	Assembly, Clutch/Brake Pedal	31	532133095	Spring, Counterbalance
13	532123394	Rod, Clutch	32	532133721	Link, Lift Lever
14	532121978	Bracket, Lift Shaft			
15	532123641	Assembly, Brake, Pivot, Arm			


NOTE: All component dimensions given in U.S. inches
1 inch = 25.4 mm

HARDWARE SHOWN LARGER FOR EASIER IDENTIFICATION

REPAIR PARTS

12.5 HP 38" LAWN TRACTOR-MODEL NO. LT120 (HA125R38B), PRODUCT NO. 954 00 04-92

MOWER LIFT LEVER



KEY NO.	PART NO.	DESCRIPTION
1	532126470	Clip, Insulated
2	532122018	Bracket, Mower Clutch
3	874780408	Bolt, Hex Head, Fin. 1/4-20 UNC x 1/2 Grade 5
4	873680600	Nut, Crownlock 3/8-16 UNC
5	532132552	Assembly, Clutch Lever
6	532106451	Bolt, Shoulder
7	532135110	Assembly, Mower Clutch Arm
8	874930624	Bolt, Hex Head 3/8-16 UNC x 1-1/2
10	876020412	Pin, Cotter 1/8 x 3/4
12	532122027	Handle, Lift Lever
13	532136658	Assembly, Lift Handle
14	532133939	Spring, Compression
15	819131616	Washer 13/32 x 1 x 11 Gauge
18	532135107	Trunnion, Threaded 3/8-16
19	873680400	Nut, Crownlock 1/4-20

KEY NO.	PART NO.	DESCRIPTION
20	874760644	Bolt, Hex Head, Fin. 3/8-16 UNC x 2-3/4
22	532132561	Bracket, Lift Lever
23	876020312	Pin, Cotter 3/32 x 3/4
24	532007672	Washer 25/64 x 1-1/4 x 12 Gauge
25	532121933	Tube, Spacer
27	532121466	Knob
30	532135039	Rod, Tension, Clutch
31	873930600	Nut, Centerlock
32	532133435	Spring, Extension, Return
33	532062333	Washer .390 x 1.437 x .074
34	873680500	Nut, Crownlock 5/16-18
35	532133603	Cap, Vinyl, Red
36	872140506	Bolt, Carriage 5/16-18 x 3/4

NOTE: All component dimensions given in U.S. inches
1 inch = 25.4 mm

HARDWARE SHOWN LARGER FOR EASIER IDENTIFICATION

REPAIR PARTS

12.5 HP 38" LAWN TRACTOR-MODEL NO. LT120 (HA125R38B), PRODUCT NO. 954 00 04-92
MOWER DECK

KEY NO.	PART NO.	DESCRIPTION	KEY NO.	PART NO.	DESCRIPTION
1	532138356	Mower Deck Assembly	35	532132554	Clutch Rod, Secondary
2	873680500	Nut, Crownlock 5/16-18	36	819131316	Washer 13/32 x 13/16 x 16 Gauge
3	872140506	Bolt, Carriage 5/16-18 x 3/4	37	876020312	Pin, Cotter 3/32 x 3/4
4	532125074	Runner, L.H.	38	532133840	Idler Arm
5	532110485	Bearing	39	532129963	Washer .150 Thick
6	532128774	Housing, Mandrel	40	532129206	Pulley, Mandrel
7	532129895	Bearing	41	532137266	Nut, Flangelock 9/16
8	532137645	Shaft and Bearing Assembly, Mandrel (Includes Key Number 7)	42	532131494	Pulley, Flat Idler
9	532138497	Blade, High Performance	43	532122052	Spacer, Retainer
10	532129962	Washer, Hardened	44	819131612	Washer 13/32 x 1 x 12 Gauge
11	810030600	Washer, Lock 3/8	45	873680600	Nut, Crownlock 3/8-16
12	532850857	Bolt, Hex 3/8-24 x 1-1/4 Grade 8	46	532131290	Belt
13	532136929	Stripper, Mower, Vented	47	532133502	Spacer, Idler Arm
14	532106736	Shield, Deflector	48	532133503	Stiffener, Idler Arm
15	532106735	Rod, Hinge	49	532133551	Rod, Pivot
16	532137607	Bracket Assembly, Deflector	50	532131289	Rod, Brake, L.H.
17	532110452	Pushnut	51	532130840	Brake Assembly
18	532106734	Spring, Deflector	52	817490512	Screw, Hex Washer Head, Thd., Roll. 5/16-18 x 3/4
19	819111016	Washer 11/32 x 5/8 x 16 Gauge	53	532131288	Rod, Brake, R.H.
20	532105304	Cap, Sleeve	54	872110614	Bolt, Carriage 3/8-16 x 1-3/4 Grade 5
21	532128772	Runner, R.H.	55	532124788	Spring, Retainer
22	819111216	Washer 11/32 x 3/4 x 16 Gauge	56	532136782	Adjustment Plate, Rear Link, L.H.
23	532078158	Bolt, Hex Head 5/16-18 x 1-1/4	57	872140606	Bolt, Carriage 3/8-16 x 3/4
24	532124670	Retainer, Spring	58	819131212	Washer 13/32 x 3/4 x 12 Gauge
25	874600636	Bolt, Carriage 3/8-16 x 2-1/4	59	873800500	Locknut, Hex, with Washer Insert 5/16-18
26	819131612	Washer 13/32 x 1 x 12 Gauge	60	819111112	Washer 11/32 x 11/16 x 12 Gauge
27	532132556	Link Assembly, Front	62	532124660	Retainer Spring
28	873350800	Nut, Hex, Jam 1/2-13 UNC	--	532130794	Mandrel Assembly (Includes Key Numbers 5-8, 10-12, 39 and 41)
29	532130171	Trunnion	--	532138422	Mower Deck, Complete
30	873800800	Locknut with Washer Insert 1/2-13 UNC			
31	532132553	Clutch Rod, Primary			
32	873350600	Nut, Hex, Jam 3/8-16			
33	532132559	Arm, Suspension, Rear			
34	532133604	Trunnion 3/8-16			


NOTE: All component dimensions given in U.S. inches
1 inch = 25.4 mm

HARDWARE SHOWN LARGER FOR EASIER IDENTIFICATION

REPAIR PARTS

12.5 HP 38" LAWN TRACTOR-MODEL NO. LT120 (HA125R38B), PRODUCT NO. 954 00 04-92

DECALS




KEY NO.	PART NO.	DESCRIPTION
1	532129057	Decal, Engine, HP
2	532135073	Decal, Indicator
3	532137541	Decal, Hood, L.H.
4	532137540	Decal, Hood, R.H.
5	532125989	Decal, Logo, Grill
8	532131582	Decal, Logo, Fender
9	532124433	Decal, 80 DBA
10	532133796	Decal, Fender, Caution
11	532137259	Decal, Warning, Multi-Language

KEY NO.	PART NO.	DESCRIPTION
12	532137546	Decal, Hood, Insert, R.H.
13	532137547	Decal, Hood, Insert, L.H.
15	532126712	Decal, Instruction, Warning
--	532139186	Manual, Operator's
--	532139185	Manual, Repair Parts

Available accessories not included with tractor:

--	CER 38	Grass Catcher
----	--------	---------------

WHEELS & TIRES



KEY NO.	PART NO.	DESCRIPTION
1	532059192	Cap, Valve Stem
2	532065139	Stem, Valve
3	532124957	Fitting, Grease (Front Wheels Only)
4	532132696	Tire, Front
	532132703	Tire, Rear
5	532059904	Tube, Front Tire (Optional - Service Item Only)
	532008134	Tube, Rear Tire (Optional - Service Item Only)
6	532124972	Rim, Front
	532124973	Rim, Rear
8	532124959	Bearing Flange
9	532121748	Washer 25/32 x 1-5/8 x 16 Gauge
10	532124577	Cover, Wheel, Front, 6"
	532124578	Cover, Wheel, Rear, 8"

NOTE: All component dimensions given in U.S. inches
1 inch = 25.4 mm