


ROTARY LAWN MOWER - - MODEL NUMBER PR65N21CH (PR65N21CHD)

2



ROTARY LAWN MOWER - - MODEL NUMBER PR65N21CH (PR65N21CHD)

KEY NO.	PART NO.	DESCRIPTION	KEY NO.	PART NO.	DESCRIPTION
1	131696	Control Bar	44	185819	Rod, Stiffener
2	166860X479	Upper Handle	45	150406	Hex Head Thread Rolling Screw 3/8-16 x 1
3	161105X479	Lower Handle	46	107339X	Danger Decal
4	179585	Rope Guide	47	73800500	Nut, Hex
5	132004	Locknut 1/4-20	48	180410X004	Axle Arm Assembly, RR
6	131959	Handle Bolt	49	181383	Wheel
7	66426	Wire Tie	51	73990500	Nut, Hex
8	74780512	Hex Bolt 5/16-18 x 3/4	52	174161	Kit, Lawn Mower Housing (Includes Key Numbers 17, 18 and 46)
9	751152	Nut, Hex	53	851084	Hex Head Screw 3/8-24 x 1-3/8 Grade 8
11	149293	Engine Zone Control Cable	54	850263	Helical Lockwasher
12	750634	Hex Washer Head Screw #10-24 x 1/2	55	851074	Hardened Washer
13	850733X004	Up-Stop Bracket	56	189028	21" Blade
14	136376	Handle Knob	57	184590	Blade Adapter
15	51793	Hairpin Cotter	58	161551	Adjustment Bolt
17	165946X479	Support Bracket	67	188973	Grass Bag
18	17600406	Screw	68	188813	Frame, Grass Bag
19	186577X004	Axle Arm Assembly, LF	70	- - -	Engine, Briggs & Stratton, Model Number 123K02 (For engine service and replacement parts, call Briggs & Stratton at 1-800-233-3723)
20	186578X004	Axle Arm Assembly, RF			
21	188987	Rear Skirt			
22	168360X004	Selector Spring	72	165754	Mulcher Door
23	186612	Kit, Rear Door (Includes Springs)	73	154132	Bracket
24	73930500	Locknut 5/16-18	74	147286	Rod
25	186212X479	Handle Bracket Assembly, LH	75	152124	Spring
26	186213X479	Handle Bracket Assembly, RH	76	73800400	Nut, Hex
27	851856	Screw 1/4-20 x 3/8	77	165760	Deflector
29	160835X007	Wheel Adjusting Bracket, Front	78	170294	Throttle Control
30	183901	Spacer	79	183365	Screw
33	170143	Selector Knob	80	132004	Nut, Hex
34	180409X004	Axle Arm Assembly, LR	81	111190X	Clamp
35	166785	Locknut 5/16-18	82	83816	Screw
36	160828	Shoulder Bolt 5/16-18	--	162300	Warning Decal (Not Shown)
37	170262	Wheel Assembly	--	172782	Operator's Manual, English
38	164362	Shoulder Bolt	--	172783	Operator's Manual, French
39	83923	Flanged Locknut	--	188972	Repair Parts Manual, English / French
40	77400	Hubcap			
41	88652	Hinge Screw			
42	165766	Spring, LH			
43	165767	Spring, RH			

NOTE: All component dimensions given in U.S. inches.
1 inch = 25.4 mm