


KEY NO.	PART NO.	DESCRIPTION	KEY NO.	PART NO.	DESCRIPTION
1		Engine Assembly B&S Model No.110702 Type No. 3118-02	51	52160	Washer
			52	55015	Retainer Clip
			53	77400	Hub Cap
2	111500X	Drive Control Head	54	48088	Wheel Adjuster Assembly (Right)
3	107657X	Drive Control Bracket			
4	107658X	Drive Cable	55	48089	Wheel Adjuster Assembly (Left)
5	86261	Machine Screw 1/4-20 x 2 1/8			
6	62966	Machine Screw 1/4-20 x 1 1/4	56	61528	Flat Head Machine Screw 1/4-20 x 3/4
7	85723	Washer			
8	53490	Locknut 1/4-20	57	63601	Locknut 1/4-20
9	107659X	Zone Control	58	77865	Selector Knob
10	107655X	Remote Control	59	76401	Dust Cover
11	76146	Truss Head Machine Screw #10-24 x 2 1/2	60	74507	Pinion
			61	53753	E-Ring
12	78186	Pan Head Machine Screw #10-24 x 2	62	100945R	Discharge Guard
			63	53847	Washer .26 x 3/4 x .06
13	53109	Screw 1/4-20 x 1 1/2	64	674A260	Discharge Guard Bracket Assembly
14	74189	Locknut #10-24			
15	111280X	Upper Handle	65	674A261	Housing Bracket Assembly
16	85548	Control Bail	66	103673X	Hinge Rod
17	84683	Lower Handle	67	100958L	Torsion Spring
18	111185X	Rope Guide	68	59349	Pal Nut
19	85436	Screw 1/4-20 x 1 1/2	69	53490	Locknut 1/4-20
20	63601	Locknut 1/4-20	70	75449	Speed Nut
21	58714	Handle Bolt	71	75448	Drive Cover
22	63688	Handle Knob	72	69411	Pan Head Machine Screw #10-24 x 1 3/4
23	51793	Hairpin Cotter			
24	81281	Lever - Handle	73	75725	Pan Head Machine Screw #10-24 x 2 3/4
25	87945	Lever - Knob			
26	62363	Spring Lever	74	85285	Front Baffle
27	103268X	Trim Plate Assembly	75	85284	Rear Baffle
28	36953	Thread Cutting Screw #10-24 x 5/8	76	83691	V-Belt 3L
			77	82626	Hex Bolt 3/8-24 x 1 1/4 Gr. 8
29	75442	Rear Skirt	78	84942	Washer 3/8
30	63640	Cotter Pin	79	103524X	Blade
31	81254	Bracket	80	107250X	Blade Adapter
32	75680	Self-Tapping Screw #10-24 x 1/2	81	84942	Washer 3/8 (Spacer)
			82	76125	Hex Head Bolt 5/16 - 18 x 1 3/8 Gr. 5
33	103510X	Handle Bracket Assembly (Left)			
34	103511X	Handle Bracket Assembly (Right)	83	83629	Belt Snubber
35	59289	Washer	84	59708	Set Screw 1/4-20 x 5/16
36	55187	Self-Tapping Screw 5/16-18 x 3/4	85	84596	Engine Pulley
			86	65053	Woodruff Key #6
37	70385	Cable Clip	87	63124	Locknut
38	81276	Self-Tapping Screw #10-24 x 1/2	88	48039	Gear Case Replacement Kit
			89	53490	Locknut 1/4-20
39	103095X	Wheel Adjusting Bracket (R.R.)	90	84920	Spacer (Plastic)
40	103096X	Wheel Adjusting Bracket (L.R.)	91	85724	Hex Machine Screw 10-32 x 3/8
41	82987	Axle Arm Assembly	92	111078X	Housing Stripe Decal
42	84888	Selector Spring	93	111080X	Housing Decal
43	77865	Selector Knob	94	103777X	Drive Cover Decal
44	62335	Spring Washer	95	103772X	Trim Plate Decal
45	84921	Shoulder Bolt	96	85463	Danger Decal
46	62333	Washer	97	111061X	Mower Housing
47	74400	Locknut 3/8-16	98	85827	Control Cable Clip
48	88348	Washer 3/8			
49	86943	Wheel & Tire Assembly 9.0 (Rear)			
50	86954	Wheel & Tire Assembly 8.0 (Front)			

GEAR CASE ASSEMBLY PART NO. 88388

16



KEY NO.	PART NO.	DESCRIPTION	KEY NO.	PART NO.	DESCRIPTION
1	53838	Locknut 1/4-20	17	53753	E-Ring - 1/2 Shaft
2	85178	Adjusting Bracket	18	83684	Square Key
3	88386	Shifter Assembly	19	83720	Worm Shaft
4	57072	Seal	20	65692	Woodruff Key #3
5	57388	Driv-Lok Pin 1/8 x 1/2	21	83680	Worm
6	48032	Gear Case Halves (Incl. Upper & Lower Halves) (Incl. Ref. # 4,7)	22	50950	Hex Head Machine Screw 1/4-20 x 1 1/4
7	77881	Bearing	23	86012	Drive Shaft Cover
8	77039	Spring Bracket	24	65692	Woodruff Key #3
9	79947	Drive Shaft Kit	25	57076	Woodruff Key #213
10	57079	Thrust Washer	26	54338	Hex Head Bolt 1/4-20 x 2 3/4
11	75144	Yoke Clutch	27	83632	Spring
12	87822	Driv-Lok Pin 1/8 x 3/4	28	68038	Locknut 1/4-20
13	86447	Plug	29	75192	Spring
14	83659	Helical Gear	30	83681	Drive Pulley
15	75424	Jaw Clutch	31	74976	Retaining Ring
16	58354	Grease (1 lb. Can - Shell Darina AX)	32	83700	Cable Clamp
			33	54562	Self-Tapping Screw 10-24 x 3/8