




## Deck Assembly


Ref #	Part Number	Qty	Description
3	17600A		42" Deck Ass'y.
	813-06119		42" Deck Ass'y. Comp. (For Service Only)
4	17664		Belt Guard Deck
6	710-0152		Hex Bolt 3/8-24 x 1.0" Lg.
7	710-0599		Hex Wash. Hd. TT-Tap Scr. 1/4-20 x .5" Lg.
8	710-0258		Hex Bolt 1/4-20 x .62"
9	710-0888		Hex Bolt Special 5/16-24 x 1.0"
10	711-0792		Hinge Pin
11	712-0123		Hex Nut 5/16-24 Thd.
13	712-0181		Hex Top L-Nut 3/8-16 Thd.
14	712-0287		Hex Nut 1/4-20 Thd.
17	734-0973		Deck Wheel - 5"
18	736-0105		Bell-Wash .40" I.D. x .88" O D.
19	736-0119		L-Wash. 5/16" I.D.
20	736-0217		L-Wash. 3/8" I.D.- H.D.
22	738-0373		Shld. Bolt .498" Dia. x 1.53"
23	742-0499A		High-Lift Blade
25	748-0300		Blade Adapter
26	754-0371A		V-Belt
27	736-0270		Bell-Wash. 1/4" I.D.
28	09322		Brake Disc
33	710-0157		Hex Bolt 5/16-24 x .75" Lg.
35	712-0318		Hex Jam Nut 5/8-18 Thd.
37	736-0158		L-Wash. 5/8" I.D.
39	717-0906		Blade Spindle Ass'y. Comp.
42	756-0556		5.5" Dia. Pulley
52	703-1693		Hinge Mtg. Brkt.
53	732-0602		Torsion Spring
54	726-0106		Push Nut
55	731-1032		Chute Ass'y. Comp. (Incl. Ref. 10, 52, 53, 54, 55)
56	710-0157		Hex Bolt 5/16-24 x .75" Lg.
57	17493A		Deck Hanger Channel
58	736-0242		Bell-Wash .345" I.D. x .88"
59	710-0167		Carr. Bolt 1/4-20 x .5" Lg.
60	17861A		Deck Skirt Ext.- Long
61	17961		Deck Skirt Ext.- Short
62	712-0271		Hex Sems Nut 1/4-20 Thd.

Deck Lift & Hanger Assembly




## Deck Lift &amp; Hanger Assembly

Ref #	Part Number	Qty	Description
1	783-0103		Connecting Rod
2	683-0029		Pivot Link Ass'y.- L.H.
3	683-0028		Pivot Link Ass'y.- R.H. (Uses "E"-Ring)
4	17710		Deck Hanger Link Ass'y.
5	14800A		Deck Hanger Link Ass'y.
6	14804A		Deck Hanger Link Ass'y.
7	748-0331		Shld. Spacer .318" I.D.
8	736-0264		FI-Wash .344" I.D. x .62" O.D.
9	736-0119		L-Wash. 5/16" I.D.
10	712-0267		Hex Nut 5/16-18 Thd.
12	714-0470		Cotter Pin 1/8" Dia.
13	736-0256		FI-Wash .635" I.D. x 1.0" O.D.
14	683-0003		Height Adj. Stop Lever Ass'y. (Incl. Ref. 15), Optional
15	08540		Knob Optional
16	710-0604		Hex Wash. TT-Tap Scr. 5/16-18 x .75" Lg.
17	748-0176		Flange Brg .63" I.D. Optional
18	710-1238		Hex Wash. Hd. Scr. 5/16-18 x .875" Lg.
19	710-0118		Hex Bolt 5/16-18 x .75" Lg.
20	17730		Index Brkt.
21	783-0042		Upper Frame - R.H. New Part
23	736-0267		FI-Wash .385" I.D. x .87" O.D.
24	736-0160		FI-Wash .531" I.D. x .93" O.D.
25	726-0272		Clamp
26	738-0526		Running Board Rod
27	710-3007		Hex Wash. Hd. Tap Scr,
28	14802A		Link Deck Lift Ass'y.
29	711-0723A		Adj. Ferrule 3/8-24 Thd
30	17712		Adj. Deck Lift Link
31	712-3066		Hex Nut 1/2-20 Thd. (Gr. 5)
32	711-0841		Lift Link Adjuster
33	17637A		Lift Shaft Ass'y.
34	725-0803C		Safety Switch (Deck)
35	714-0145		Inter. Cotter Pin 3/8" Dia.
36	732-0637		Extension Spring
37	17636B		Stabilizer Bracket
38	738-0670		Shaft 1/2" Dia. x 10.28" Lg.
39	732-0638		Extension Spring
40	720-0233		Grip (Lift Handle)
41	17675		Deck Lift Handle Ass'y
42	738-0669		Shaft 3/8" Dia. x 9 3/4" Lg.
43	747-0598		Disengagement Rod
44	17624		Stabilizer Shaft Ass'y
45	732-0556		Extension Spring 7.58" Lg
46	783-0043		Upper Frame - L H New Part
47	741-0313		Flange Brg. .632" I.D.
48	17128		Spring Retainer Brkt
49	716-0104		"E"-Ring
50	736-0425		Bell-Wash 3/25" I.D.



## Electrical/Switches

Ref #	Part Number	Qty	Description
1	725-1635		Battery
2	725-1426		Solenoid
3	725-1625		Fuse 7.5 Amps
4	725-0634		Light Switch (Optional)
5	725-0925		Ammeter (Optional)
6	725-0267		Ignition Switch
7	725-1657		Safety Switch (Clutch) New Part
9	629-0201		Wire Harness w/o Ammeter
	629-0203		Wire Harness w/Ammeter
12	725-1643		Safety Switch (Reverse)
13	725-1649		Socket (Styles 0, 5)
	725-1650		Socket (Styles 8, 9)
	725-1651		Socket (Styles 1, 3, 7)
14	725-0963		Bulb (Headlight)
15	725-1303		Safety Switch (Seat)
16	725-0980		Ground Wire 7.5" Lg.
17	725-1439		Safety Switch (Seat)
18	629-0207		Harness Adaptor New Part




## Hood Style 7

Ref #	Part Number	Qty	Description
1	783-0020		Hood
2	738-0724		Shld. Bolt .375" Dia. x .125" Lg.
3	736-0342		Fl-Wash .28" I.D. x .75" O.D.
4	710-0206		Hex Bolt 1/4-20 x .88" Lg.
5	736-0329		L-Wash. 1/4" I.D.
6	712-0287		Hex Nut 1/4-20 Thd.
7	749-0916		Grille Support Rod
8	731-1362		Headlight Lens
9	712-0380		Flange L-Nut 1/4-28 Thd.
10	783-0018		Grille
11	736-0119		L-Wash. 5/16" I.D.
12	712-0267		Hex Nut 5/16-18 Thd."
13	725-0963		Lamp
14	725-1651		Socket
15	710-0703		Carriage Bolt 1/4-20 x .75" Lg.
16	710-0599		Hex Wash. Hd. TT-Tap Scr. 1/4-20 x .5" Lg.
18	726-0233		Bolt Retainer 1/4" I.D.
19	726-0130		Speed Nut #10-24 Thd.
20	710-0118		Hex Bolt 5/16-18 x .75" Lg.
21	17633A		Gas Tank Support Brkt.
22	731-1348		Dash
23	725-0267		Ignition Switch
24	725-0201		Ignition Key
25	746-0616A		Choke Control New Part
	746-0614A		Choke Control
	746-3021		Choke Control (Vanguard)
	746-3026		Choke Control (Tec.)
26	725-0634		Light Switch
27	725-0925		Ammeter
32	710-0286		Truss Mach. Scr. 1/4-20 x .5" Lg.
34	17870		Fender
35	17871A		Fender w/Cutout
38			UNKNOWN
39	17954A		Shift Cover w/Cutout
40	17286A		Shift Cover
41	831-0823A		Throttle Box Ass'y.
42	710-0779A		Truss Mach. AB-Tap Scr. #10 x .5" Lg.
43	746-0501		Throttle Control Wire
	746-0634		Throttle Control Wire
	746-0638		Throttle Control Wire (12 H.P. Tec )
	746-0637		Throttle Control Wire (16 H.P. Tec )
45	710-0603		Hex Wash. Hd. B-Tap Ser. 5/16-18 x .5" Lg.
46	17782		Choke Retainer
49	783-0035A		Dash Reinforcement Brkt.- L.H. New Part
50	783-0036A		Dash Reinforcement Brkt.- R.H. New Part
51	732-0714		Hood Spring
52	726-0326		Flat Fastener (Special)
53	736-3078		Fl-Wash .344" I.D. x 1" O.D.
54	736-0413		Spr. Wash .39" I.D. x .62" O.D.
55	736-0242		Bell-Wash .345" I.D. x .88" O.D.
56	710-0924		Pan Hd. Scr. 1/4-20 x .75" Lg.
57	710-0351		Truss Mach. Scr. #10-24 x .5" Lg.
	751-0302		Muffler (Single Cylinder Engines) Used on 11.5, 12 & 12.5 HP (B & S)
	712-0250		Conduit L-Nut (Hardware)




Ref #	Part Number	Qty	Description
	751-0443A		Muffler (Single Cylinder Engines) Used on 12 & 12.5 HP (Tec.)
	721-0208		Gasket (Hardware)
	738-0636		Shoulder (Hardware)



## Mulching Kits

Ref #	Part Number	Qty	Description
1	710-0134	2	Carriage Bolt 1/4-20 x .62" Lg.
2	710-0258	1	Hex Bolt 1/4-20 x .62" Lg.
3	710-3029	4	Hex Bolt 7/16-20 x 1.25" Lg. (Gr. 5)
4	710-0932	1	Carriage Bolt 1/4-20 x 1" Lg.
5	711-0957	1	Retaining Bolt
6	712-0378	4	Hex Nut 7/16-20 Thd.
7	712-0287	3	Hex Nut 1/4-20 Thd.
8	712-0291	1	Hex L-Nut 1/4-20 Thd.
9	712-0397	2	Wing Nut
10	736-0171	4	L-Wash. 7/16" I.D.
11	736-0329	3	L-Wash, 1/4" I.D.
12	742-0539	2	Mulching Blade 12.5"
13	742-0537	2	Mulching Blade 19.38" For model (096)
	742-0538	2	Mulching Blade 21.2" For model (097)
14	748-0365	2	Blade Adapter
15	783-0024	1	Top Mulching Baffle For model (096)
	783-0026	1	Top Mulching Baffle For model (097)
16	783-0025	1	Side Mulching Baffle For model (096)
	783-0027	1	Side Mulching Baffle For model (097)
17	783-0028	1	Locking Bracket
18	736-0217	2	L-Wash. 3/8" I.D.
19	710-1039	2	Hex Bolt 3/8-24 x 1" Lg.(Gr. 8)

Seat/Frame, Upper/Fuel Tank/Battery




## Seat/Frame, Upper/Fuel Tank/Battery

Ref #	Part Number	Qty	Description
2	710-1208		Hex Wash. Hd. Tap Scr. 5/16-18 x 3.25" Lg.
3	738-0155		Shld. Bolt .437" Dia. x .162"
4	738-0145		Shld. Bolt .50" Dia. x .84"
5	736-0141		Spr-Wash .445" I.D. x .75
6	783-0039		Seat Pivot Bracket
7	751-0603		Fuel Cap
8	751-0553		Fuel Tank (12.5 W.P. & Smaller)
	751-0555		Fuel Tank (13 H.P. & Larger)
9	726-0209		Tie Strap
10	751-0535-15		Fuel Line
11	726-0205		Hose Clamp
13	712-0287		Hex Nut 1/4-20 Thd.
14	736-0329		L-Wash. 1/4" I.D.
16	732-0735		Compression Spring New Part
21	738-0526		Running Board Rod
22	710-0227		Hex Wash. Hd. AB-Tap Scr. #8 x .50" Lg.
23	726-0139		Speed Nut #102
24	783-0041		Front Pivot Brkt.
25	710-0623		Hex Tap Scr. 3/8-16 x .75"
26	710-0726		Hex Wash. Hd. AB-Tap Scr. 5/16 x .75" Lg.
28	710-0134		Carriage Bolt 1/4-20 x .62"
29	17770A		Running Board (R.H. & L.H.)
30	761-0168A		Blade Brake Ass'y.
32	731-0909		Rubber Foot Pad - L.H. Optional Parts
	731-0910		Rubber Foot Pad - R.H. Optional Parts
	723-0422		Abrasive Foot Pad Optional Parts
33	710-0323		Truss Mach. Scr. 5/16-18 x .75" Lg
34	683-0065		Lower Frame New Part
35	736-0169		L-Wash. 3/8" I.D.
36	726-0278		Insulator Boss Plate
37	736-0264		FI-Wash .344" I.D. x .625" O.D.
38	710-0118		Hex Bolt 5/16-18 x .75" Lg.
39	783-0042		Upper Frame - R.H. New Part
41	712-0798		Hex Nut 3/8-16 Thd.
42	732-0581B		Extension Spring 5.31" Lg.
43	731-1200		Battery Cover
44	725-1635		12-V Battery
45	783-0043		Upper Frame - L.H. New Part
46			Shift Cover See "Lawn Tractors Style 0" through "Lawn Tractors Style 9" illustrations and parts lists.
47	725-1643		Reverse Safety Switch
48	726-0279		Insulator Plate
49	17951		Seat Pivot Brkt. Support - L.H.
50	17953		Hitch Plate
51	712-0267		Hex Nut 5/16-18 Thd.
52	736-0119		L-Wash. 5/16" I.D.
53	17239A		Seat Lift Brkt.
54	757-0363		Seat 8-7/8" High
	757-0364		Seat 8-7/8" High (Yellow)
	757-0360		Seat 10-5/8" High
	757-0365		Seat 10-5/8" High (Yellow)
	757-0350		Seat 14-1/4" High
	757-0372		Seat 14-1/4" High (Yellow)
55	17950		Seat Pivot Brkt. Support - R.H.
56	738-0296		Shld. Bolt .437" Dia. x .268"

## Seat/Frame, Upper/Fuel Tank/Battery

Ref #	Part Number	Qty	Description
57	725-1303		Spring Switch
59	710-0650		Hex Wash. TT-Tap Scr. 5/16-18 x 7/8" Lg.
62	726-0320		Insulator Nut Plate
63	725-1439		Safety Switch (Seat)
64	732-0674		Battery Tray Clip (Single Cylinder)
65	17952		Battery Tray
66	710-0351		Truss Mach. B-Tap Scr. #10 x .5" Lg.
67	748-0347		Spring Spacer
68	710-1221		Pan Hd. Cutting Scr. 5/16-18 x .75" Lg.
69	710-0118		Hex Bolt 5/16-18 x .75" Lg.



## Speed Control Lever

Ref #	Part Number	Qty	Description
1	732-0645		Compression Spring
2	712-0267		Hex Nut 5/16-18 Thd.
3	736-0119		L-Wash. 5/16" I.D.
4	17956		Shift Lever Support
5	711-0198		Ferrule 3/8-24 Thd.
6	747-0787		Speed Control Rod
7	750-0662		Spacer 1.56" Lg.
8	736-0253		Bell-Wash .505" I.D. x 1"
9	736-0300		FI-Wash .385" I.D. x .87"
10	17888A		Speed Selector Lever
11	720-0232		Shift Knob
12	750-0913		Spacer 1.46" Lg.
13	736-0242		Bell-Wash .345" I.D. x .88"
14	710-3056		Hex Bolt 5/16-18 x 3.25" Lg.
15	714-0111		Cotter Pin 3/32" Dia. x 1"
16	736-0226		FI-Wash .469" I.D. x .88"
17	736-0418A		FI-Wash .34" I.D. x 2.25"





## Steering Assembly/Wheels, Front/Axle, Front


Ref #	Part Number	Qty	Description
1	731-0220		Steering Wheel Cap
	731-1459		Steering Wheel Cap (Sq.- MTD) New Part
	731-1460		Steering Wheel Cap (Square - No Logo) New Part
2	712-0411		Hex L-Nut 5/16-24 Thd.
3	736-0242		Belleville Wash .345" I.D.
4	731-0805		Steering Wheel (3 Spoke)
	731-1406		Steering Wheel (3 Spoke) New Part
	731-0806A		Steering Wheel (4 Spoke)
5	731-0559		Steering Bellow - 4.5" (Style 8)
	731-0954		Steering Bellow - 9" (Style 0, 1, 3, 4, 5, 6, 9)
	731-1542		Steering Bellow - 3.25" (Style 7)
6	737-0280		Grease Fitting (Optional)
7	741-0587		Flange Bearing .628" I.D. x 1.36 O.D. (Style 8)
9	17198A		Retainer Plate
10	738-0141		Shoulder Bolt .437" Dia. x .35 Lg. 5/16-18 Thd.
11	710-0152		Hex Bolt 3/8-24 x 1.0" Lg. (Gr. 5)
13	750-0535		Spacer.380" I.D. x .625" O.D. x .227
14	736-0217		L-Wash. 3/8" I.D. (H.D.)
15	710-0726		Hex Wash. Hd. Self-Tap Scr.
16	711-1001		Steering Drag Link
17	783-0041		Front Pivot Brkt.
18	738-0527		Shoulder Bolt .498" Dia. x 2.04 Lg. 3/8-16 Thd.
19	712-0798		Hex Nut 3/8-16 Thd.
20	736-0169		L-Wash. 3/8" I.D.
21	712-0411		Hex L-Nut 5/16-24 Thd.
22	16481A		Steering Arm Front Axle
23	710-0772		Hex Bolt 5/16-24 x 2.00" Lg. (Grade 5)
24	741-0487A		Hex Flg. Brg .632 I.D.
25	683-0002		Pivot Bar Ass'y.
26			Front Axle Ass'y.- L.H.
	634-0056		Wheel Ass'y. Comp.
	634-0105		Wheel Ass'y. Comp.
	734-0864		Tire Only
	734-1731		Tire Only
	634-0024		Rim Only
	741-0487A		Bearing
	734-0255		Air Valve
	737-0211		Grease Fitting Optional
	737-0212		Grease Plug
	17585		Front Axle Ass'y. - L.H.
	17584		Front Axle Ass'y. - R.H.
	683-0041		Front Axle Ass'y. - L.H. (46" Deck)
	683-0040		Front Axle Ass'y. - R.H. (46" Deck)
27	712-0241		Hex Nut 3/8-24 Thd.
28	736-0169		L-Wash. 3/8" I.D.
29	723-3018		Ball Joint 3/8-24 Thd.
30	747-0753		Tie Rod (Adjustable)
	747-0861		Tie Rod (Non-Adjustable)
31	712-0711		Hex Jam Nut 3/8-24 Thd.
32			Front Axle Ass'y.- R.H.
	634-0056		Wheel Ass'y. Comp.
	634-0105		Wheel Ass'y. Comp.
	734-0864		Tire Only
	734-1731		Tire Only
	634-0024		Rim Only
	741-0487A		Bearing

## Steering Assembly/Wheels, Front/Axle, Front

Ref #	Part Number	Qty	Description
	734-0255		Air Valve
	737-0211		Grease Fitting Optional
	737-0212		Grease Plug
	17585		Front Axle Ass'y. - L.H.
	17584		Front Axle Ass'y. - R.H.
	683-0041		Front Axle Ass'y. - L.H. (46" Deck)
	683-0040		Front Axle Ass'y. - R.H. (46" Deck)
33			Wheel Ass'y. Comp.
	634-0056		Wheel Ass'y. Comp.
	634-0105		Wheel Ass'y. Comp.
	734-0864		Tire Only
	734-1731		Tire Only
	634-0024		Rim Only
	741-0487A		Bearing
	734-0255		Air Valve
	737-0211		Grease Fitting Optional
	737-0212		Grease Plug
	17585		Front Axle Ass'y. - L.H.
	17584		Front Axle Ass'y. - R.H.
	683-0041		Front Axle Ass'y. - L.H. (46" Deck)
	683-0040		Front Axle Ass'y. - R.H. (46" Deck)
34			Front Wheel Rim Only
	634-0056		Wheel Ass'y. Comp.
	634-0105		Wheel Ass'y. Comp.
	734-0864		Tire Only
	734-1731		Tire Only
	634-0024		Rim Only
	741-0487A		Bearing
	734-0255		Air Valve
	737-0211		Grease Fitting Optional
	737-0212		Grease Plug
	17585		Front Axle Ass'y. - L.H.
	17584		Front Axle Ass'y. - R.H.
	683-0041		Front Axle Ass'y. - L.H. (46" Deck)
	683-0040		Front Axle Ass'y. - R.H. (46" Deck)
35			Bearing
	634-0056		Wheel Ass'y. Comp.
	634-0105		Wheel Ass'y. Comp.
	734-0864		Tire Only
	734-1731		Tire Only
	634-0024		Rim Only
	741-0487A		Bearing
	734-0255		Air Valve
	737-0211		Grease Fitting Optional
	737-0212		Grease Plug
	17585		Front Axle Ass'y. - L.H.
	17584		Front Axle Ass'y. - R.H.
	683-0041		Front Axle Ass'y. - L.H. (46" Deck)
	683-0040		Front Axle Ass'y. - R.H. (46" Deck)
36	736-0285		FI-Wash .635 I.D. x 1.59" O.D.
37	731-0484A		Front Wheel Hub Cap
	731-1787		Spoked Hub Cap (Yellow) Optional
	734-1613		Spoked Hub Cap (Gray) Optional
	734-1612		Spoked Hub Cap (Beige) Optional
38	714-0470		Cotter Pin 1/8" Dia. x 1.25"
39	736-0187		FI-Wash .640" I.D. x 1.24" O.O.

## Steering Assembly/Wheels, Front/Axle, Front

Ref #	Part Number	Qty	Description
40	726-0214		Push Cap 5/8" Dia. Rod
42	712-0446		Hex Jam Nut 3/8-24 Thd.
43	710-0538		Hex L-Bolt 5/16-18 x .62"
44	736-0119		L-Wash. 5/16" I.D.
45	736-0343		FI-Wash .33" I.D. x 1.25" O.D.
46	750-0532		Spacer (Plastic)
47	712-0214		Hex Cent. L-Nut 3/8-24 Thd.
48	736-0169		L-Wash. 3/8" I.D.
49	712-0158		Hex Cent. L-Nut 5/16-18 Thd.
50	736-0119		L-Wash. 5/16" I.D.
51	717-0622A		Steering Gear Segment
52	741-0225		Hex Flg. Brg .634 I.D.
53	736-0187		FI-Wash. (Hardened)
54	738-0743		Steering Shaft
57	710-0837		Oval Hd. Cr.- Sunk Scr. #10 x 5/8" Lg. (Style 8)
58	736-0271		Wave-Wash .32" I.D. x .62" O.D.
59	736-0187		FI-Wash. (Hardened)
60	723-3018		Drag Link Ball Joint 3/8-24 Thd.
61	736-0607		Ext. L-Wash. 5/16" I.D.
63	727-0425A		Spring Clip (Used w/Spoked Hub Cap)
64	736-0356		Bell-Wash .39" I.D. x 1.38" O.D.
65	731-1291		Pivot Bar End Cap (Optional)
66	710-0459		Hex Bolt 3/8-24 x 1.5" Lg. (Gr. 5)
69	731-1389		Plastic Tube 1.54" Lg.
70	731-0955		Steering Wheel Insert (Optional)
71			UNKNOWN
72	738-0886		Upper Steering Shaft (Used w/46" Deck)
73	650-0001		Lower Steering Shaft (Used w/46" Deck)
74	710-0958		Hex Bolt 1/4-20 x 1.25" Lg.
75	712-0324		Hex L-Nut 1/4-20 Thd.




## Transaxle Assembly

Ref #	Part Number	Qty	Description
	918-0163B	1	Transaxle Complete
1	732-0614		Wire Ring
2	716-0231		"E" - Ring
3	710-1026		Hex Wash. TT-Tap Scr. 1/4-20 x 1.75" Lg.
4	710-0809		Hex Tap Scr. 1/4-20 x 1.25" Lg.
5	719-0314		Upper Housing
6	712-0200A		Hex Jam Nut 1/2-20 Thd.
7	717-1019		Miter Gear
8	711-0861		Input Shaft
10	736-0335		Thrust Washer 5/8" I.D. x 1.25" O.D.
11	717-0633		Pinion Input 14T
12	716-0171		Retaining Ring
13	711-1003		Drive Shaft - R.H. Brake New Part
14	741-0336		Flange Brg. 5/8" I.D. x 3/4" Lg
15	717-1362		Bevel Gear 42T Small I.D.
16	717-1363		Bevel Gear 42T Large I.D.
17	718-0228		Clutch Collar
18	717-1020		Miter Gear 15T (H.D.)
19	716-0184		Snap Ring
20	741-0589		Thrust Bearing
21	710-0862A		Pan Head Scr. 1/4-20 x .50" Lg. w/Patch
22	717-0537		Axle R.H.
23	741-0340		Sleeve Bearing 3/4" I.D. x 1.0" Lg.
24	721-0179		Oil Seal 3/4" I.D.
25	750-0767		Axle Spacer
26	736-0445		FI-Wash .760" I.D. x 1.5" O D.
27	711-0918		Cross Shaft
28	717-1252		Differential Can Ass'y.
32			Washer
	736-0495		Thrust Wash. 5/8" I.D. x 1" O.D. x .025" Thk.
	736-0336		FI-Wash. 5/8" I.D. x 1" O.D. x .030" Thk.
	736-0494		Thrust Wash. 5/8" I.D. x 1" O.D. x .035" Thk.
	736-0337		FI-Wash. 5/8" I.D. x 1" O.D. x .040" Thk.
34	719-0313		Lower Housing
35	718-0150		Anti-Rotation Brkt.
37			Washer
	736-0349		FI-Wash. 5/8" I.D. x 1" O.D. x .020" Thk.
	736-0336		FI-Wash. 5/8" I.D. x 1" O.D. x .030" Thk.
	736-0337		FI-Wash. 5/8" I.D. x 1" O.D. x .040" Thk.
38	712-0273		Hex Nut 5/16-24 Thd.
39	736-0371		FI-Wash .344" I.D. x .875" O.D.
40	717-0700		Actuating Arm
41	761-0198		Brake Yoke
42	717-0682		Puck Plate
43	717-0678		Brake Puck
44	717-0536		Axle L.H.
45	761-0202		Brake Disc
46	741-0337		Flange Bearing 5/8" I.D. x 15/16" Lg.
48	611-0011		Shift Fork Ass'y.
49	741-0862		Ball Detent .250" Dia.
50	732-0863		Spring Detent
52	741-0335		Needle Brg. 5/8" I.D. x 1/2" Lg.
54	736-0349		FI-Wash. 5/8" I.D. x 1" O.D. x .020 Thk.
55	741-0343		Actuating Pin 5/16" Dia.
56	710-1206		Hex Wash Hd. Self-Tap Scr. 1/4-20 Thd.
57	717-1364		Differential Gear 58T

Ref #	Part Number	Qty	Description
58	736-0349		FI-Wash. 5/8" I.D. x 1" O.D. x .020 Thk.
	736-0495		Thrust Wash. 5/8" I.D. x 1" O.D. x .025" Thk.
60			Washer
	736-0492		FI-Wash. .76" I.D. x 1.5" O.D. x .010" Thk.
	736-0493		FI-Wash. .76" I.D. x 1.5" O.D. x .020" Thk.
	736-0351		FI-Wash. .76" I.D. x 1.5" O.D. x .030" Thk.
	736-0445		FI-Wash. .76" I.D. x 1.5" O.D. x .060" Thk.
61	736-0519		Thrust Washer
	737-0148		Grease - Shell (15 oz.)

Wheels, Rear/Drive/Frame, Lower/Pedal Assembly





## Wheels, Rear/Drive/Frame, Lower/Pedal Assembly

Ref #	Part Number	Qty	Description
	1		Engine
2	710-0726		Hex Wash. AB-Tap Scr. 5/16" x .75"
3	725-0980		Electric Ground Wire
5	736-0119		L-Wash. 5/16" I.D.
7	736-0247		Fl-Wash .406" I.D. x 1.25"
9	750-0965		Spacer
8	736-0222		Ext. L-Wash. 1/4" I.D.
10	710-1007		Hex Tap Scr. 3/8-16 x 1.5" Lg.
11	683-0065		Lower Frame Ass'y. New Part
12	726-0235		Speed Clip
13	712-0287		Hex Nut 1/4-20 Thd.
14	736-0329		L-Wash. 1/4" I.D.
16	17893A		Belt Guard Brkt. Ass'y. New Part
17	736-0242		Bell-Wash .345" I.D. x .88"
18	712-0267		Hex Nut 5/16-18 Thd.
19	711-0986		Belt Guard Stud 3.6" Lg.
20	714-0114		Sq. Key 1/4" x 1/4" x 2.00"
21	756-0488		Engine Pulley
22	736-0322		Fl-Wash. 7/16" I.D. x 1.25"
23	736-0171		L-Wash. 7/16" I.D.
24	710-0757		Hex Bolt 7/16-20 x 1.50" Lg.
25	754-0280		Variable-Speed Belt
26	710-0118		Hex Bolt 5/16-18 x .75" Lg.
27	17963		Bearing Shaft Bracket Ass'y.
28	741-0591		Flanged Nyliner Brg .63" I.D. x .6" Lg.
29	712-0241		Hex Nut 3/8-24 Thd.
30	17643		Idler Bracket (Used w/20" Wheels w/o 46" Deck)
	17694		Idler Bracket (Used w/18" Wheels or 46" Deck)
31	736-0169		L-Wash. 3/8" I.D.
32	712-0241		Hex Nut 3/8-24 Thd.
33	17629A		Transaxle Support Brkt.
34	732-0556		Ext. Spring .94" O.D. x 7.58"
35	714-0149B		Inter. Cott-Pin
36	750-0802		Spacer .63" I.O.
39	712-0138		Hex Nut 1/4-28 Thd.
43	710-0599		Hex Wash. Hd. S-Tap Scr. 1/4-20 x .50" Lg.
44	17715B		Clutch/Brake Pedal Ass'y.
45	736-0264		Fl-Wash .344" I.D. x .62"
47	17686A		Brake Rod Ass'y.
48	735-0196		Foot Pad
51	17705		Shift Lever Ass'y.
53	732-0264		Ext. Spring .38" O.D. x 2.5"
54	732-0413		Ext. Spring 7.08" (Used w/20" Wheels w/o 46" Deck)
	732-0642		Ext. Spring 7.33" (Used w/18" Wheels or 46" Deck)
55	710-1068		Hex Bolt 5/16-18 x 3.5" Lg. (Used w/18" Wheels or 46" Deck)
	710-0189		Hex Bolt 5/16-18 x 3" Lg. (Used w/20" Wheels w/o 46" Deck)
56			Wheel Ass'y. Comp.
	734-0817		Wheel Ass'y. Comp. 18" x 9.50"
	734-0448		Tire Only
	634-0070		Rim Only
	734-0592		Wheel Ass'y. Comp. 18" x 6.50"
	734-0294		Tire Only
	634-0069		Rim Only

## Wheels, Rear/Drive/Frame, Lower/Pedal Assembly

Ref #	Part Number	Qty	Description
	734-1675		Wheel Ass'y. Comp. 20" x 8.0"
	734-1596		Tire Only
	634-0070		Rim Only
	634-0104		Wheel Ass'y. Comp. 20" x 8.0"
	734-1730		Tire Only
	634-0070		Rim Only
57			Wheel Rim Only
	734-0817		Wheel Ass'y. Comp. 18" x 9.50"
	734-0448		Tire Only
	634-0070		Rim Only
	734-0592		Wheel Ass'y. Comp. 18" x 6.50"
	734-0294		Tire Only
	634-0069		Rim Only
	734-1675		Wheel Ass'y. Comp. 20" x 8.0"
	734-1596		Tire Only
	634-0070		Rim Only
	634-0104		Wheel Ass'y. Comp. 20" x 8.0"
	734-1730		Tire Only
	634-0070		Rim Only
58	734-0255		Air Valve (Service Only)
59	710-0627		Hex Bolt 5/16-24 x .75" Lg.
61	732-0722		Brake Return Spring Anchor New Part
62	711-0768		Belt Guard Pin 1/4-20 Thd.
63	736-0275		FI-Wash .34" I.D. x .68" O.D.
64	710-0428		Hex Bolt 1/4-28 x 1.25" Lg.
65	732-0568		Ext. Spring
66	732-0384		Ext. Spring .62" O.D. x 6.12"
67	16554A		Variable Speed Torque Brkt. Ass'y.
	16352A		Variable Speed Torque Brkt. Ass'y. (30" Deck Only)
68	741-0419		Flanged Bearing
69	714-0111		Cotter Pin 3/32" Dia.
70	748-0234		Shoulder Spacer .27" Lg.
71	747-0530A		Speed Control Link
72	741-0405		Truss Bearing .56 Dia. x 1.25"
73	720-0232		Shift Knob
74	756-0437		FI-Idler Pulley 3.25" x .75"
75	656-0005		"V"-Pulley (Used w/18" Wheels or 46" Deck)
	656-0004		"V"-Pulley (Used w/20" Wheels w/o 46" Deck)
76	736-0427		Bell-Wash .56" I.D. x 1.125"
77	712-3035		Hex Jam Nut 9/16-18 Thd.
78	710-0539		Hex Bolt 3/8-24 x 1.75" Lg.
79	754-0370		Variable Speed Belt
80	716-0114		Snap Ring .56" Dia.
81	736-0355		FI-Wash.
82	717-0800A		Variable Speed Pulley Ass'y. 5" O.D.
83	711-1000		Belt Keeper 3" Lg.
84	16354B		Variable Speed Brkt. Ass'y.
85	732-0525		Comp. Spring - Clip
86	17668		Axle Support Brkt.- R.H.
	17669		Axle Support Brkt.- L.H. (Not Shown)
88	725-1426		Solenoid
89	17630		Shift Lever Bracket
90	736-0414		Teflon Washer .565" I.D.
93	725-1657		Safety Switch (Clutch) New Part
94	738-0755		Shld. Bolt 3/8-24 x 3.12" Lg.
96	748-0334		Transaxle Spacer (Used w/18" Wheels or 46" Deck)

## Wheels, Rear/Drive/Frame, Lower/Pedal Assembly

Ref #	Part Number	Qty	Description
97	736-0105		Bell-Wash .38" I.D. x .88"
98	738-0569		Shaft .56" Dia. x 3.875" Lg.
99	736-0331		Bell-Wash .39" I.D. x 1.12"
100	736-0256		FI-Wash .64" I.D. x .94"
101	714-0470		Cotter Pin 1/8" Dia. x 1.25"
102	710-0604		Hex Wash. Hd. Scr. 5/16-18 x .62" Lg.
103	734-1615		Hub Cap (Gray) Optional
	734-1614		Hub Cap (Beige) Optional
	734-1788		Hub Cap (Yellow) Optional
106	710-0323		Pan Hd. Mach. Scr. 5/16-18 x .75" Lg.
107	17860		Pedal Bracket
108	714-0470		Cotter Pin 1/8" Dia. x 1.25"
109	711-0198		Ferrule
110	710-0376		Hex Bolt 5/16-18 x 1.0" Lg.- (Gr. 5)
111	710-0195		Hex Bolt 1/4-28 x .50" Lg.
112	736-0270		Bell-Wash .265" I.D. x .75"
113	17707		Shift Lever Link Ass'y.
114			Muffler See "Lawn Tractors Style 0" through "Lawn Tractors Style 9" illustrations and parts lists.
	751-0302		Muffler Used on 11.5, 12 & 12.5 HP (B & S)
	712-0250		Conduit L-Nut Hardware
	751-0443A		Muffler Used on 12 & 12.5 HP (Tec.)
	721-0208		Gasket Hardware
	738-0636		Shoulder Bolts Hardware
115	736-0140		FI-Wash .385" I.D. x .62"
116	741-0404	(2 Req'd.)	Needle Brgs.
117	727-0425A		Spring Clip (Used w/Ref. #103)
118	736-0607		External L-Wash. 5/16" I.D.
119	710-0650		Hex TT-Tap Scr. 5/16-18 x .75"
120	17840		Transaxle Mtg Brkt.