


PARTS LIST 707



REF. NO.	PART NO.	DESCRIPTION
1	682-0051A	Mower Housing, 18"
2	731-2425	Motor Support
3	710-1756	Screw, M7 x 25
4	724-0309	Electric Motor, 115V, 1500W
6	731-2400	Air Guide Cover
7	731-2401-0637	Hood
8	631-0132	Blade Hub Assembly
9	742-0827	Mulching Blade
10	782-7050	Locking Plate
11	624-0075	Screw, Blade
12	731-1028	Trailing Shield
13	17098	Hinge Clip
14	731-1409	Side Discharge Deflector
15	682-7002	Mulch Plug
16	732-0731	Torsion Spring
17	747-0710	Hinge Pin
18	782-7006	Chute Hinge
19	736-0270	Beleville Washer
20	710-0599	Screw
21	682-3001A	Handle Bracket Assy. LH
22	682-3000A	Handle Bracket Assy. RH
23	15262B	Pivot Bar
24	738-0507B	Shoulder Bolt
25	14832	Lever and Knob Assy. (Incl #26)
26	720-0190	Knob, Height Adjustment
27	15261A	Adjusting Plate
28	14578	Height Adjustment Assembly RH (Includes #23-27)
	14579	Height Adjustment Assembly LH (Includes #23-27)
29	736-0105	Spring Washer
30	734-1781	Wheel
31	738-0102	Axle Bolt
32	736-0356	Spring Washer
33	712-0798	Nut
34	749-1310-0637	Upper Handle
35	725-1937	Switch Plug Combination
36	710-1757	Screw
37	747-1094	Guide Rod
38	726-0368	Cord Restraint
39	731-1267	Height Adjuster, Lower Handle
40	731-1268	Height Adjuster, Upper Handle
41	731-1388	Insulating Washer
42	710-0450	Carriage Bolt
43	720-0241	Wing Nut
44	749-0885	Lower Handle
45	714-0104	Internal Cotter Pin
46	731-2422	Cable Guide
47	736-0695	Washer