


# PARTS LIST 136



<b>REF. NO.</b>	<b>PART NO.</b>	<b>DESCRIPTION</b>
1	749-1042A	Upper Handle
2	749-1312	Lower Handle
3	720-0369	Handle Plug
4	710-1718	Handle Bolt
5	736-0649	Lock Washer
6	712-0690	Hex Nut
7	710-1757	Screw
8	725-1941	Motor / Blade Control Switch
9	731-2427	Cord Insulator
10	731-2421-0638	Mower Housing (Incl. Ref# 39-41)
11	731-2088A-0637	Electric Motor Cover
12	731-2224	Air Guide Pot
13	724-0310	Electric Motor
14	710-1756	Screw
15	631-0148	Blade Hub Assembly
16	742-0804	Cutting Blade
17	731-1961	Lock Washer
18	624-0077	Blade Bolt
19	731-1971A-0637	Rear Discharge Door
20	747-1072	Rod
21	732-0912	Spring
22	736-0697	Washer
23	736-0698	Lock Washer
24	710-1350	Screw
25	731-1805-0638	Cap
26	782-0609	Holder Plate
27	734-1884-0637	Rear Wheel
28	734-1885-0637	Front Wheel
29	720-0343-0637	Rear Wheel Cap
30	720-0342-0637	Front Wheel Cap
31	738-1031	Axle Bolt
32	731-2402	Rear Trailing Shield
33	710-1758	Screw
34	747-1010	Guide Rod
35	726-0368-0637	Cable Clamp
37	731-1968-0637	Grass Bag
38	731-2426-0637	Grass Bag Cover
39	782-9095-0638	Protection Plate
40	736-0766	Washer
41	728-0286	Rivet