



Ref #	Part Number	Qty	Description
1	951-11012		Bolt
2	951-11054		Valve Cover
2	951-11054	1	Valve Cover
3	731-07059		Breather Hose
4	726-04101		Hose Clamp
5	N/A	1	Head Cover Gasket
5	N/A	1	Head Cover Gasket
5	N/A	1	Head Cover Gasket
5	N/A	1	Head Cover Gasket
5	N/A	1	Head Cover Gasket
6	N/A	1	Intake Valve Spring Seat
7	751-11124		Pivot Locking Nut
7	751-11124	2	Pivot Locking Nut
8	751-11123		Valve Adjusting Nut
8	751-11123	2	Valve Adjusting Nut
9	N/A	2	Rocker Arm
10	710-04902		Pivot Bolt
10	710-04902	2	Pivot Bolt
11	N/A	1	Exhaust Valve Adjuster
12	N/A	1	Exhaust Valve Spring Seat
13	N/A	2	Valve Spring
14	N/A	1	Intake Valve Seal
15	710-04933		Bolt
16	N/A	1	Push Rod Guide Plate
17	N/A	1	Cylinder Head - Complete
18	951-10292		Spark Plug
19	951-11282		Muffler Assembly
20	710-05001		Stud
20	710-05001	2	Stud
21	951-11289		Muffler Gasket
21	951-11289	1	Muffler Gasket
21	951-11289	1	Muffler Gasket
21	951-11289	1	Muffler Gasket
21	951-11289	1	Muffler Gasket
22	712-04214		Nut
23	710-05002		Bolt
24	951-11111		Exhaust Pipe Shield
25	710-04940		Bolt
26	710-04915		Bolt
27	951-10642A		Muffler Shroud
28	710-04939		Stud, M6 x117
29	710-04910		Stud, M6 x 105
30	N/A	1	Carburetor Insulator Gasket
30	N/A	1	Carburetor Insulator Gasket
30	N/A	1	Carburetor Insulator Gasket
30	N/A	1	Carburetor Insulator Gasket
31	N/A	1	Carburetor Insulator Plate
31	N/A	1	Carburetor Insulator Plate
31	N/A	1	Carburetor Insulator Plate
31	N/A	1	Carburetor Insulator Plate
31	N/A	1	Carburetor Insulator Plate
32	N/A	1	Carburetor Gasket
32	N/A	1	Carburetor Gasket
33	951-10638		Carburetor Assembly
33	951-10638		Carburetor Assembly
34	N/A	2	Carburetor Gasket Plate
34	N/A	2	Carburetor Gasket Plate
35	951-11112		Choke Control Bracket
36	951-10634		Engine Shroud
37	712-04213		Nut
38	951-11284		Choke Knob

Ref #	Part Number	Qty	Description
38	951-11284		Choke Knob
39	951-10757		Throttle Control Knob
40	951-10637		Ignition Switch
43	951-10640		Choke Push Rod
44	951-10635		Heater Box
45	710-04919		Bolt
46	N/A	1	Cylinder Head Gasket
46	N/A	1	Cylinder Head Gasket
46	N/A	1	Cylinder Head Gasket
47	951-10648		Push Rod Kit (incl. intake and exhaust rod)
48	N/A	2	Tappet
49	715-04090		Dowel Pin
49	715-04090	2	Dowel Pin
52	N/A	1	Piston Ring Set
53	N/A	2	Piston Pin Snap Ring
54	N/A	1	Piston
55	N/A	1	Piston Pin
56	951-11283		Oil Fill Plug Assembly
57	951-11113		Air Shield
58	N/A	1	Connecting Rod Assembly
59	951-11356		Governor Arm Shaft
59	951-11356	1	Governor Arm Shaft
60	736-04461		Washer
60	736-04461	1	Washer
60	736-04461	1	Washer
61	N/A	1	Governor Seal
61	N/A	1	Governor Seal
61	N/A	1	Governor Seal
62	714-04078		Cotter Pin
62	714-04078	1	Cotter Pin
62	714-04078	1	Cotter Pin
63	N/A	1	Camshaft Assembly
64	951-11369		Radial Ball Bearing
64	951-11369	2	Radial Ball Bearing
64	951-11369	1	Radial Ball Bearing
64	951-11369	2	Radial Ball Bearing
64	951-11369	1	Radial Ball Bearing
65	951-10307		Flywheel Key
65	951-10307	1	Flywheel Key
65	951-10307	1	Flywheel Key
66	N/A	1	Crankshaft Assembly
66	N/A	1	Crankshaft Assembly
67	N/A	1	Governor Gear/Shaft Assembly
68	715-04092		Dowel Pin, 7 x 14
68	715-04092	1	Dowel Pin, 7 x 14
69	715-04089		Dowel Pin, 9 x 14
69	715-04089	1	Dowel Pin, 9 x 14
70	951-11371		Crankcase Cover Gasket
70	951-11371	1	Crankcase Cover Gasket
70	951-11371	1	Crankcase Cover Gasket
70	951-11371	1	Crankcase Gasket
70	951-11371	1	Crankcase Cover Gasket
71	N/A	1	Case Cover
71	N/A	1	Case Cover
72	710-04932		Bolt
72	710-04932	7	Bolt
72	N/A	7	Cover Bolts
73	N/A	1	O-Ring
73	N/A	1	O-Ring
73	N/A	1	O-Ring

Ref #	Part Number	Qty	Description
73	N/A	1	O-Ring
74	N/A	1	Oil Fill Plug
74	N/A	1	Oil Fill Plug
74	N/A	1	Oil Fill Plug
75	951-11368		Oil Seal
75	951-11368	1	Oil Seal
75	951-11368	1	Oil Seal
75	951-11368	1	Oil Seal
75	951-11368	2	Oil Seal
76	N/A	1	Crankcase
76	N/A	1	Crankcase
77	N/A	1	Oil Drain Pipe
78	736-04440		Washer
78	736-04440	1	Washer
78	736-04440	1	Washer
78	736-04440	1	Washer
79	N/A	1	Oil Drain Plug Washer
80	951-11370		Oil Seal
80	951-11370	2	Oil Seal
80	951-11370	1	Oil Seal
80	951-11370	1	Oil Seal
80	951-11370	1	Oil Seal
81	951-10646		Ignition Coil
82	951-11110		Air Flow Shield
83	951-10650		Fuel Line Kit (incl. clamps and fuel line)
84	951-10641		Oil Drain Assembly, includes 77, 78, 79
85	951-10719		Stator
86	951-10805		Flywheel
87	951-10909		Cooling Fan
88	951-10911		Starter Cup
89	712-04209		Nut
90	951-10647		Valve Kit (incl. intake and exhaust valve)
90	951-10647	1	Valve Kit
92	951-10663A		Blower Housing
93	736-04455		Washer
94	710-04914		Bolt
95	951-10658		Recoil Starter Assembly
96	731-05632		Key
97	951-10758		Throttle Control Assembly
98	710-04928		Bolt
99	951-11108		Governor Shield
100	951-10654		Governor Spring
101	951-10664		Throttle Return Spring
102	951-10665		Governor Rod
104	712-04216		Nut
105	710-04929		Bolt
109	951-10662		Engine/Dipstick Cover
110	710-04905		Bolt
113	951-10656		Dipstick Tube, incl. Ref. 156
115	951-10655		Dipstick
117	951-10649		Fuel Cap Assembly
118	951-10652		Fuel Filter
119	951-10653A		Fuel Tank
121	951-11114		Switch Housing Mounting Bracket
122	712-04212		Nut
123	710-04934		Bolt, M4 x 55
124	710-04935		Bolt, M4 x 60
125	710-04943		Bolt
126	715-04088		Dowel Pin
127	951-10645A		Electric Starter

Ref #	Part Number	Qty	Description
127	951-10645A		Electric Starter
128	710-05003		Bolt
129	951-11109		Blower Housing Shield
130	951-10639		Primer
130	951-10639	1	Primer
131	710-04945		Bolt
131	710-04945	1	Bolt
132	710-04938		Drain Bolt
132	710-04938	1	Drain Bolt
133	N/A	1	Gasket, Throttle Plate
133	N/A	1	Gasket, Throttle Plate
134	N/A	1	Float Pin
134	N/A	1	Float Pin
135	N/A	1	Emulsion Tube
135	N/A	1	Emulsion Tube
136	N/A	1	Needle Valve
136	N/A	1	Needle Valve
137	N/A	1	Main Jet
137	N/A	1	Main Jet
138	N/A	1	Needle Valve Spring
138	N/A	1	Needle Valve Spring
139	N/A	1	Float
139	N/A	1	Float
140	N/A	1	Fuel Bowl Gasket
140	N/A	1	Fuel Bowl Gasket
141	N/A	1	Fuel Drain Plug Gasket
141	N/A	1	Fuel Drain Plug Gasket
142	N/A	1	Fuel Bowl Gasket
142	N/A	1	Fuel Bowl Gasket
143	731-05696		Starter Handle
145	951-10657		Muffler Stud Assembly
146	N/A	1	Choke Shaft
147	N/A	1	Choke Plate
148	N/A	1	Throttle Shaft
149	N/A	1	Throttle Plate
150	N/A	1	Screw, M3×5
151	N/A	1	Lock Washer
152	N/A	1	Idle Jet Assembly
153	N/A	1	Idle Speed Adjusting Screw
154	N/A	1	Fuel Bowl
155	951-11106		Governor Arm Bracket
156	951-11380		O-Ring
	951-10651		Fuel Tank Nipple
	951-10661B		Gasket Kit, External
	951-10668A		Cylinder Head Assembly
	951-11021		Carburetor Kit, Major
	951-11059A		Gasket Kit, Complete
	951-11060A		Short Block Assembly
	951-11063		Valve Cover Kit
	951-11176		Starter Pinion Shaft
	951-11246		Crankcase Cover Kit
	951-11247		Crankshaft Kit
	951-11249		Crankcase Kit
	952Z370-SUB		Engine, Complete