


PARTS LIST

REPLACEMENT PARTS - MODEL PS720r POLE SAW ADD-ON



Item	Part No.	Description
1	753-04621	Gearbox
2	753-04622	Screw
3	753-04623	Shaft Assembly
4	753-04624	Spindle Assembly
5	753-04625	Connection Stick Assembly
6	753-04626	Screw
7	753-04627	Case Cover
8	753-04628	Screw
9	753-04629	Sprocket
10	753-04630	Washer
11	753-04631	C Ring
12	753-04632	Oil Pump Assembly
13	753-04633	Rubber Cork
14	753-04634	Fixed Plate
15	753-04635	Screw

Item	Part No.	Description
16	753-04636	Oiler Assembly
17	753-04637	Anti-Spillage Pad
18	753-04638	Regulation Screw
19	753-04639	Regulation Cap
20	753-04640	Adjustable Plate
21	753-04641	Screw
22	753-04642	Bar 8"
23	753-04643	Saw Chain
24	753-04644	Guard
25	753-04644	Fixed Ring
26	753-04645	Nut
27	753-04646	Screw
28	753-04647	Covering
29	753-04649	Guard
30	753-04648	Inner Pipe Assembly