


Ref #	Part Number	Qty	S/P/F	Description
1	791-610314	1		Throttle Trigger Spring
2	791-180975	1	S	Throttle Trigger
3	753-04927	1	/P	Throttle Housing Assembly (includes 1 & 2)
4	753-04901	1	/P	Throttle Cable
5	753-04280	1	/P	Flexible Drive Shaft
6	753-04921	1		Drive Shaft Housing (includes 13)
7	791-153064	1	/P	D-Handle Assembly (includes 8)
8	791-153317	1	S	D-Handle Hardware
9	753-04282	1		Guard Mounting Hardware
10	753-04283	1		Guard (includes 11)
11	791-180553	1		Blade Assembly
12	753-04284	1		Outer Reel (includes 13)
13	791-610660	1		Retainer
14	791-610317B	1	/P	Spring
15	753-1155	1	/P	Inner Reel
16	791-153066B	1	/P	Bump Knob
	791-153577B	1	/P	Inner Reel & Line (NOT SHOWN)



Ref #	Part Number	Qty	S/P/F	Description
1	753-04511	1	/P	Air Cleaner Cover Assembly (includes 2 & 34)
2	791-180350B	1	/P	Air Cleaner Filter
3	791-180351	1		Carburetor Mounting Screws
4	791-180226	1	S	Wavey Washer
5	753-04418	1	/P	Choke Lever Assembly
6	753-04419	1	/P	Choke Lever & Plate (includes 5)
7	753-04408	1	/P	Carburetor Assembly (includes 8 & 18)
8	791-610675	1		Carburetor Gasket
9	791-181860	1		Carb Mount Screw
10	791-683974B	1	/P	Primer and Hose Assembly
11	753-1196	1	/P	Carburetor Mount Assembly (includes 9, 12 & 13)
12	791-684451	1		Reed Assembly
13	753-1208	1	/P	Carburetor Mount Gasket
14	753-04321	1		Crankcase Service Assembly (includes 9)
15	791-612134	1		Rear Mounting Pad
16	791-182612	1	/P	Fuel Cap Assembly
17	791-181086	1	/P	Fuel Return Line
18	791-682039	1	/P	Fuel Line Assembly
19	791-182767	1		Fuel Tank Assembly (includes 16-18)
20	791-145308	1		Front Mounting Pad
21	791-182736	1	S	Flywheel Assembly
22	791-610303	1		Square Nut Drive
23	753-1202	1		Plate Screw
24	753-04288	1	/P	Palnut
25	753-04928	1		Pressure Plate (includes 23 & 28)
26	753-04823	1		Recoil Pulley Assembly (includes 24)
27	753-04286	1		Recoil Spring
28	753-04824	1		Eyelet Retainer
29	791-611061	1		Rope Guide
30	791-181079	1	S	Pull Handle
31	791-613103	1		Rope
32	791-182673	1		Switch Assembly
33	791-181862	1		Housing Screw
34	791-181345	1	/P	Cover Screw
35	753-04242	1	S	Wire Lead
36	753-05069	1		Starter Housing Assembly (includes 23-35)
37	753-04466	1		Anti-Rotation Screw
38	753-05056	1		Clamp Assembly (includes 37)
39	753-04702	1		Shroud Extension and Stand (includes 34)
40	753-04324	1		Module Assembly
41	791-611063	1	/P	Ground Tab
42	791-610311B	1	/P	Spark Plug
43	753-04619	1	/P	Exhaust Gasket
44	753-04620	1	S	Muffler Mounting Bolt Assembly
45	753-05169	1	/P	Muffler Assembly (includes 43, 44 & Spark Arrestor)
46	753-04367	1	/P	Piston & Rod Assembly
47	791-182723	1		Cylinder Bolt
48	753-04182	1		Cylinder Gasket
49	753-04814	1	/P	Cylinder Assembly (includes 47 & 48)
	753-1209	1		Piston Ring Set (NOT SHOWN)
	753-04689	1		Spark Arrestor (NOT SHOWN)

Ref #	Part Number	Qty	S/P/F	Description
	753-04826	1		Short Block Assembly (includes 14, 42 & 46-49) (NOT SHOWN)