


# ENGINE PARTS - MODEL TB90BC 2-CYCLE GAS TRIMMER/BUSHCUTTER

PPN 41ADT90C063




Item	Part No.	Description	Item	Part No.	Description
1	753-1192	Air Cleaner/Muffler Cover Assembly (includes 2 & 41)	34	753-1203	Starter Housing Assembly (includes 26-31 & 41)
2	791-180350B	Air Cleaner Filter	35	791-181862	Housing Screw
3	791-180351	Carburetor Mounting Screw Assembly	36	791-182368	Clutch Washer
4	753-1193	Choke Extension	37	791-182369	Clutch Rotor Assembly
5	753-1194	Choke Plate	38	791-153592	Clutch Drum Assembly
6	753-1195	Carburetor Assembly W/Limiter Caps (includes 7 & 18)	39	791-612468	Spring
7	791-610675	Carburetor Gasket	40	753-1204	Clutch Cover Assembly (includes 41-44)
8	791-181860	Carb Mount Screw	41	791-181345	Cover Screw
9	791-181801	Primer and Hose Assembly	42	791-182519	Anti-Rotation Screw
10	791-182063	Carb Mount Assembly (includes 8)	43	753-04003	Clamping Screw
11	791-684451	Reed Assembly	44	791-180217	Clamping Nut
12	791-182790	Power Shaft Assembly	45	791-182798	Wire Leads and Sleeve
13	753-1208	Carburetor Mount Gasket	46	791-611063	Ground Tab
14	791-182807	Crank Case Service Assembly (includes 10, 12 & 22)	47	753-1205	Module Assembly
15	791-612134	Rear Mounting Pad	48	791-610311B	Spark Plug
16	753-1198	Fuel Tank Assembly (includes 17-19)	49	791-182066	Muffler Assembly (includes 50-52)
17	791-182612	Fuel Cap Assembly	50	791-182747	Spark Arrestor Screen
18	791-181168	Fuel Return Line	51	791-182065	Exhaust Gasket
19	791-682039	Fuel Line Assembly	52	791-147575	Muffler Mounting Bolt Assembly
20	791-145308	Front Mounting Pad	53	753-1206	Cylinder Assembly (includes 55)
21	791-153520	Shroud Assembly	54	753-1207	Piston and Rod Assembly
22	791-181861	Shroud Screw	55	753-1197	Cylinder Gasket
23	791-182064	Shroud Extension and Stand	56	791-182723	Cylinder Bolt
24	791-181867	Flywheel Assembly	*	791-180090	O.E.M. Carburetor Repair Kit (Zama)
25	791-181065	Spacer	*	791-180091	Gasket Diaphragm Repair Kit (Zama)
26	753-1199	Recoil Pulley Assembly	*	753-1209	Piston Ring Set
27	791-613102	Recoil Spring	*	753-1210	Short Block Assembly (includes 8, 12, 14, 22, 48, 51-56)
28	753-1200	Rope Guide	*	791-610309	Crankcase Seal
29	791-181441	Pulley Retainer	*	791-181599	Clutch Springs (Qty. 2)
30	791-181079	Pull Handle	*		Items Not Shown
31	791-613102	Rope			
32	753-1201	Pressure Plate Assembly			
33	7531202	Plate Screw			

# BOOM AND TRIMMER PARTS - MODEL TB90BC

## 2-CYCLE GAS TRIMMER/BRUSHCUTTER

PPN 41ADT90C063



Item	Part No.	Description
1	182801	Throttle Housing and Trigger Assembly (includes 2-4)
2	182802	Throttle Trigger Lock-Out
3	182803	Throttle Trigger
4	182690	Throttle Trigger Spring
5	182539	Switch Assembly (includes 6)
6	182357	Throttle Cable Assembly
7	610327	Harness Clip
8	182309	Upper Drive Shaft Housing Assembly
9	181099	J-Handle Assembly (includes 10 & 11)
10	612831	Grip
11	612021	Tube Closure
12	683295	Handle Bracket Assembly (includes 13-18)
13	181811	Screw
14	181812	Upper Handle Clamp
15	181813	Middle Handle Clamp
16	181814	Lower Handle Clamp
17	181815	Nut
18	145569	Anti-Rotation Screw
19	181616	Click-Link Coupler (includes 20-23)
20	182057	Screw
21	181617	Bolt
22	181618	Adjustment Knob
23	181886	Knob Retaining Nut
24	180804	Lower Drive Shaft Housing Assembly
25	613300	Lower Flexible Drive Shaft
26	182200	Shield Mount Screw Assembly
27	182193	2 piece Gearbox Assembly (includes 28-30)
28	182195	Gearbox Mounting Hardware
29	145569	Anti-Rotation Screw
30	182196	Blade Driver
31	147492	Blade Shield/Shield Mount
32	683304	Shield Mounting Screw
33	683299	Shield and Blade Assembly (includes 34)
34	682061	Blade Assembly
35	147490	Retaining Washer
36	612483	Spool Shaft
37	683301	Outer Spool and Eyelet Assembly
38	612026	Retainer
39	610636	Spring
40	147495	Inner Reel
41	180814	Bump Head Knob Assembly
42	145873	4-Tooth Blade
43	181699	Nut
*	180014	Blade Retaining Kit (includes 35 & 43)
*	613226	Locking Rod Tool
*	682075	Shoulder Harness

### 2 Piece Gearbox Assembly Parts - Item 27

44	182191	Left Housing
45	182192	Right Housing
46	182194	Pinion Gear Assembly
47	182199	Output Shaft Bushing
48	182198	Output Shaft Gear
49	182197	Output Shaft Assembly (includes 46 & 47)

### Optional Accessories

*	180120	Replacement Line, 0.095 Diameter
*	147345	Reel and Line Assembly
*	147498	Bump Head Assembly (includes 36-41)
*	147543	Ryobi 2-Cycle Oil
*		Items Not Shown