


Parts List

Models 42046 and 42050

HANDLEBAR AND DRIVE ASSEMBLIES

S/N: 420461100101-420461199999
420501100101-420501199999



Ref. #	Part #	Description	Qty.	Ref. #	Part #	Description	Qty.
1	1703539	Handle Grip	2	46	1748617001	Doublers Plate Assembly	1
2	1750796	Bumper	2	47	1749291010	Rear Cover	1
3	1107381	Flat Washer, 1/4	11	48	1757862	Shift Decal	1
4	1111601	Hex hd. Screw, 1/4-20 x 1-3/4	2	49	1739463	Flat Washer	4
5	1734398	Locknut, 1/4-20	7	50	1739470	Bearing	2
6	1745672001	Control Lever	1	51	1773892010	Frame	1
7	1771727	Drive Cable	2	52	1750799	Rubber Pad	1
8	1754177010	Handlebar - right hand	1	53	1749299010	Frame Cover	1
9	1745673001	Control Lever	1	54	1724760	Clevis Pin	2
10	1749977001	Cable Bracket	2	55	1717897	Hair Pin	2
11	1752500	Extension Spring	2	60	1750704	Belt Guide	2
12	1754128	Thread Forming Screw, 1/4-20 x 3/4	2	61	1100044	Hex hd. Screw, 5/16-18 x 3/4	2
13	*	Engine	1	62	1740127	Transmission Sheave	1
14	1104435	Woodruff Key, 1/8 x 5/8	1	63	1733185	Set Screw, 5/16-18 x 5/8	2
15	1740121	PTO Sheave	1	64	1186328	Hex Flange Screw, 5/16-18 x 5/8	4
16	1103441	Set Screw, 1/4-20 x 3/8	2	65	1759447	Belt Guide	1
17	1108852	Square Key, 3/16 x 3/4	1	66	1100351	Cotter Pin, 1/8 x 1-1/4	2
18	1903631	Set Screw, 5/16-18 x 5/16	2	69	1710566	Flat Idler	1
19	1771238	Engine Sheave	1	70	1918456	V-Belt	1
20	1754175	Belt Cover	1	71	1771750	Brake Arm	1
21	1115815	Truss Screw, #10-24 x 5/8	2	72	1185986	Speed Nut, #10	2
22	1729440	Idler Pulley	1	73	1100002	Hex hd. Screw, 1/4-28 x 3/4	1
23	1100243	Lockwasher, 3/8	2	74	1100241	Lockwasher, 1/4	1
24	1186231	Hex Nut, 3/8-16	2	76	1748443	Idler Arm	1
25	182087	Link - Offset	1	77	1758184	Axle	1
26	1751017	Idler Arm Stop	1	79	1100004	Hex hd. Screw, 5/16-24 x 3/4	2
27	1918462	Idler Arm	1	80	1758259	Belt Guide	1
28	1724492	Thread Forming Screw, 1/4-20 x 1/2	5	82	1754159	Cable Clamp	2
29	1100242	Lockwasher, 5/16	3	94	1771728	Nyliner Bearing	2
30	1748659	Spacer	2	95	1185585	Grommet	1
31	1111608	Hex hd. Screw, 5/16-18 x 2-1/2	2	96	1100254	Flat Washer, 1/4	4
32	1715538	Bearing - Nyliner	4	98	1918465	Decal, Logo - Model 42046	1
33	1740102	Torsion Spring	2		1918466	Decal, Logo - Model 42050	1
34	1100257	Flat Washer, 1/2	1	99	1774209	Console (Incl. Ref. 208)	1
35	1100255	Flat Washer, 5/16	6	100	1100811	Hex hd. Screw, 1/4-20 x 1-1/2	4
36	1774473	Drive Chain #41	1	101	1754176010	Handlebar - left hand	1
37	1185013	Connector Link	1	109	1748393	Carriage Bolt, 3/8-16 x 1-3/4	2
38	1200033	Hi-Pro Key, 3/16 x 3/4	1	200	1900706	Red Spray Paint, 13 oz. can	NI
39	1740100	Transmission (See breakdown, pg. 26) ...	1	201	1735222	Black Spray Paint, 13 oz. can	NI
40	1740139010	Reinforcement Bracket	1	202	1757032	Loctite #242, .02 oz.	A/R
41	1766984	Thread Forming Screw, 5/16-18 x 3/4 ...	2	203	1756276	Tire Chains	NI
42	1737041	Handle Grip	1	204	1760190	Wheel and Tire Assembly	2
43	1774124010	Shift Handle	1	207	1774122	Bracket, Shift Decal	1
44	1186327	Hex Hd. Flange Screw, 5/16-18 x 1/2	17	208	1773817	Decal, Instructions	1
45	1186391	Flange Locknut, 5/16-18	6				



* Order parts from your local authorized engine service dealer. Refer to engine nameplate for model/type numbers.

NI Item not included with unit. Order separately.

A/R As required.

S/N: 420461100101-420461199999
420501100101-420501199999

AUGER ASSEMBLY



Ref. #	Part #	Description	Qty.	Ref. #	Part #	Description	Qty.
1	1724791	Push-On Cap	1	56	1200033	Key, 3/16 x 3/4	1
2	1735868	Knob.....	1	57	1733185	Square Set Screw, 5/16-18 x 5/8	2
3	1890945	Flat Washer, 3/8	1	58	1750703	Belt Guide.....	2
4	1749283	Chute Control Crank	1	59	1714243	Nylon Bushing.....	1
5	1185147	Cotter Pin, 3/32 x 5/8	2	60	1185984	Flange Nut	1
7	1177625	Roll Pin, 1/8 x 3/4	2	61	1753356	Sleeve.....	1
8	1773919	Chute Control Shaft	1	62	1752460	Shim.....	3
9	1918480	Crank Support.....	1	63	1917356	V-Belt	1
10	1724870	Worm Gear.....	1	64	1755282	Auger Sheave	1
11	1186329	Hex Flange Screw, 5/16-18 x 3/4	1	65	1757859	Logo Decal	1
12	1724885	Drive Pin, 3/32 x 3/4.....	1	66	1714782	Swivel Block	1
13	1735869	Gear Support.....	1	69	1724491	Hex Flange Screw, 5/16-18 x 3/4	4
14	1100255	Flat Washer, 5/16	1	74	1719271	Shim Washer.....	1
15	1732499	Locknut, 5/16-18	8	75	1737957	Nylon Washer.....	2
16	1100068	Hex hd. Screw, 3/8-16 x 3/4	2	76	1737499	Grip	1
17	1759142	Cap Assembly (Incl. Ref. 18).....	1	77	1723643	Adjusting Lever	1
18	1750692	Warning Decal.....	1	78	1771274	Chute Deflector	1
22	1771723010	Chute	1	79	1737940	Truss Head Bolt, 10-24	3
23	1107383	Flat Washer, 3/8	8	80	1917113	Gear Case Assembly (See exploded view on page 22).....	1
25	1752461	Sems Screw , #10-24 x 7/8	6	81	1757861	Logo Decal	2
26	1772333	Locknut, #10-24	9	202	1757032	Loctite #242, .02 oz.	NI
27	1103959	Flat Washer, #10	6	85	1185224	Oil Seal	1
28	1724869	Hold Down Clip	3	86	1185374	Needle Bearing	1
30	1103195	Hex hd. Screw, 5/16-18 x 5/8	3	87	1185841	Thrust Race	2
31	1185809	Ball Bearing.....	1	88	1185431	Thrust Bearing	1
32	1739488	Bearing Retainer.....	1	89	1741774	Spacer	1
33	1917462	Collector (auger/impeller) Housing Assembly (Incl. Ref. 34).....	1	90	1185842	Washer	1
34	1750691	Warning Decal.....	1	91	1118726	Internal Retaining Ring	1
35	1750969	Plug.....	2	92	1773207	Oil Seal	2
36	1734398	Locknut,1/4-20	6	93	1773170001	Gear Case Cover	1
37	1186126	Carriage Bolt, 3/8-16 x 3/4.....	4	94	1735894001	Gear Case (case only)	1
38	1186391	Flange Locknut, 5/16-18.....	5	95	1741832	Screw, 1/4-20 x 5/8	4
39	1712059	Carriage Bolt, 5/16-18 x 1/2.....	5	96	1100241	Lockwasher, 1/4	4
40	1749282001	Scraper Blade	1	97	1185728	Flange Bearing	2
41	1728567010	Skid Shoe.....	2	98	1185815	Thrust Race	2
42	1733398	Locknut, 3/8-16	8	99	1720933	Worm Gear, 20T	1
43	1720922	Support Bearing	2	100	1720763	Spacer	1
44	1185846	Flange Bushing.....	2	101	1100276	Woodruff Key, 1/4 x 7/8	1
45	1100257	Flat Washer, 1/2	2	102	1185568	Needle Bearing	1
46	1100245	Lockwasher, 1/2	2	103	1105620	Pipe Plug, 1/4-18	1
47	1100053	Hex Hd. Screw, 1/2-13 x 3/4.....	2	104	1740468	Impeller Shaft	1
48	1111599	Hex Hd. Screw, 1/4-20 x 5/8.....	6	105	1917108	Auger Shaft	1
49	1185816	Special Washer.....	8	106	1185840	Thrust Race	1
50	1918434001	Left Auger Blade.....	1	107	1741775	Spacer	1
51	1918435001	Right Auger Blade	1	108	1112634	Welsh Plug	1
52	1750515	Shear Bolt, 5/16-18	2	109	†	Sealant	A/R
53	1740462001	Impeller	1	---	1700182	Gear Lube, EP 90, 8 Oz. Tube	NI
54	1185348	Roll Pin, 1/4 x 1-1/4	1				

NI Item not included with unit. Order separately.

† Use General Electric SILMATE #RTV 1473 or equivalent.


A/R As required.

Parts List

Models 42046 and 42050

TRANSMISSION ASSEMBLY — PEERLESS MODEL 700—005

S/N: 420461100101-420461199999
420501100101-420501199999



Order transmission parts from your local factory-authorized Peerless/Tecumseh dealer.

Ref. #	Part #	Description	Qty.	Ref. #	Part #	Description	Qty.
1	776061	Case, Transmission.....	1	27	780105A	Bushing, Flanged.....	4
2	772083	Cover, Transmission	1	28	786062	Chain, Roller (No. 41 Chain, 22 Links)	1
3	776171	Output Shaft.....	1	29	780072	Thrust Washer.....	5
4	778121 A	Spur Gear (20 Teeth).....	1	30	780086	Needle Bearing.....	2
5	786072	Spacer, Keyed	1	31	792072	Retaining Ring.....	1
6	778124A	Spur Gear (30 Teeth).....	1	32	792035	Retaining Ring.....	1
7	778125	Spur Gear (35 Teeth).....	1	33	780109	Washer.....	1
9	784266	Shift Collar	1	34	788040	Retaining Ring.....	1
10	786060	Sprocket (14 Teeth).....	1	35	784270	Rod & Fork Assembly, Shift	1
11	786061	Sprocket (10 Teeth).....	1	36	792073	Hex Flange Screw, Thread-Forming, 1/4- 20 x 1-1/4	4
12	776134	Countershaft.....	1	37	792089A	Key	2
13	778137A	Bevel Gear (42 Teeth).....	1	40	792077	Ball, Steel, 5/16"	1
14	778136	Spur Gear (15 Teeth).....	1	41	792078	Setscrew, 3/8-16 x 3/8	1
15	778126A	Spur Gear (20 Teeth).....	1	42	792079	Spring	1
16	786071	Spacer.....	1	43	780108	Thrust Washer.....	3
17	778129A	Spur Gear (30 Teeth).....	1	44	792001	"O" Ring.....	1
18	776135	Input Shaft	1	45	792074	Plug.....	1
19	778113A	Bevel Pinion, Input	1				
20	786047	Sprocket (8 Teeth).....	1				