


Ref #	Part Number	Qty	Description
1	753-05631		Muffler Assembly
2	753-05701		Muffler Gasket
3	753-05636		Shortblock Assembly
4	794-00042		Spark Plug
5	753-05702		Insulator Gasket
6	753-05632		Insulator Assembly
7	791-181709		Carburetor Gasket
8	753-05633		Carburetor Assembly
9	791-181757		Air Filter
10	753-05634		Aircleaner Assembly
11	753-04324		Module Assembly
12	710-04715		Screw
13	753-05704		Cylinder Gasket
14	753-05705		Flywheel Adapter
15	936-0326		Washer
16	753-05707		Bushing
17	753-05708		Flywheel Assembly
18	753-05635		Pawl Assembly



Ref #	Part Number	Qty	Description
1	753-06000		Nozzle
2	753-05971		Lower Blower Tube
3	753-05975		Throttle Grip Assembly
4	753-05991		Upper Blower Tube
5	726-04080		Clamp
6	753-05641		Flex Tube
7	753-05990		Elbow
8	753-06036		Harness
9	753-05643		Lead Wire
10	753-06018		Throttle Cable
11	912-0442		Nut
12	750-04929		Spacer
13	753-05648		Insulator Mount
14	753-05649		Intake Cover
15	791-181345		Screw
16	791-180050		Nut
17	791-181862		Screw
18	753-05650		Impeller Housing Assembly
19	791-182414		Bolt
20	753-04482		Impeller Hardware
21	753-05651		Impeller
22	753-05654		Fuel Tank Assembly
23	791-182529		Fuel Cap
25	753-05653		Starter Housing Assembly