


Ref #	Part Number	Qty	Description
1	753-04234		Throttle Housing Assembly (includes 2-4)
2	791-182405		Switch
3	753-04119		Throttle Trigger
4	791-182690		Throttle Trigger Spring
5	753-04405		Throttle Cable
6	753-04344		Upper Drive Shaft Housing Assembly
7	791-180869		Deluxe D-Handle (includes 8 & 9)
8	753-05009		Deluxe D-Handle Base
9	791-181070		Screw
10	753-1190		Split Boom Coupler (includes 11-14)
11	791-182057		Screw
12	791-181617		Bolt
13	791-181981		Adjustment Knob
14	753-04386		Knob Retaining Nut
15	753-04508		Lower Drive Shaft Housing Assembly
16	753-04282		Guard Mounting Hardware
17	753-04283		Guard Assembly (includes 18)
18	791-180553		Blade Assembly
19	753-04284		Outer Spool Assembly (includes 20)
20	791-610660		Retainer
21	791-610317B		Spring
22	753-1155		Inner Reel
23	791-153066B		Bump Head Knob Assembly
	791-153577B		Reel and Line Assembly (Optional Accessory) (not shown)



Ref #	Part Number	Qty	Description
1	753-04511		Air Cleaner Cover Assembly (includes 2 & 39)
2	791-180350B		Air Cleaner Filter
3	791-180351		Carburetor Mounting Screw Assembly
4	791-180226		Wavey Washer
5	791-182202		Choke Knob w/Screw
6	753-04418		Choke Lever (includes 5)
7	753-04419		Choke Plate (includes 6)
8	753-05133		Carburetor Assembly (includes 9 & 20)
9	791-610675		Carburetor Gasket
10	791-181860		Carb Mount Screw
11	791-683974B		Primer & Hose Assembly
12	753-1196		Carb Mount Assembly (includes 10, 13 & 14)
13	791-684451		Reed Assembly
14	753-1208		Carburetor Mount Gasket
15	753-04401		Crankcase Service Assembly (includes 10)
16	791-612134		Rear Mounting Pad
17	753-04307		Fuel Tank Assembly (includes 18-20)
18	791-182529		Fuel Cap Assembly
19	791-181086		Fuel Return Line
20	753-04233		Fuel Line Assembly
21	791-145308		Front Mounting Pad
22	753-04409		Shroud Extension & Stand (includes 39)
23	753-05240		Flywheel Assembly
23	914-04016		Woodruff Key .125 x .375
24	791-181525		Spacer
25	753-04459		Recoil Pulley Assembly (includes 28 & 30)
26	753-04286		Recoil Spring
27	753-1200		Rope Guide
28	753-04288		Pulley Retainer
29	791-181079		Pull Handle
30	791-613103		Rope
31	753-04417		Pressure Plate Assembly (includes 32)
32	753-1202		Plate Screw
33	753-04402		Starter Housing Assembly
34	791-181862		Housing Screw
35	791-182396		Clutch Washer
36	791-182369		Clutch Rotor Assembly
36	753-05722		Clutch Rotor Assembly
37	791-153592		Clutch Drum Assembly
37	753-05723		Clutch Drum Assembly
38	753-04403		Clutch Cover Assembly (includes 39-42)
39	791-181345		Cover Screw
40	791-182519		Anti-Rotation Screw
41	753-04003		Clamping Screw
42	791-180217		Clamping Nut
43	753-05025		Wire Leads and Sleeve
44	791-611063		Ground Tab
45	753-04336		Module Assembly
46	791-610311B		Spark Plug
47	753-05169		Muffler Assembly
48	753-04619		Exhaust Gasket
49	753-04620		Muffler Mounting Bolts
50	753-04323		Cylinder Assembly (includes 52 & 53)
51	753-04367		Piston and Rod Assembly
52	753-04182		Cylinder Gasket
53	791-182723		Cylinder Bolt
	753-1209		Piston Ring Set
	753-04812		Short Block Assembly