


Ref #	Part Number	Qty	Description
1	753-04234		Throttle Housing Assembly (includes 2-4)
2	753-04119		Throttle Trigger
3	791-182690		Throttle Trigger Spring
4	791-182405		Switch
5	753-04405		Throttle Cable Assembly
6	753-04344		Upper Drive Shaft Housing Assembly
7	791-180869		Deluxe D-Handle Assembly (includes 8-10)
8	791-181070		Screw
9	791-182167		Deluxe D-Handle
10	791-182168		Bottom Clamp
11	753-1190		Split Boom Coupler (includes 12-15)
12	791-182057		Screw
13	791-181617		Bolt
14	791-181981		Adjustment Knob
15	753-04386		Knob Retaining Nut
16	753-1212		Lower Drive Shaft Housing Assembly
17	753-05182		Lower Flexible Drive Shaft
18	791-145569		Anti-Rotation Screw
19	753-05183		Gear Box Assembly (includes 23-27)
20	791-180547		Shield Mounting Hardware
21	791-180548		Shield Assembly (includes 22)
22	791-682061		Blade Assembly
23	791-153619		Outer Spool Assembly (includes 24)
24	791-610660		Retaining
25	791-610317B		Spring
26	753-1155		Inner Reel
27	791-153066B		Bump Head Knob Assembly
	791-180120		Replacement Line, 0.095 Diameter
	753-1156		Reel and Line Assembly



Ref #	Part Number	Qty	Description
1	753-04511		Air Cleaner Cover Assembly (includes 2 & 38)
2	791-180350B		Air Cleaner Filter
3	791-180351		Carburetor Mounting Screw Assembly
4	791-180226		Wavey Washer
5	791-182202		Choke Knob w/Screw
6	753-04418		Choke Lever (includes 5)
7	753-04419		Choke Plate (includes 6)
8	753-05133		Carburetor Assembly (includes 9 & 19)
9	791-610675		Carburetor Gasket
10	791-181860		Carb Mount Screw
11	791-683974B		Primer & Hose Assembly
12	753-1196		Carb Mount Assembly (includes 10, 13 & 14)
13	791-684451		Reed Assembly
14	753-1208		Carburetor Mount Gasket
15	791-612134		Rear Mounting Pad
16	753-04307		Fuel Tank Assembly (includes 17-19)
17	791-182529		Fuel Cap Assembly
18	791-181086		Fuel Return Line
19	753-04233		Fuel Line Assembly
20	791-145308		Front Mounting Pad
21	753-05091		Shroud Extension & Stand (includes 38)
22	753-05240		Flywheel Assembly
22	914-04016		Woodruff Key .125 x .375
23	791-181525		Spacer
24	753-04459		Recoil Pulley Assembly (includes 27 & 29)
25	753-04286		Recoil Spring
26	753-1200		Rope Guide
27	753-04288		Pulley Retainer
28	791-181079		Pull Handle
29	791-613103		Rope
30	753-04417		Pressure Plate Assembly (includes 31)
31	753-1202		Plate Screw
32	753-04402		Starter Housing Assembly
33	791-181862		Housing Screw
34	791-182396		Clutch Washer
35	791-182369		Clutch Rotor Assembly
35	753-05722		Clutch Rotor Assembly
36	791-153592		Clutch Drum Assembly
36	753-05723		Clutch Drum Assembly
37	753-04403		Clutch Cover Assembly (includes 38-41)
38	791-181345		Cover Screw
39	791-182519		Anti-Rotation Screw
40	753-04003		Clamping Screw
41	791-180217		Clamping Nut
42	753-05025		Wire Leads and Sleeve
43	791-611063		Ground Tab
44	753-04336		Module Assembly
45	791-610311B		Spark Plug
46	753-05169		Muffler Assembly
47	753-04619		Exhaust Gasket
48	753-04620		Muffler Mounting Bolts
49	753-04814		Cylinder Assembly (includes 51 & 52)
50	753-04367		Piston and Rod Assembly
51	753-04182		Cylinder Gasket
52	791-182723		Cylinder Bolt
	753-1209		Piston Ring Set
	753-04812		Short Block Assembly