


MODEL 60ESL
4 H.P. 20" Cut Side-Discharge Electric-Start Rotary Mower
Uses Grass Catcher Model GC12A
Grass Catcher P/N 161109
Repl. Bag P/N 161117



S/N 232025
P/L 082531
O/M 798066
E/M 189142
P/B 397039

MODEL 60ESL
4 H.P. 20" Cut Side-Discharge Electric-Start Rotary Mower
Uses Grass Catcher Model GC12A
Grass Catcher P/N 161109
Repl. Bag P/N 161117

INDEX PART

NO.	NO.	DESCRIPTION
1	391771	Chute Deflector Assembly
2	022699	Deck - 20"
3	031369	Blade - 20"
4	043158	Wheel - 8" x 1-1/2" Pl. Dia.
5	053040	Control - Throttle w/Cable
6	053041	Cable - Engine/Blade Control
7	073403	Handle - Lower
8	073560	Handle - Upper
9	092775	Back Plate - Height Adjuster
10	091819	Arm Wheel
11	001438	Decal - 20"
12	092718	Handle Bracket - R.H. and L.H.
13	164756	Shoulder Bolt - Handle Bracket
14	073551	Bail - Engine/Blade Control
15	164681	Washer - Blade Conical
16	088930	Baffle - Front and Rear
17	106914	Clip - Trailing Shield
18	715607	Washer - Belleville
19	110064	Bolt Cap
20	110379	Cable Tie
21	114462	Plastic Tip - Height Adjuster
22	114421	Trailing Shield - Plastic
23	150623	Screw #10-24 x 5/8 HWH
24	092221	Blade Adapter
25	144063	Decal - Danger
26	001206	Decal - Blade Warning
27	715557	Decal - Starting Instructions
28	164020	Washer - Hardened
29	157255	Bolt - Blade 3/8-24 x 1-1/4 Gr. 8
30	150730	Shoulder Bolt - Wheel
31	150201	Washer - Curved 5/16"
32	092817	Lever - Setting Hgt. Adjust.
33	157552	Cable Clamp
34	457499	Bolt 1/4-20 x 1/2 TD FM
35	616094	Bolt - 1/4-20 x 2-1/2 HHCS
36	113589	Wing Nut
37	151936	Bolt - Curved HD Crg 5/16-18 x 5/8

INDEX PART

NO.	NO.	DESCRIPTION
38	152074	Rope Stop
39	152371	Eyebolt - Rope Guide
40	158907	Bolt - Carriage 5/16-18 x 5/8
41	157610	Nut - 5/16-18 Flange Lock
42	152421	Washer - Spring - Height Adjuster
43	164897	Shoulder Bolt - Height Adjuster
44	452318	Nut - #10-24 Hex Nylon Insert
45	457168	Bolt - 3/8-16 x 7/8 TDFM
46	458687	Bolt - Hex Head #10-24 x 1/2
47	310151	Nut - 5/16-18 Nylock
48	796652	Decal Lawn Chief
49	715037	Locknut - 1/4-20 Keps
50	310045	Nut 5/16 - 18 Hex
51	156406	3/8-16 Nut - Flange Lock
52	156877	Washer - 3/8 Hardened
53	092734	Plate - Height Adj. Hdle. L.H.
54	092759	Plate - Height Adj. Hdle. R.H.
55	018846	Panel - Handle
56	050252	Switch - Ignition
57	134601	Battery - 12 Volt
58	138743	Wiring Harness
59	144089	Decal - Ignition
60	147322	Decal - Aux. Rope Start
61	310102	Nut - Hex 5/8-32
62	311241	Washer - Lock 5/8 Int. Tooth
63	716761	Decal - Electric Start Instr.
64	716779	Decal - Danger Elect. Start
65	819714	Clip Wiring Press-on
66	101246	Plate - Reinforcing
67	132571	Battery Charger
68	151886	Screw - Machine Rd #8-32 x 3-1/4"
69	151894	Locknut - Hex #8-32
70	156836	Bolt #10-24 x 1-1/8
71	304352	Keys - Ignition
72	715136	Washer #10 Flat
73	715334	Nut #10-24 Keps

S/N 232025
P/L 082531
O/M 798066
E/M 189142
P/B 397039