


SECTION 4: PARTS LIST



Ref. No.	Part No.	Description	Ref. No.	Part No.	Description
1.	17200A	Support Bracket	17.	731-04159	Discharge Chute Elbow
2.	17247	Adapter Bracket: Support Tube	18.	731-0926B	Catcher Tube
3.	664-04018	Grasscatcher Cover Assembly	19.	736-0253	Beleville Washer
4.	689-00002	Support Assembly: Grasscatcher	20.	736-0270	Beleville Washer
5.	710-0623	TT Screw 3/8-16 x 0.75	21.	736-0407	Bell Washer
6.	710-0751	Hex Screw 1/4-20 x 0.620	22.	736-3092	Flat Washer
7.	710-3008	Hex Screw 5/16-18 x 0.75	23.	738-0380	Shoulder Screw
8.	710-3015	Hex Screw 1/4-20 x 0.75	24.	738-1020	Shoulder Screw
9.	711-0309A	Clevis Pin	25.	742-0644	Blade 16.28"
10.	711-04069	Grasscatcher Pin	26.	742-0645	Blade 14.88"
11.	712-0431	Flange Lock Nut 3/8-16	27.	783-04138	Catcher Support Bracket
12.	712-0459	Lock Nut 7/16-20	28.	783-0601	Catcher Support Bracket
13.	712-3004A	Lock Nut 5/16-18	29.	783-0673	Catcher Support Bracket RH
14.	712-3027	Lock Nut 1/4-20	30.	783-0764	Catcher Support Bracket LH
15.	714-0117	Hairpin Clip	31.	783-0765	Cross Bracket: Support
16.	723-04008	Chute Strap	32.	864-0251	Bag Assembly: Triple Bagger