


SECTION 10: PARTS LIST FOR MODELS 466 & 469



IMPORTANT: For a proper working machine, use Factory Approved Parts. **V-BELTS** are specially designed to engage and disengage safely. A substitute (non OEM) V-Belt can be dangerous by not disengaging completely.

Models 466 & 469

Ref. No	Part No.	Description	Ref. No	Part No.	Description
1.	747-1214	Lower Bail Handle	44.	716-0865	Snap Ring
2.	710-0599	TT Screw 1/4-20 x 0.5	45.	717-1762	Gear 14T RH FWD
3.	736-0270	Bell Washer.265 x 0.75		717-1761	Gear 14T LH FWD *
4.	17032A	Deflector Chute Adapter	46.	747-04080	Grass Bag Frame
5.	732-1014	Torsion Spring	47.	736-0451	Saddle Washer
6.	731-04204	Deluxe Bail Cover	48.	710-1652	TT Scr. w/Washer 1/4-20 x.625
7.	747-1161A	Blade Control Handle	49.	687-02068	RH Handle Bracket Assembly
8.	749-1092A	Upper Handle		687-02069	LH Handle Bracket Assembly
9.	731-04177	Chute Deflector	50.	715-0221	Dowel Pin
10.	687-02055	Mulch Plug Complete	51.	736-0474	Washer
11.	747-0710	Hinge Pin	52.	687-02071	Pivot Arm Assembly - RH
12.	732-0708	Bearing Retainer		687-02070	Pivot Arm Assembly - LH*
13.	720-0279	Handle Knob	53.	732-04175	Rear Spring Lever
14.	720-0284	Wing Knob	54.	720-0426	Spring Lever Knob
15.	710-1205	Eye Bolt	55.	738-04136	Shoulder Scr.500 Dia. x.434
16.	746-1132	Control Cable - 40.75"	56.	782-0512B	Height Adjuster Plate - RH
17.	710-1174	Carriage Bolt 5/16-18 x 2.0		782-0511A	Height Adjuster Plate - LH*
18.	726-0240	Cable Tie	57.	732-0706	Front Lever - RH
19.	714-0104	Cotter Pin		732-0707	Front Lever - LH*
20.	710-1008	Sems Hex Screw	58.	732-0700	Wire
21.	746-04112A	Drive Cable	59.	731-04998	Rear Trailing Shield
22.	664-04011	Grassbag Assembly	60.	747-04035	Pivot Rod
23.	710-1650	Shoulder Screw # 12 -24	61.	716-0102	Snap Ring
24.	682-0015	Bearing Assembly	62.	731-04134A	Rear Discharge Door
25.	787-01222	21" Deck	63.	782-7551A	Wheel Dust Cap
26.	710-0216	Hex Screw 3/8-16 x.75	64.	750-04162	Spacer.375 x.50 x 1.02" Lg.
27.	732-04090A	Torsion Spring RH	65.	710-0703	Carriage Bolt 1/4-20
28.	712-0431	Flange Lock Nut 3/8-16	66.	712-0397	Wing Nut
29.	731-05020	Transmission Cover (Black)	67.	618-0657	Transmission Assembly
30.	782-5002B	Front Baffle	68.	732-1043	Belt Tension Spring
31.	754-0637A	V-Belt	69.	756-04017	Pulley Assembly
32.	736-0447	Wave Washer	70.	682-0511A	Height Adjustment Assembly LH
33.	750-04178	Sleeve Spacer 9.04" Lg.		682-0512A	Height Adjustment Assembly RH
34.	748-04015A	Blade Adapter w/ Pulley	71.	710-0286	Machined Screw
35.	742-0741	21" Mulching Blade	72.	710-04371	HL Screw
36.	736-0524B	Blade Bell Support	73.	712-04064	Flange Nut
37.	687-02044	Pivot Plate Assembly	74.	731-04150	Rear Baffle
38.	710-1257	Hex Screw 3/8-24 x 2.50	75.	736-0504	Wave Washer
39.	749-0928A	Lower Handle	76.*	710-1256	HL Scr #8-18:1.250:P
40.	750-1166	Slev. Spacer 2.1" Lg.	77.*	751B699869	Engine Shrd B&S Quantum
41.	732-04089A	Torsion Spring LH			
42.	734-04018A	Wheel 8 x 2.125 Gear GW			
43.	734-04014	Wheel 8 x 2.125 Gray IDL			

* Not shown in illustration