




SECTION 4: PARTS LIST FOR MODELS OEM-190-192 & 190-192-190



Components of Bag Assembly pn # 864-0251:



Components of Cover Assembly pn # 664-04018:



Models OEM-190-192 & 190-192-190

Ref. No.	Part No.	Description	Ref. No.	Part No.	Description
1.	17200A	Catcher Support Bracket	29.	783-0601	Catcher Support Bracket
2.	17247	Tubing Adapter	30.	783-0673	Catcher Support Bracket RH
3.	631-0221	Chute Elbow	31.	783-0764	Catcher Support Bracket LH
4.	664-04018	Cover Assembly (includes ref. 35 to 46)	32.	783-0765	Bracket: Cross Support
5.	683-0617	Bracket Assembly: Chute Stop	33.	783-1501	Spacer
6.	689-00002	Grasscatcher Support Assembly	34.	864-0251	Grasscatcher Bag Assembly
7.	710-0597	Hex Bolt 1/4-20 x 1.0	35.	17202A	Screen Mounting Bracket
8.	710-0751	Hex Bolt 1/4-20 x 0.620	36.	710-1652	TT Screw 1/4-20 x 0.625
9.	710-3008	Hex Bolt 5/16-18 x 0.75	37.	720-04018	Screen
10.	710-3168	Carriage Bolt	38.	726-04027	Push Nut
11.	711-0309A	Clevis Pin	39.	726-0479	Ratchet Clip
12.	711-04069	Grasscatcher Pin	40.	728-0123	Pop Rivet
13.	712-0130	Hex Lock Nut 3/8-16	41.	731-04166	Grass Bag Cover
14.	712-0431	Flange Lock Nut 3/8-16	42.	731-04189	Retainer Seal
15.	712-3004A	Flange Lock Nut 5/16-18	43.	731-0824A	Plastic Plate
16.	712-3027	Flange Lock Nut 1/4-20	44.	735-04020	Grass Bag Seal
17.	714-0117	Hairpin Clip	45.	736-0400	Flat Washer
18.	723-04008A	Chute Strap	46.	749-0747	Hinge Bracket
20.	723-0476	Chute Strap	47.	17201A	Bag Hanger Bracket
21.	731-0926B	Catcher Tube	48.	710-0473	Machine Screw
23.	736-0253	Beleville Washer	49.	710-0604A	TT Screw 5/16-18 x 0.625
24.	736-0270	Bell Washer	50.	712-0272	Hex Sems Nut
25.	736-3092	Flat Washer	51.	749-0745A	Tube: Grass Bag Frame
26.	738-0380	Shoulder Screw	52.	764-0251	Grassbag
27.	742-04056	Blade			