



# PARTS LIST

## ENGINE PARTS - MT780 2-CYCLE GAS TRIMMER / BRUSHCUTTER



Item	Part No.	Description	Item	Part No.	Description
1	753-04810	Air Cleaner Cover Assembly (includes 2 & 38)	33	791-182396	Clutch Washer
2	791-180350B	Air Cleaner Filter	34	791-182369	Clutch Rotor Assembly
3	791-180351	Carburetor Mounting Screw Assembly	35	791-153592	Clutch Drum Assembly
5	753-04419	Choke Plate	36	753-04889	Clutch Cover Assembly (includes 37 & 38)
5	753-04227	Choke Lever	37	791-182519	Anti-Rotation Screw
6	791-181086	Fuel Return Line	38	791-181345	Cover Screw
7	753-04331	Carburetor Assembly (includes 8 & 17)	39	753-04702	Shroud Extension & Stand (includes 38)
8	791-610675	Carburetor Gasket	40	791-182798	Wire Leads and Sleeve
9	791-181860	Carb Mount Screw	41	791-611063	Ground Tab
10	753-1196	Carb Mount Assembly (includes 9, 11 & 13)	42	753-04337	Module Assembly
11	791-684451	Reed Assembly	43	791-610311B	Spark Plug
12	791-683974B	Primer and Hose Assembly	44	753-04618	Muffler Assembly (includes 45-50)
13	753-1208	Carburetor Mount Gasket	45	753-04689	Spark Arrestor Screen
14	791-612134	Rear Mounting Pad	46	753-04690	Spark Arrestor Plate
15	753-04311	Fuel Tank Assembly (includes 6, 16 & 17)	47	753-04691	Spark Arrestor Hood
16	791-182612	Fuel Cap Assembly	48	753-04315	Spark Arrestor Screw
17	753-04233	Fuel Line Assembly	49	753-04619	Exhaust Gasket
18	791-145308	Front Mounting Pad	50	753-04620	Muffler Mounting Bolt Assembly
19	753-04470	Crank Case Service Assembly (includes 9)	51	753-04814	Cylinder Assembly (includes 53 & 54)
20	791-182736	Flywheel Assembly	52	753-04182	Cylinder Gasket
21	791-181065	Spacer	53	753-04367	Piston and Rod Assembly
22	753-1202	Pressure Plate Screw	54	753-04361	Cylinder Bolt
23	753-04705	Pressure Plate	*	753-1209	Piston Ring Set
24	753-04288	Pulley Retainer	*	753-04822	Short Block Assembly (includes 9, 19, 43, 51-54)
25	753-04823	Recoil Pulley Assembly	*	791-181599	Clutch Springs (Qty. 2)
26	753-04286	Recoil Spring			
27	753-04824	Rope Guide Retainer			
28	791-611061	Rope Guide			
29	791-613103	Rope			
30	791-181079	Pull Handle			
31	791-181862	Housing Screw			
32	753-04905	Starter Housing Assembly (includes 22-31 & 38)			
			*	Items Not Shown	

# PARTS LIST



Item	Part No.	Description
1	791-182801	Throttle Housing Assembly (includes 2-4)
2	791-182802	Throttle Trigger Lock-Out
3	791-101502	Throttle Trigger
4	791-182690	Throttle Trigger Spring
5	791-182405	Switch Assembly (includes 6)
6	753-04278	Throttle Cable Assembly
7	791-610327	Harness Clip
8	791-147486	Upper Drive Shaft Housing Assembly
9	791-181099	J-Handle Assembly
10	791-683295	Handle Bracket Assembly (includes 13-15 & 20)
11	791-181811	Screw
12	791-181812	Upper Handle Clamp
13	791-181813	Middle Handle Clamp
14	791-181814	Lower Handle Clamp
15	791-181815	Nut
16	791-181817	Flexible Drive Shaft
17	791-182200	Shield Mount Screw Assembly
18	791-182193	2 piece Gearbox Assembly (includes 19-29)
19	791-182195	Gearbox Mounting Hardware
20	791-145569	Anti-Rotation Screw
21	791-182191	Left Housing
22	791-182192	Right Housing
23	791-182195	Gear Box Screw
24	791-182194	Pinion Gear Assembly
25	791-182199	Output Shaft Bushing
26	791-182198	Output Shaft Gear
27	791-182197	Output Shaft Assembly (includes 25 & 26)
28	791-182196	Blade Driver
29	753-04348	Palmnut
30	791-147492	Blade Shield/Shield Mount
31	791-683304	Shield Mounting Screw
32	791-683299	Shield Assembly (includes 33)
33	791-682061	Blade Assembly
34	791-147490	Retaining Washer
35	791-612483	Spool Shaft
36	791-683301	Outer Spool Assembly
37	791-612026	Retainer
38	791-610636	Spring
39	791-147495	Inner Reel
40	791-180814	Bump Head Knob Assembly
41	791-145873	4-Tooth Blade
42	791-181699	Nut
*	791-180014	Blade Retaining Kit (includes 34 & 42)
*	791-613226	Locking Rod Tool
*	791-682075	Shoulder Harness

## Optional Accessories

- \* 791-180120 Replacement Line, 0.095 Diameter
- \* 791-147345 Reel and Line Assembly
- \* 791-147498 Bump Head Assembly (includes 35-40)

\* Items Not Shown