


PARTS LIST

ENGINE PARTS - TB20CS 2-CYCLE GAS TRIMMER - ENGINE




Item	Part No.	Description	Item	Part No.	Description
1	753-04810	Air Cleaner Cover Assembly (includes 2 & 37)	31	753-04402	Starter Housing Assembly (includes 23-30, 32 & 37)
2	791-180350B	Air Cleaner Filter	32	791-181862	Housing Screw
3	791-180351	Carburetor Mounting Screw Assembly	33	791-182368	Clutch Washer
4	753-04227	Choke Extension	34	791-182369	Clutch Rotor Assembly
5	753-1194	Choke Plate	35	791-153592	Clutch Drum Assembly
6	753-04318	Carburetor Assembly (includes 7 & 18)	36	753-1204	Clutch Cover Assembly (includes 37-40)
7	791-610675	Carburetor Gasket	37	791-181345	Cover Screw
8	791-181860	Carb Mount Screw	38	791-182519	Anti-Rotation Screw
9	791-683947B	Primer & Hose Assembly	39	753-04003	Clamping Screw
10	753-1196	Carb Mount Assembly (includes 8, 11 & 12)	40	791-180217	Clamping Nut
11	791-684451	Reed Assembly	41	791-182798	Wire Leads and Sleeve
12	753-1208	Carburetor Mount Gasket	42	791-611063	Ground Tab
13	753-04401	Crankcase Service Assembly (includes 8)	43	753-04336	Module Assembly (includes 42)
14	791-612134	Rear Mounting Pad	44	791-610311B	Spark Plug
15	753-04307	Fuel Tank Assembly (includes 16-18)	45	753-04618	Muffler Assembly (includes 46-51)
16	753-04084	Fuel Cap Assembly	46	753-04619	Exhaust Gasket
17	791-181068	Fuel Return Line	47	753-04689	Spark Arrestor Screen
18	753-04233	Fuel Line Assembly	48	753-04690	Exhaust Hood Diverter
19	791-145308	Front Mounting Pad	49	753-04691	Exhaust Hood
20	753-04702	Shroud Extension & Stand	50	753-04315	Screws
21	791-182736	Flywheel Assembly	51	753-04620	Muffler Mounting Bolts
22	791-181525	Spacer	52	753-04323	Cylinder Assembly (includes 54 & 55)
23	753-04459	Recoil Pulley Assembly (includes 24, 26 & 28)	53	753-04367	Piston and Rod Assembly
24	753-04286	Recoil Spring	54	753-04182	Cylinder Gasket
25	753-1200	Rope Guide	55	791-182723	Cylinder Bolt
26	791-181247	Pulley Retainer	*	753-1209	Piston Ring Set
27	791-181079	Pull Handle	*	753-04812	Short Block Assembly (includes 8, 13, & 52-55)
28	791-613103	Rope	*	791-181599	Clutch Springs (Qty. 2)
29	753-04417	Pressure Plate Assembly			
30	753-1202	Plate Screw			

* Items Not Shown

PARTS LIST

BOOM AND TRIMMER PARTS - TB20CS 2 CYCLE TRIMMER



Item	Part No.	Description
1	753-04829	Throttle Housing Assembly (includes 2-4)
2	791-182405	Switch
3	753-04119	Throttle Trigger
4	791-182690	Throttle Trigger Spring
5	753-04405	Throttle Cable
6	753-04236	Upper Drive Shaft Housing Assembly
7	791-182405	Harness Clip
8	791-153064	D-Handle (includes 9)
9	791-153317	Handle Hardware
10	753-1190	Split Boom Coupler (includes 11-14)
11	791-182057	Screw
12	791-181617	Bolt
13	791-181981	Adjustment Knob
14	753-04386	Knob Retaining Nut
15	753-04508	Lower Drive Shaft Housing Assembly
16	753-04282	Guard Mounting Hardware
17	753-04283	Guard (includes 16)
18	791-180553	Blade Assembly
19	753-04284	Outer Spool Assembly (includes 20)
20	791-610660	Retainer
21	791-610317B	Spring
22	753-1155	Inner Reel
23	791-153066B	Bump Head Knob Assembly

Optional Accessories

- * 791-153577B Reel and Line Assembly
- * 791-682075B Shoulder Strap Assembly

* Items Not Shown