



# 8

## Parts List



1	17032A	Chute Hinge
2	17098	Hinge Clip
3	687-02145	Handle Bracket Assembly - RH
4	687-02144	Handle Bracket Assembly - LH
5	787-01084A	Deck Assembly, 22"
6	712-3017	Hex Nut, 3/8-16
7	731-0981A†	Hubcap - Radial Spoke (Not Shown)
	720-0249†	Hubcap - Gray (Not Shown)
8	710-0216	Hex Cap Screw 3/8-16 x .75
9	710-0599	TT Screw 1/4-20 x 0.5"
10	710-0654A	TT Screw 3/8-16 x 1.0
11	710-1044	Hex Cap Screw 3/8-24 x 1.5
12	710-1174	Carriage Bolt 5/16-18 x 2.0
13	710-1205	Eye Bolt
14	712-0431	Lock Nut 3/8-16
15	720-0279	Wing Nut
16	720-0284	Wing Nut
17	749-1092A	Upper Handle
18	725-0157	Cable Tie
19	731-04019	Trail Shield
20	731-04197†	Mulching Baffle
21	731-1034B	Hinged Chute Deflector Assembly
22	749-04037	Lower Handle
23	732-1014	Torsion Spring
24	734-04063	Wheel, 7 x 1.5, Star-Diam Gray
	734-1987	Wheel, 8 x 1.8, Spoke Bar Gray
	734-1781	Wheel, 8 x 1.75, Slot Bar Gray
25	748-0376C	Blade Adapter
26	736-0270	Bell Washer .265 ID x .75 OD
27	736-0451	Saddle Washer .320 ID x .93 OD
28	736-0524B	Blade Bell Support
29	736-0105	Bell Washer, .375 x .870 x .063
30	736-0331	Bell Washer, .390 x 1.13 x .062
31	738-0533	Shoulder Screw, .498 x 1.635
32	747-1161A	Blade Control
33	742-0642A	Standard Blade, 22"
	742-0742A†	Mulching Blade, 22"
34	746-0957	Blade Control Cable - 37.25"
	746-0554	Blade Control Cable - 40.5"
	746-0555	Blade Control Cable - 55"
35	747-0710	Hinge Pin

† If equipped