


SECTION 10: PARTS LIST MODEL 556



Model Series 556

Ref. No	Part No.	Description	Ref. No	Part No.	Description
1.	747-1214	Drive Control	43.	710-1257	Hex Screw 3/8-24 x 2.50
2.	710-0599	TT Screw 1/4-20 x 0.5	44.	749-0928A	Lower Handle
3.	782-5004B	Rear RH Baffle 21" Rd.	45.	732-1043	Belt Tension Spring
4.	782-5003A	Rear LH Baffle 21" Rd.	46.	720-0426	Adjustment Knob
5.	710-1017	Hex Washer Head Tap Screw	47.	732-04089A	Torsion Spring - LH
6.	731-2626	Deluxe Bail Cover	48.	734-2042	Front Wheel, 8 x 2.125 Gear Zag Blk
7.	747-1161A	Blade Control	49.	716-0865	Snap Ring
8.	749-1092A	Upper Handle	50.	717-1762	Gear 14T RH FWD
9.	631-0075B	Engine Assembly Spacer		717-1761	Gear 14T LH FWD
10.	736-0250	Flat Washer 1.00 x 1.75 x .107	51.	747-04080	Grass Bag Frame
11.	736-04173	Spring Washer 1.005 x 1.825 .048	52.	736-0451	Saddle Washer
12.	750-04438	Sleeve Spacer 25mm x1.375 x.440	53.	712-3005	Hex Flange Lock Nut 3/8-16
13.	720-0279	Handle Knob	54.	710-1652	TT Scr. w/Washer 1/4-20 x.625
14.	720-0284	Handle Knob	55.	687-02057	Handle Bracket Assembly - LH
15.	710-1205	Eye Bolt		687-02056	Handle Bracket Assembly - RH
16.	746-1113	Control Cable - 37.75"	56.	715-0221	Dowel Pin
17.	710-1174	Carriage Bolt 5/16-18 x 2.0	57.	736-0474	Washer
18.	687-02033	Handle Bracket - RH	58.	687-02039	Pivot Arm Assembly - RH
	687-02031	Handle Bracket - LH		687-02040	Pivot Arm Assembly - LH
19.	726-0240	Cable Tie	59.	732-0866	Rear Spring Lever
20.	714-0104	Cotter Pin	60.	720-0312	Foam Grip
21.	710-1008	Self-Tapping Sems Screw	61.	738-0507B	Shoulder Scr.500 Dia. x.434
22.	746-04112A	Drive Cable - 50.50"	62.	734-04093	Rear Wheel, 12 x 2.125
23.	664-04027	Grassbag Assembly	63.	782-0512B	Height Adjuster Plate - RH
24.	710-1650	Shoulder Screw # 12 -24		782-0511A	Height Adjuster Plate - LH
25.	682-0015	Front Bearing Assembly	64.	732-0706	Front Lever - RH
26.	756-04160	Half Key Pulley 25mm x 2.62 O.D.		732-0707	Front Lever - LH
27.	756-04161	Half Upper Pulley 25mm x 2.62 O.D.	65.	732-0700	Wire
28.	787-01248	21" Deck SS SP	66.	731-04998	Rear Trailing Shield
29.	731-0981A	Hub Cap	67.	747-0996	Pivot Rod
30.	750-1166	Slev. Spacer 2.1" Lg.	68.	716-0102	Snap Ring
31.	710-0216	Hex Screw 3/8-16 x.75	69.	731-04134A	Rear Discharge Door
32.	732-04090A	Torsion Spring - RH	70.	782-7551A	Wheel Dust Cap
33.	712-04065	Flange Lock Nut 3/8-16	71.	756-04017	Input Pulley
34.	731-05013A	Transmission Cover (Black)	72.	750-04162	Spacer.375 x.50 x 1.02" Lg.
35.	782-5002B	Front Baffle	73.	715-04011	Roll Pin
36.	754-0637A	V-Belt	74.	710-0703	Carriage Bolt 1/4-20
37.	736-0447	Wave Washer	75.	712-0397	Wing Nut
38.	750-04178	Sleeve Spacer 9.04" Lg.	76.	618-0657	Transmission Assembly
39.	748-04082	Blade Adapter w/ Pulley	77.	682-0512A	Height Adjustment Assembly - RH
40.	742-0741	21" Mulching Blade		682-0511A	Height Adjustment Assembly - LH
41.	736-0524B	Blade Bell Support	78.	736-0182	Spacer Washer .500 x 1.00 x .022
42.	687-02044	Pivot Plate Assembly			

Model Series 556

