


Clip for cable #50 is 731-04216A



8

Parts List



IMPORTANT

For a proper working machine, use Factory Approved Parts. **V-BELTS** are specially designed to engage and disengage safely. A substitute (non OEM) V-Belt can be dangerous by not disengaging completely.

NOTE: For painted parts, please refer to the list of color codes below. Please add the applicable color code, wherever needed, to the part number to order a replacement part. For instance, if a part numbered 700-xxxx is painted green, the part number to order would be 700-xxxx-0665.
Green: 0665
Powder Black: 0637

1	747-1161A	Blade Control
2	749-1233A	Upper Handle
3	747-04080	Grass Catcher Frame
4	749-0928A	Lower Handle
5	720-0279	Wing Nut
6	710-1205	Rope Guide
7	710-1174	Carriage Bolt ,5/16-18 x 2
8	664-04027	Grass Bag Assembly
9	720-0284	Hand Knob
10	736-0451	Saddle Washer
11	726-0240	Cable Tie
12	710-0703	Carriage Bolt ,1/4-20
13	731-04134	Rear Discharge Door
14	750-04162	Spacer
15	732-04089A	Torsion Spring - LH
16	732-04090A	Torsion Spring - RH
17	734-04087	Rear Wheel, 8" x 1.8"
18	731-04150	Rear Baffle
19	756-04017	Input Pulley
20	787-01277	Deck - 21"
21	715-04011	Roll Pin
22	782-5002B	Front Baffle
23	748-04015A	Blade Adapter w/Pulley
24	742-0641	21" Standard Cut Blade
25	710-1257	Hex Bolt , 3/8-24 x 2.5
26	687-02044	Pivot Plate Assembly
27	736-0524B	Blade Bell Support
28	782-0512B	Height Adjustment Plate - RH
	782-0511A	Height Adjustment Plate - LH
29	720-0426	Adjustment Lever Knob
30	732-0706	Front Lever - RH
	732-0707	Front Lever - LH
31	738-04136	Shoulder Screw
32	634-04100	Front Wheel, 8" x 1.8"
33	710-04371	Screw, 1/4-15 x 1.250
34	746-1114	Control Cable - 50.56"
35	750-04178	Sleeve Spacer - RH
36	731-04998	Trailshield
37	732-0700	Trailshield Wire
38	712-0397	Wing Nut, 1/4-20
39	747-04035	Rear Door Pivot Rod
40	732-04175	Spring Lever
41	687-02071	Pivot Arm Assembly - RH
	687-02070	Pivot Arm Assembly - LH

42	710-1652	AB Screw
43	712-04065	Flange Lock Nut, 3/8-16
44	714-0104	Hairpin Clip
45	710-0654A	TT Sems Screw, 3/8-16 x 1.00
46	682-0511A	Ht. Adj. Assy. Front - LH
	682-0512A	Ht. Adj. Assy. Front - RH
47	687-02069	Rear Handle Bracket Assy. - LH
	687-02068	Rear Handle Bracket Assy. - RH
48	747-1214	Drive Control
49	710-1650	Shoulder Screw
50	746-04112A	Drive Cable
51	754-0637A	V-Belt
52	618-0657	Transmission Assembly
53	731-05021A	Front Drive Cover
54	732-1043	Belt Tension Spring
55	682-0015	Bearing Assembly
56	736-0447	Wave Washer
57	710-0216	Hex Screw
58	715-0221	Dowel Pin
59	717-1762	Gear, 14T - RH
	717-1761	Gear, 14T - LH
60	716-0865	Snap Ring
61	782-7551A	Wheel Dust Cap
62	716-0102	Snap Ring
63	736-0474	Washer, 1.5" OD
64	750-1166	Sleeve Spacer - LH
65	725-1442	Electric Starter Harness Assembly
66	710-0606	Screw, 1/4-20 x 1.50
67	710-0136	Screw, 1/4-20 x 1.75
68	710-0969	Screw, #12-16 x 1.00
69	712-0324	Hex Lock Nut, 1/4-20
70	725-0298	7.5 Amp Fuse
71	725-0873	Key Switch
72	725-1206	Plug
73	725-1276	12 Volt Battery
74	725-1428	Fuse Holder
75	725-1538	Ext Harness
76	731-0891A	Upper Battery Tray
77	736-0451	Saddle Washer, .320 x .93 x .060
78	736-0270	Bell Washer, .265 x .75 x .062
79	782-9012	Lower Battery Tray
	725-0727†	Battery Charger
	751-10153†	Engine Bracket
	731-04525†	Engine Shroud

† Not Shown