



8

Parts List



IMPORTANT
 For a proper working machine, use Factory Approved Parts. V-BELTS are specially designed to engage and disengage safely. A substitute (non OEM) V-Belt can be dangerous by not disengaging completely.

1	731-2626	Bail Cover
2	747-1161A	Blade Control
3	746-1113	Control Cable 37.75-inch
4	726-0240	Cable Tie
5	664-04007A	Grass Bag Assembly
6	747-04080	Grass Bag Frame
7	732-0700	Trailshield Wire
8	731-04998	Trailshield
9	731-04134A	Rear Door
10	687-02057	Height Adj. Bracket Assy - LH
	687-02056	Height Adj. Bracket Assy - RH
11	787-01248	21-inch Deck
12	732-1043	Compression Spring
13	687-02193	Front Height Adj. Assy - LH
	687-02194	Front Height Adj. Assy - RH
14	750-04595	Sleeve Spacer .52 ID x 1.5 long
15	715-0221	Dowel Pin
16	618-04376	Transmission
17	710-1650	Shoulder Screw
18	731-05013A	Deck Cover
19	782-5002B	Front Baffle
20	750-04438A	Sleeve Spacer
21	754-04101	V-Type Belt
22	736-04173	Spring Washer 1.005 x 1.825 x .048
23	748-04082	Blade Adapter with Star
24	742-0741	21-inch Mulching Blade
25	736-0524B	Bell Blade Spacer
26	710-1257	Screw 3/8-24 x 2.5
27	736-0250	Flat Washer 1 x 1.75 x .107
28	756-04160	Key Half Pulley
29	756-04161	Upper Half Pulley
30	750-04594	Sleeve Spacer
31	682-0015	Front Bearing Assembly
32	787-01298	Adjustment Plate RH
	787-01299	Adjustment Plate LH
33	687-02044	Pivot Plate Assembly
34	732-0706	Spring Lever RH
	732-0707	Spring Lever LH
35	736-0474	Flat Washer 1.01 x 1.5 x .035
36	716-0102	Snap Ring

37	782-7551A	Wheel Cover
38	717-1762	Spur Gear 14T RH
	717-1761	Spur Gear 14T LH
39	710-04531	Screw 1/4-20 x .39
40	734-2042	Front Wheel 8 x 2.125 Gear Zag Blk
41	731-0981A	Hubcap
42	710-0216	Screw 3/8-16 x .75
43	720-0426	Knob
44	736-0447	Wave Washer 1.5 x 1 x .029
45	710-1008	Screw TT 3/8-16 x 1.875
46	712-04065	Flange Lock Nut 3/8-16
47	782-5004B	Rear RH Baffle
48	710-1652	Screw TT 1/4-20 x .625
49	720-0312	Foam Grip
50	738-0507B	Shoulder Screw
51	734-04093	Rear Wheel 12 x 2.125 Idle Zag Gry
52	732-0866	Spring Lever
53	687-02039A	Pivot Arm Assembly RH
	687-02040A	Pivot Arm Assembly LH
54	710-0599	Screw TT 1/4-20 x .5
55	714-0104	Hairpin Clip
56	687-02192	Handle Bracket Assembly RH
	687-02191	Handle Bracket Assembly LH
57	710-0703	Screw 1/4-20 x .75
58	631-0075B	Engine Spacer
59	732-04090A	Torsion Spring RH
	732-04089A	Torsion Spring LH
60	750-04162	Spacer
61	747-0996	Pivot Rod
62	782-5003A	Rear Baffle LH
63	710-1017	Screw AB 1/4-14 x .625
64	712-0397	Wing Nut
65	749-0928A	Lower Handle
66	710-1174	Carriage Bolt 5/16-18 x 2
67	720-04072	Star Knob
68	720-0279	Handle Knob
69	710-1205	Eye Bolt
70	749-1092A	Upper Handle
71	747-1214	Drive Control
72	746-04203	Control Cable 51-inch