


Model Series J830



Ref No.	Part Number	Description
1	746-04464	Drive Cable
2	735-04059	Rubber Grommet
3	687-02398	Drive Control
4	732-04516	Shift Spring
5	747-04879	Blade Control
6	746-04465	Control Cable
7	749-04037	Lower Handle
8	725-0157	Cable Tie
9	732-04265	Torsion Spring, LH
10	710-0599	TT Screw, 1/4-20 x .500
11	787-01618	21-inch Deck
12	710-0654A	TT Screw, 3/8-16 x 1.00
13	787-01346	Front Deck Baffle
14	731-06304	Variable Speed Cont. Panel Cover
15	731-06305	Variable Speed Cont. Panel Cover
16	710-0779A	Screw, #10-16 x .500
17	736-0451	Saddle Washer
18	736-0329	Washer, Lock, 1/4
19	712-04064	Nut, Flange Lock, 1/4-20
20	710-0606	Screw, 1/4-20 x 1.50
21	731-06374	Variable Speed Control Panel
22	747-04718	Bail Pivot Rod - RH
	747-04719	Bail Pivot Rod - LH
23	746-04439	Variable Speed Cable
24	731-06173	Rear Baffle
25	710-3025	Screw, 5/16-18 x .625
26	712-04063	Flange Lock Nut, 5/16-18
27	731-05462A	Trailshield
28	731-05157	Mulch Plug
29	731-05017A	Rear Door

Ref No.	Part Number	Description
30	710-1241	Screw, 1/4-15 x 1.00
31	720-04072	Star Knob
32	732-04264	Torsion Spring, RH
33	711-04374	Door Pivot Rod
34	647-04051	Grass Catcher Frame
35	664-04045	Grass Catcher
36	710-1174	Carriage Bolt, 5/16-18 x 2.00
37	720-0279	Wing Nut
38	710-1205	Eye Bolt
39	749-04436	Upper Handle
40	736-0270	Bell Washer, .265 x .75 x .062
41	732-1014	Torsion Spring
42	17032A	Chute Deflector Adapter
43	747-0710	Hinge Pin
44	687-02055	Mulch Plug Assembly
45	731-04177	Side Discharge Chute
46	710-04373A	Screw, #12-16 x .75
47	728-0199	Rivet, Plastic
48	731-06189	4 Speed Actuator
49	731-06193	Speed Selector Level
50	715-04073	Dowel Pin
51	736-0463	Washer, Flat, .25 x .630 x .0515
52	736-3000	Washer, Flat, .250 x .750 x .119
53	710-0895	Screw, 1/4-15 x .750
54	725-04329	Battery Charger
55	625-04050	Harness Assembly
56	725-04323	Battery, 12V
57	725-0201	Ignition Key
58	725-04347	Key Switch

Model Series J830

Ref No.	Part Number	Description
1	754-04176	V-Belt
2	732-04338B	Spring Lever
3	720-04092	Foam Grip
4	717-04540	Spur Gear, 14T - LH
5	738-04278	Shldr. Screw, 1/4-20 x 0.50
6	710-04373A	Screw, #12-16 x .750
7	749-04267A	Cross Bracket
8	687-02204	Front Bracket Assembly
9	731-05470	Clip Spacer
10	741-04136B	Split Hex Flange Bearing
11	734-04014B	Front Wheel
12	712-04065	Flange Lock Nut, 3/8-16
13	634-04430	Rear Wheel
14	710-04531	Screw, 1/4-20 x .39
15	717-04539	Spur Gear, 14T - RH
16	731-06284	Baffle
17	731-06355	Wheel Dust Cover
18	687-02415	Transmission Bearing Support
19	731-05872	Clip Spacer
20	716-0198	Retaining Ring .875
21	687-02314	Rear Bracket Assembly

Ref No.	Part Number	Description
22	732-04482	Compression Spring
23	756-04316	Upper Pulley
24	736-0406	Flat Washer, .442 x 1.38 x .060
25	756-04317	Lower Pulley
26	687-02320	Handle Bracket Assembly LH
27	715-0221	Dowel Pin
28	618-04581	Transmission Assembly
29	687-02321	Handle Bracket Assembly RH
30	748-0390	Bearing Support Spacer
31	732-04313	Extension Spring
32	748-04096	Blade Adapter
33	710-1044	Screw, 3/8-24 x 1.50
34	736-0524B	Blade Bell Support
35	742-0741	21" Mulching Blade
36	736-0447	Washer, Wave, 1.5 x 1.0 x .029
37	710-0599	TT Screw, 1/4-20 x .500
38	731-06112	Engine Baffle
39	656-04046	Lower Pulley Assembly
40	756-04311	Pulley, Half
41	736-3012A	Washer, Wave, .390 x .625 x .016
42	710-1241	Screw, 1/4-15 x 1.00