


## PARTS LIST

### REPLACEMENT PARTS - MODEL 2-CYCLE 2-CYCLE GAS TRIMMER/ BRUSHCUTTER




Item	Part No.	Description
1	753-04511	Air Cleaner Cover Assembly (includes 2 & 38)
2	791-180350B	Air Cleaner Filter
3	791-180351	Carburetor Mounting Screw Assembly
4	791-180226	Wavey Washer
5	791-182202	Choke Knob w/Screw
6	753-04418	Choke Lever (includes 5)
7	753-04419	Choke Plate (includes 6)
8	753-05133	Carburetor Assembly (includes 9 & 19)
9	791-610675	Carburetor Gasket
10	791-181860	Carb Mount Screw
11	791-683947B	Primer & Hose Assembly
12	753-1196	Carb Mount Assembly (includes 10, 13 & 14)
13	791-684451	Reed Assembly
14	753-1208	Carburetor Mount Gasket
15	791-612134	Rear Mounting Pad
16	753-04307	Fuel Tank Assembly (includes 17-19)
17	791-182529	Fuel Cap Assembly
18	791-181086	Fuel Return Line
19	753-04233	Fuel Line Assembly
20	791-145308	Front Mounting Pad
21	753-04409	Shroud Extension & Stand (includes 38)
22	791-182736	Flywheel Assembly
23	791-181525	Spacer
24	753-04459	Recoil Pulley Assembly (includes 27 & 29)
25	753-04286	Recoil Spring
26	753-1200	Rope Guide
27	753-04288	Pulley Retainer
28	791-181079	Pull Handle
29	791-613103	Rope
30	753-04417	Pressure Plate Assembly (includes 31)
31	753-1202	Plate Screw

Item	Part No.	Description
32	753-04402	Starter Housing Assembly (includes 24-31, 33 & 38)
33	791-181862	Housing Screw
34	791-182396	Clutch Washer
35	791-182369	Clutch Rotor Assembly
36	791-153592	Clutch Drum Assembly
37	753-04403	Clutch Cover Assembly (includes 38-41)
38	791-181345	Cover Screw
39	791-182519	Anti-Rotation Screw
40	753-04003	Clamping Screw
41	791-180217	Clamping Nut
42	753-05025	Wire Leads and Sleeve
43	791-611063	Ground Tab
44	753-04336	Module Assembly
45	791-610311B	Spark Plug
46	753-05169	Muffler Assembly (includes 47, 48 & spark arrestor)
47	753-04619	Exhaust Gasket
48	753-04620	Muffler Mounting Bolts
49	753-04814	Cylinder Assembly (includes 51 & 52)
50	753-04367	Piston and Rod Assembly
51	753-04182	Cylinder Gasket
52	791-182723	Cylinder Bolt
*	753-1209	Piston Ring Set
*	753-04812	Short Block Assembly (includes 10, Crankcase, 45, 49-52)
*	791-181599	Clutch Springs (Qty. 2)
*		Items Not Shown

PARTS LIST

REPLACEMENT PARTS - MODEL 2-CYCLE  
2-CYCLE GAS TRIMMER/ BRUSHCUTTER



Item	Part No.	Description
1	753-05192	Throttle Housing Assembly (includes 2-5)
2	753-04991	Throttle Trigger
3	753-05007	Throttle Trigger Spring
4	753-05171	Throttle Trigger Lock-Out
5	791-182405	Switch Assembly
6	753-05172	Throttle Cable Assembly
7	791-610327	Harness Clip
8	753-04236	Upper Drive Shaft Housing Assembly
9	791-181099	J-Handle Assembly
10	791-683295	Handle Bracket Assembly (includes 11-16)
11	791-181811	Screw
12	791-181812	Upper Handle Clamp
13	791-181813	Middle Handle Clamp
14	791-181814	Lower Handle Clamp
15	791-181815	Nut
16	791-182519	Anti-Rotation Screw
17	753-1190	Split Boom Coupler (includes 18-21)
18	791-182057	Screw
19	791-181617	Bolt
20	791-181981	Adjustment Knob (includes 21)
21	753-04386	Knob Retaining Nut
22	791-182541	Lower Drive Shaft Housing Assembly
23	791-613300	Lower Flexible Drive Shaft
24	791-182200	Shield Mount Screw Assembly
25	791-182193	2 piece Gearbox Assembly (includes 26-29)
26	791-182195	Gearbox Mounting Hardware
27	791-182519	Anti-Rotation Screw
28	791-182196	Blade Driver
29	753-04348	Palnut
30	791-147492	Blade Shield/Shield Mount
31	791-683304	Shield Mounting Screw
32	753-1191	Shield Assembly (includes 33)
33	791-682061	Blade Assembly
34	791-147490	Retaining Washer
35	791-612483	Spool Shaft
36	791-683301	Outer Spool Assembly (includes 37)
37	791-612026	Retainer
38	791-610636B	Spring
39	791-147495	Inner Reel
40	791-180814B	Bump Head Knob Assembly
41	791-145873B	4-Tooth Blade
42	791-181699	Nut
*	791-180014B	Blade Retaining Kit (includes 34 & 42)
*	791-613226	Locking Rod Tool
*	791-682075B	Shoulder Harness

Optional Accessories

- \* 753-04216 Replacement Line, 0.105 Diameter
- \* 753-1224 Reel and Line Assembly
- \* 753-1161 Bump Head Assembly (includes 35-40)

\* Items Not Shown