



REPLACEMENT PARTS - MODEL BL100

2-CYCLE GAS TRIMMER



Item	Part No.	Description	Item	Part No.	Description
1	753-04511	Air Cleaner Cover Assembly (includes 2 & 34)	29	791-181079	Pull Handle
2	791-180350B	Air Cleaner Filter	30	791-611061	Rope Guide
3	791-180351	Carburetor Mounting Screws	31	791-613103	Rope
4	791-180226	Wavey Washer	32	791-182405	Switch Assembly (includes 39)
5	791-182202	Choke Knob & Screw	33	791-181862	Housing Screw
6	753-04418	Choke Lever Assembly (includes 5)	34	791-181345	Cover Screw
7	753-04419	Choke Lever & Plate (includes 6)	35	753-04466	Anti Rotation Screw
8	753-04408	Carburetor Assembly (includes 9 & 19)	36	753-05056	Clamp Assembly (includes 35)
9	791-610675	Carburetor Gasket	37	753-05422	Starter Housing Assembly (includes 22 & 24-36)
10	791-181860	Carb Mount Screw	38	753-05091	Shroud Extension and Stand (includes 34)
11	791-683974B	Primer and Hose Assembly	39	753-04290	Wire Lead
12	753-1196	Carburetor Mount Assembly (includes 10, 13 & 14)	40	753-04324	Module Assembly
13	791-684451	Reed Assembly	41	791-611063	Ground Tab
14	753-1208	Carburetor Mount Gasket	42	791-610311B	Spark Plug
15	791-612134	Rear Mounting Pad	43	753-05169	Muffler Assembly (includes 44, 45 & Spark Arrestor)
16	753-04285	Fuel Tank Assembly (includes 17-19)	44	753-04619	Exhaust Gasket
17	791-182612	Fuel Cap Assembly	45	753-04620	Muffler Mounting Bolt Assembly
18	791-181086	Fuel Return Line	46	753-04814	Cylinder Assembly (includes 48 & 49)
19	791-682039	Fuel Line Assembly	47	753-04367	Piston & Rod Assembly
20	791-145308	Front Mounting Pad	48	753-04182	Cylinder Gasket
21	791-182736	Flywheel Assembly	49	791-182723	Cylinder Bolt
22	753-1202	Plate Screw	*	753-1209	Piston Ring
23	791-610303	Square Nut Drive	*	753-04826	Short Block Assembly (includes Crankcase, 10, 42 & 46-49)
24	753-04928	Pressure Plate (includes 22 & 28)			
25	753-04288	Palnut			
26	753-04823	Recoil Pulley Assembly (includes 25 & 31)			
27	753-04286	Recoil Spring			
28	753-04824	Eyelet Retainer			
			*	not shown	

REPLACEMENT PARTS - MODEL BL100 2-CYCLE GAS TRIMMER



Item	Part No.	Description
1	753-04927	Throttle Housing Assembly (includes 2-4)
2	791-610314	Throttle Trigger Spring
3	791-180975	Throttle Trigger
4	753-04917	Throttle Housing Screws
5	753-04901	Throttle Cable
6	753-04280	Flexible Drive Shaft
7	753-04921	Drive Shaft Housing
8	791-153064	D-Handle Assembly (includes 9)
9	791-181587	D-Handle Hardware
10	753-04282	Guard Mounting Hardware
11	753-04283	Guard Assembly (includes 12)
12	791-180553	Blade Assembly
13	753-04284	Outer Reel w/Retainer
14	791-610317B	Spring
15	753-1155	Inner Reel
16	791-153066B	Bump Knob
*	753-04281	Drive Shaft Housing Assembly (includes 6 & 13)


Optional Accessories

* 791-153577B Inner Reel and Line

* Items Not Shown

REPLACEMENT PARTS - MODEL BL150

2-CYCLE GAS TRIMMER



Item	Part No.	Description
1	753-04927	Throttle Housing Assembly (includes 2-3)
2	791-610314	Throttle Trigger Spring
3	791-180975	Throttle Trigger
4	753-04901	Throttle Cable
5	791-153064	D-Handle (includes 6)
6	791-181587	D-Handle Hardware Assembly
7	753-04330	Drive Shaft Housing Assembly
8	753-05211	Flexible Drive Shaft
9	791-180547	Guard Mounting Screw Assembly
10	791-180548	Guard Assembly (includes 11)
11	791-180553	Blade Assembly
12	791-145569	Anti-Rotation Screw
13	753-05185	Gearbox Assembly (includes 14-18)
14	791-153619	Outer Spool and Eyelet Assembly (includes 15)
15	791-610660	Retainer (10 pack)
16	791-610317B	Spring
17	753-1155	Inner Reel
18	791-153066B	Bump Head Knob Assembly

Optional Accessories

* 791-153577 Spool and Line (25 ft.) Assembly

* Items Not Shown