


Model E46M



Ref No.	Part Number	Description
1	747-1214	Drive Control
2	710-0599	TT Screw 1/4-20 x 0.5
3	736-0270	Bell Washer.265 x 0.75
4	17032A	Deflector Chute Adapter
5	732-1014	Torsion Spring
6	618-04376A	Transmission Assembly
7	747-1161A	Blade Control
8	749-1233D	Upper Handle
9	731-04177	Chute Deflector
10	687-02055	Mulch Plug Complete
11	747-0710	Hinge Pin
12	782-7551A	Wheel Dust Cap
13	720-0279	Handle Knob
14	720-04072	Star Knob
15	710-1205	Eye Bolt
16	746-04485	Control Cable
17	710-1174	Carriage Bolt 5/16-18 x 2.0
18	732-04089A	Torsion Spring - LH
19	726-0240	Cable Tie
20	746-04380	Choke Cable
21	710-0654A	Self-Tapping Sems Screw
22	746-04484	Drive Cable
23	664-04027	Grassbag
24	710-1650	Shoulder Screw # 12 -24
25	687-02347	Front Bearing Assembly
26	710-1241	Screw, 1/4-15 x 1.000
27	687-02194A	Height Adjustment Ass'y - RH
	687-02193A	Height Adjustment Ass'y - LH
28	787-01278	21" Deck
29	731-04150C	Rear Baffle
30	712-0397	Wing Nut
31	750-04595	Slev. Spacer 1.4" Lg.
32	710-0216	Hex Screw, 3/8-16 x.75
33	732-04090A	Torsion Spring - RH
34	712-04065	Flange Lock Nut, 3/8-16
35	731-05021A	Transmission Cover
36	782-5002B	Front Baffle
37	754-0637A	V-Belt
38	736-0447	Wave Washer
39	750-04594	Sleeve Spacer 8.985" Lg.
40	748-04015A	One Piece Blade Adapter
41	742-0741	21" Mulching Blade
42	736-0524B	Blade Bell Support

Ref No.	Part Number	Description
43	687-02334	Pivot Plate Assembly
44	710-1257	Hex Screw 3/8-24 x 2.50
45	749-0928A	Lower Handle
46	732-1043	Belt Tension Spring
47	720-0426	Adjustment Knob
48	731-05865	Rear Discharge Door
49	634-04100	Front Wheel
50	710-04531	Screw, 1/4-20 x .390
51	717-1762	Gear 14T RH FWD
	717-1761	Gear 14T LH FWD
52	747-04080A	Grass Bag Frame
53	710-0703	Carriage Bolt 1/4-20
54	716-0102	Snap Ring
55	710-1652	TT Scr. w/Washer 1/4-20 x.625
56	687-02271A	Handle Bracket Assembly - RH
	687-02270A	Handle Bracket Assembly - LH
57	715-0221	Dowel Pin
58	736-0474	Washer
59	687-02333	Pivot Arm Assembly - RH
	687-02332	Pivot Arm Assembly - LH
60	732-04175	Rear Spring Lever
61	738-04266	Shoulder Scr.500 Dia. x.434
62	734-04087	Rear Wheel
63	782-01298	Height Adjuster Plate - RH
	782-01299	Height Adjuster Plate - LH
64	732-0706	Front Lever - RH
	732-0707	Front Lever - LH
65	747-04587	Pivot Rod
66	731-05642	Rear Trailing Shield
67	731-06029	Engine Baffle
68	787-01593	Engine Baffle Bracket
69	731-05401	Engine Shroud
70	710-04577	Screw, Machine, M4-.7
71	710-0606	Screw, 1/4-20 x 1.50
72	712-04064	Nut, Flange Lock, 1/4-20
73	725-04329	Battery Charger
74	629-04051	Electric Start Harness Assembly
75	725-04347	Key Switch
76	710-1667A	Screw, #10-16 x .750
77	725-0201	Key
78	725-1276	Battery
79	728-0199	Rivet