


# PARTS LIST


## HOUSING PARTS - MODEL TB320BV 2-CYCLE GAS MULCHING BLOWER VACUUM



Item	Part No.	Description	Item	Part No.	Description
1	753-04511	Air Cleaner Cover Assembly (includes 2 & 33)	28	753-04996	Eyelet Retainer
2	791-180350B	Air Cleaner Filter	29	791-611061	Rope Guide
3	791-180351	Carburetor Mounting Screws	30	791-181079	Pull Handle
4	791-180226	Wavey Washer	31	791-613103	Rope
5	753-04418	Choke Lever Assembly	32	791-181862	Housing Screw
6	753-04419	Choke Lever & Plate (includes 5)	33	791-181345	Cover Screw
7	753-04408	Carburetor Assembly (includes 8 & 18)	34	791-182402	Wire Lead
8	791-610675	Carburetor Gasket	35	753-05404	Starter Housing Assembly (includes 23-33)
9	791-181860	Carb Mount Screw	36	753-04409	Shroud Extension and Stand (includes 33)
10	791-683974B	Primer and Hose Assembly	37	753-05866	Module Assembly
11	753-1196	Carburetor Mount Assembly (includes 9, 12 & 13)	38	791-610311B	Spark Plug
12	791-684451	Reed Assembly	39	791-180980	Exhaust Gasket
13	753-05487	O-Ring	40	753-04620	Muffler Mounting Bolt Assembly
14	753-04747	Crankcase Service Assembly (includes 9)	41	753-05709	Muffler Assembly (includes 39, 40 & Spark Arrestor)
15	791-612134	Rear Mounting Pad	42	753-04367	Piston & Rod Assembly
16	791-182529	Fuel Cap Assembly	43	791-182723	Cylinder Bolt
17	791-181086	Fuel Return Line	44	753-04182	Cylinder Gasket
18	791-682039	Fuel Line Assembly	45	753-04814	Cylinder Assembly (includes 43 & 44)
19	753-04310	Fuel Tank Assembly (includes 16-18)	46	791-181524	Crankshaft Extension
20	791-145308	Front Mounting Pad	47	791-182396	Washer
21	791-182736	Flywheel Assembly	*	753-1209	Piston Ring Set
22	753-04748	Spacer	*	753-04924	Short Block Assembly (includes 8, 14, 38 & 42-45)
23	753-1202	Plate Screw			
24	753-04288	Palnut			
25	753-04705	Pressure Plate (includes 23 & 28)			
26	753-04823	Recoil Pulley Assembly (includes 24)			
27	753-04286	Recoil Spring			
			*	not shown	

## PARTS LIST

### HOUSING PARTS - MODEL TB320BV 2-CYCLE GAS MULCHING BLOWER VACUUM



Item	Part No.	Description
1	753-04452	Engine Cover Assm (includes 2)
2	791-181345	Screw
3	753-04451	Handle Asm (includes 2)
4	753-05013A	Throttle control Asm (includes 5, 6 & 8)
5	791-00048	Throttle Control Lever
6	791-182423	Screw
7	791-182405	Rocker Switch Assm
8	791-182422	Throttle Control Plate (includes 6)
9	791-00049	Throttle Cable
10	753-04809	Engine Mount Plate (includes 11 & 12)
11	791-182409	Washer
12	753-04755	Screw
13	753-04596	Impeller Blade
14	753-04482	Impeller Hardware (includes 15-17)
15	753-04833	Washer
16	753-04834	Lock Washer
17	791-182414	Bolt

Item	Part No.	Description
18	753-04456	Vacuum Door Spring
19	753-04455	Vacuum Door Lock
20	753-04454	Vacuum Door
21	791-182424	Mounting Plate Hardware
22	791-182647	Blower Tube
23	791-182477	Vacuum Bag Adaptor
24	791-180466	Upper Vacuum Tube
25	791-180467	Lower Vacuum Tube
*	791-612930	Cable Tie
*	753-04458	Vacuum Bag Assm (includes Bag & Cable Tie)
*	791-682075B	Shoulder Strap
*		<i>Items Not Shown</i>