


PARTS LIST

ENGINE PARTS - MODEL YMGBV3100 2-CYCLE GAS MULCHING BLOWER VACUUM




Item	Part No.	Description
1	753-04511	Air Cleaner/Muffler Cover Assembly (includes 2 & 32)
2	791-180350B	Air Cleaner Filter
3	791-180351	Carburetor Mounting Screw
4	791-180226	Wavey Washer
5	791-182202	Choke Knob and Screw
6	753-04418	Choke Lever Assembly (includes 5)
7	753-04419	Choke Lever and Plate (includes 6)
8	753-04408	Carburetor Assembly (includes 9 & 20)
9	791-610675	Carburetor Gasket
10	791-181860	Carb Mount Screw
11	791-683974B	Primer and Hose Assembly
12	753-1196	Carb Mount Assembly (includes 10,13 & 14)
13	791-684451	Reed Assembly
14	753-05487	O-Ring
15	753-04328	Crank Case Service Assembly (includes 10)
16	791-612134	Rear Mounting Pad
17	753-04310	Fuel Tank Assembly (includes 18-20)
18	753-1187	Fuel Cap Assembly
19	791-181086	Fuel Return Line
20	791-682039	Fuel Line Assembly
21	791-145308	Front Mounting Pad
22	791-182401	Shroud Extension (includes 32)
23	791-182736	Flywheel Assembly
24	753-04481	Spacer
25	753-1199	Recoil Pulley
26	791-613102	Recoil Spring
27	791-611061	Rope Guide
28	791-180930	Pulley Retainer Assembly

Item	Part No.	Description
29	791-181079	Pull Handle
30	791-613103	Rope
31	791-181862	Housing Screw
32	791-181345	Cover Screw
33	791-181931	Starter Housing Assembly (includes 25-32)
34	791-182402	Wire Lead Assembly
35	753-05866	Module Assembly
36	791-610311B	Spark Plug
37	753-05709	Muffler Assembly (includes 38 & 39)
38	791-180980	Exhaust Gasket
39	753-04620	Muffler Mounting Bolt Assembly
40	753-04814	Cylinder Assembly (includes 42 & 43)
41	753-04367	Piston and Rod Assembly
42	753-04182	Cylinder Gasket
43	791-182723	Cylinder Bolt
44	791-181524	Crankshaft Extension
45	791-182396	Washer
*	753-1209	Piston Ring
*	753-04689	Spark Arrestor Set
*	753-04895	Short Block Assembly (includes 10, 15, 36, 40-43)

* Items Not Shown

PARTS LIST

HOUSING PARTS - MODEL YMGBV3100 2-CYCLE GAS MULCHING BLOWER VACUUM



Item	Part No.	Description
1	753-04753	Engine Cover Assembly (includes 2)
2	753-04595	Cover Screw
3	753-05013A	Throttle Control Assembly (includes 4-6)
4	791-00048	Throttle Control Lever
5	791-182422	Throttle Control Plate (includes 6)
6	791-182423	Screw, Plastic
7	791-182405	Rocker Switch Assembly
8	753-04483	Engine Mounting Plate (includes 9 & 10)
9	791-182409	Washer
10	791-181903	Screw
11	791-182410	Mode Control Flapper
12	791-00050	Mode Control Lever (includes 21)

Item	Part No.	Description
13	753-04596	Impeller Blade
14	753-04833	Washer
15	753-04834	Lock Washer
16	791-182414	Bolt
17	791-00051	Blower/Vac Tube Assembly (includes 22)
18	791-182417	Vacuum Bag Adapter
19	791-182424	Mounting Plate Hardware
20	791-182425	Blower/Vac Tube Mounting Hardware
21	791-181482	Screw
22	791-00049	Throttle Cable
23	791-181345	Screw
*	791-612930	Cable Tie
*	753-04465	Vacuum Bag Assembly (includes 19, Vacuum Bag & Cable Tie)
*	753-04325	Patio Head

* Items Not Shown