


REPLACEMENT PARTS - MODEL TB144

4-CYCLE GAS CULTIVATOR

PPN 21CA144R966

#14 includes crankcase breather



REPLACEMENT PARTS - MODEL TB144
4-CYCLE GAS CULTIVATOR
PPN 21CA144R966

<u>Item</u>	<u>Part No.</u>	<u>Description</u>
1	753-05998	Engine Cover
2	791-181345	Screw
3	753-05377	Screw
4	753-05209	Valve Cover
5	753-05210	Valve Cover Gasket
6	753-05438	Cylinder Assembly (includes 5, 7 & 43)
7	791-181003	Cylinder Screw
8	753-05247	Insulator Gasket
9	753-05248	Nut
10	753-05452	Insulator (includes 11)
11	753-05439	Carburetor Gasket
12	753-1225	Carburetor w/Primer
13	791-181751	Carburetor O-Ring
14	753-05995	Air Filter Cover Assembly (includes 16)
15	753-05253	Air Filter Mounting Screw
16	753-05996	Air Filter
17	753-05289	Fuel Cap
18	791-181930	Screw
19	791-182366	Clip Nut
20	753-05443	Fuel Tank Assembly (includes 17)
21	753-05997	Muffler Assembly (includes 22 & 23)
22	753-05244	Muffler Gasket
23	753-05246	Muffler Mounting Screw
24	753-04039	Lead Wire
25	753-05999	Starter Housing Assembly (includes 3 & 26-29)


<u>Item</u>	<u>Part No.</u>	<u>Description</u>
26	753-1202	Plate Screw
27	753-05260	Push Nut
28	753-06051	Rope
29	791-181079	Pull Handle
30	791-182396	Washer
31	753-1238	Clutch Assembly
32	791-153592	Clutch Drum
33	753-05446	Clutch Cover Assembly (includes 34-36)
34	791-181345	Cover Screw
35	791-182519	Anti-Rotation Screw
36	753-04291	Clamping Screw Assembly
37	753-05243	Ignition Module Assembly
38	753-05078	Spacer
39	753-05240	Flywheel
40	791-181861	Shroud Screw
41	753-04919	Cam Bracket Assembly (includes 42)
42	791-181012	Cam Bracket Screw
43	791-182374	Cylinder Gasket
44	791-182377	Oil Pan (includes 45 & 46)
45	791-181018	Oil Pan Gasket
46	791-181020	Oil Pan Screw
47	791-182378	Dipstick Assembly (includes 48)
48	791-182290	O-Ring
49	753-05458	Piston Assembly
*	753-05784	Spark Plug
*	753-05450	Shortblock Assembly (includes 3-7 & 37-49)

* Items Not Shown

REPLACEMENT PARTS - MODEL TB144

4-CYCLE GAS CULTIVATOR

PPN 21CA144R966



Item	Part No.	Description	Item	Part No.	Description
1	753-04042	Throttle Control	19	753-04060	Cap Screw
2	753-05940	Torsion Spring	20	753-04061	Lock Nut
3	791-182673	On/Off Switch	21	753-04062	Cap Push
4	753-04044	Foam Grip	22	753-04063	Wheel Support Bracket Assembly
5	753-06050	Throttle Cable	23	753-04501	Wheel
6	753-04498	Upper Handle	24	753-05001	Cap Screw
7	791-182899	Bolt	25	753-04502	Tine Shield
8	753-04049	Cable Tie	26	753-06063	Gear Box Assembly
9	753-04499	Flex Shaft	27	753-05986	Tine (Left Outer, Right Inner)
10	791-182677	Knob	28	753-05987	Tine (Left Inner, Right Outer)
11	753-04052	Shoulder Washer	31	753-06064	Click Pin
12	753-04053	Lower Handle	32	753-05988	Edger Tine
13	753-04054	Screw	33	753-04068	Edger Wheel
14	753-04055	Front Handle	34	753-05469	Drive Shaft Housing
15	753-04056	Lock Nut	35	791-180288	Sleeve Retaining Bolt
16	753-04057	Cotter Pin			
17	753-04058	Tailpiece Bracket Assembly			
18	753-04059	Clevis Pin			