


# REPLACEMENT PARTS - MODEL TB70SS

## 2-CYCLE GAS TRIMMER

PPN 41DDT70C966




Item	Part No.	Description	Item	Part No.	Description
1	753-04511	Air Cleaner Cover Assembly (includes 2 & 26)	22	753-05775	Starter Housing Assembly (includes 23 & 26)
2	791-180350B	Air Cleaner Filter	23	791-181862	Housing Screw
3	791-180351	Carburetor Mounting Screw Assembly	24	753-05860	Clutch Rotor Assembly
4	791-180226	Wavey Washer	25	753-04403	Clutch Cover Assembly (includes 26-29)
5	791-182202	Choke Knob w/Screw	26	791-181345	Cover Screw
6	753-04418	Choke Lever (includes 5)	27	791-182519	Anti-Rotation Screw
7	753-04419	Choke Plate (includes 6)	28	753-04003	Clamping Screw
8	753-05133	Carburetor Assembly (includes 9)	29	791-180217	Clamping Nut
9	791-610675	Carburetor Gasket	30	753-05025	Wire Leads and Sleeve
10	791-181860	Carb Mount Screw	31	791-611063	Ground Tab
11	<b>791-683974B</b>	Primer & Hose Assembly	32	753-04336	Module Assembly (includes 31)
12	753-1196	Carb Mount Assembly (includes 10, 13 & 14)	33	791-610311B	Spark Plug
13	791-684451	Reed Assembly	34	753-05169	Muffler Assembly (includes 35, 36 & Spark Arrestor)
14	753-1208	O-Ring	35	791-180680	Exhaust Gasket
15	791-612134	Rear Mounting Pad	36	753-04620	Muffler Mounting Bolts
16	753-04307	Fuel Tank Assembly (includes 17)	37	753-04814	Cylinder Assembly (includes 39 & 40)
17	791-182529	Fuel Cap Assembly	38	753-04367	Piston and Rod Assembly
18	791-145308	Front Mounting Pad	39	753-04182	Cylinder Gasket
19	753-05091	Shroud Extension & Stand (includes 26)	40	791-182723	Cylinder Bolt
20	753-05240	Flywheel Assembly	*	753-1209	Piston Ring Set
21	791-181525	Spacer	*	753-04812	Short Block Assembly (includes Crankcase, 10, 33 & 37-40)

\* Items Not Shown

# REPLACEMENT PARTS - MODEL TB70SS

## 2-CYCLE GAS TRIMMER

PPN 41DDT70C966



Item	Part No.	Description
1	753-04234	Throttle Housing Assembly (includes 2-4)
2	753-04119	Throttle Trigger
3	791-182690	Throttle Trigger Spring
4	791-182405	Switch
5	753-04405	Throttle Cable Assembly
6	753-04344	Upper Drive Shaft Housing Assembly
7	753-06039	Deluxe D-Handle Assembly (includes 8)
8	753-06040	Bolt
9	753-1190	Split Boom Coupler (includes 10-13)
10	791-182057	Screw
11	791-181617	Bolt
12	791-181981	Adjustment Knob (includes 13)
13	753-04386	Knob Retaining Nut
14	753-06139	Lower Drive Shaft Housing Assembly
15	753-05267	Lower Flexible Drive Shaft
16	753-05698	Anti-Rotation Screw
17	753-06140	Gear Box Assembly (includes 16 & 22-26)
18	753-06125	Shield Mounting Screws
19	753-06123	Shield Assembly (includes 18 & 20)
20	753-06126	Blade Assembly
21	791-610327	Shoulder Strap Clip
22	753-04284	Outer Spool Assembly
23	791-610660	Retainer
24	791-610317B	Spring
25	753-1155	Inner Reel
26	791-153066B	Bump Knob Assembly
*	753-1156	Reel & Line Assembly
*	791-682075B	Shoulder Strap
*	753-05778	Fixed Line Insert

\* Items Not Shown