



REPLACEMENT PARTS - MODEL TB2BP 2-CYCLE GAS BACKPACK BLOWER

PPN 41BR2BPG966



Item	Part No.	Description	Item	Part No.	Description
1	753-05631	Muffler Assembly (includes 2)	10	753-05634	Aircleaner Assembly (includes 9)
2	753-05701	Muffler Gasket	11	753-04324	Module Assembly
3	753-05636	Shortblock Assembly (includes 4 & 11-17)	12	753-05703	Screw
4	753-05784	Spark Plug	13	753-05704	Cylinder Gasket
5	753-05702	Insulator Gasket	14	753-05705	Flywheel Adapter
6	753-05632	Insulator Assembly (includes 5)	15	753-05706	Washer
7	791-181709	Carburetor Gasket	16	753-05707	Bushing
8	753-05633	Carburetor Assembly (includes 7)	17	753-05708	Flywheel Assembly
9	791-181757	Air Filter	18	753-05635	Pawl Assembly

REPLACEMENT PARTS - MODEL TB2BP
2-CYCLE GAS BACKPACK BLOWER
 PPN 41BR2BPG966



<u>Item</u>	<u>Part No.</u>	<u>Description</u>	<u>Item</u>	<u>Part No.</u>	<u>Description</u>
1	753-06000	Nozzle	13	753-05648	Insulator Mount
2	753-05971	Lower Blower Tube	14	753-05649	Intake Cover
3	753-05975	Throttle Grip Assembly	15	791-181345	Screw
4	753-05991	Upper Blower Tube	16	791-180050	Nut
5	753-05640	Clamp	17	791-181862	Screw
6	753-05641	Flex Tube	18	753-05650	Impeller Housing Assembly (includes 13 & 15-17)
7	753-05990	Elbow	19	791-182414	Bolt
8	753-06036	Harness	20	753-04482	Impeller Hardware (includes 19)
9	753-05643	Lead Wire	21	753-05651	Impeller (includes 19 & 20)
10	753-06018	Throttle Cable	22	753-05654	Fuel Tank Assembly
11	753-05647	Nut	23	791-182529	Fuel Cap
12	753-05646	Spacer	24	753-05653	Starter Housing Assembly (includes 21 & 23)