



Model 86K



Ref No.	Part Number	Description
1	746-04515	Drive Cable
2	735-04059	Rubber Grommet
3	687-02417	Drive Control
4	732-04516	Shift Spring
5	747-04917A	Blade Control
6	746-04516	Control Cable
7	749-04435	Lower Handle
8	725-0157	Cable Tie
9	732-04265	Torsion Spring, LH
10	710-0599	TT Screw, 1/4-20 x .500
11	787-01618	21-inch Deck
12	710-0654A	TT Screw, 3/8-16 x 1.00
13	787-01346	Front Deck Baffle
14	731-06304	Variable Speed Cont. Panel Cover
15	731-06305	Variable Speed Cont. Panel Cover
16	710-0779A	Screw, #10-16 x .500
17	736-0451	Saddle Washer
18	736-0329	Washer, Lock, 1/4
19	712-04064	Nut, Flange Lock, 1/4-20
20	710-0606	Screw, 1/4-20 x 1.50
21	631-04278	Variable Speed Control Panel
22	747-04718	Bail Pivot Rod - RH
	747-04719	Bail Pivot Rod - LH
23	746-04439	Variable Speed Cable
24	731-06173	Rear Baffle
25	710-3025	Screw, 5/16-18 x .625
26	712-04063	Flange Lock Nut, 5/16-18
27	731-05462A	Trailshield
28	731-05157	Mulch Plug

Ref No.	Part Number	Description
29	731-05017A	Rear Door
30	710-1241	Screw, 1/4-15 x 1.00
31	720-04072	Star Knob
32	732-04264	Torsion Spring, RH
33	711-04374	Door Pivot Rod
34	647-04051	Grass Catcher Frame
35	664-04045	Grass Catcher
36	710-1174	Carriage Bolt, 5/16-18 x 2.00
37	720-0279	Wing Nut
38	710-1205	Eye Bolt
39	749-04436	Upper Handle
40	736-0270	Bell Washer, .265 x .75 x .062
41	732-1014	Torsion Spring
42	17032A	Chute Deflector Adapter
43	747-0710	Hinge Pin
44	687-02055	Mulch Plug Assembly
45	731-04177	Side Discharge Chute
46	710-04373A	Screw, #12-16 x .75
47	728-0199	Rivet, Plastic
48	731-06189	4 Speed Actuator
49	731-06193	Speed Selector Level
50	715-04073	Dowel Pin
51	736-0275	Washer, Flat, .344 x .688 x .065
52	736-3000	Washer, Flat, .250 x .750 x .119
53	714-0104	Cotter Pin
54	712-0397	Wing Nut
55	710-0703	Carriage Bolt, 1/4-20
56	710-0895	Screw, 1/4-15 x .750
57	746-04517	Choke Cable

Model 86K



Ref No.	Part Number	Description
1	754-04176	V-Belt
2	732-04480A	Spring Lever
3	720-04092	Height Adjuster Knob
4	717-04452	Spur Gear, 16T - LH
5	738-04278	Shldr. Screw, 1/4-20 x 0.50
6	710-04762	Screw, #12-16
7	749-04414	Cross Bracket
8	687-02367	Front Bracket Assembly
9	731-05470	Clip Spacer
10	741-04136B	Split Hex Flange Bearing
11	734-04014B	Front Wheel
12	712-04065	Flange Lock Nut, 3/8-16
13	634-04404	Rear Wheel
14	710-04770	Screw, 1/4-20 x .39
15	717-04457	Spur Gear, 16T - RH
16	717-04575	Gear, Spur, 23T
17	731-06145	Wheel Dust Cover
18	741-0604A	Bearing Sleeve
19	787-01645	Dust Cover Seal Plate
20	731-06146	Hub Cap
21	687-02390	Rear Bracket Assembly
22	732-04527	Compression Spring
23	756-04316	Upper Pulley
24	712-04161	Nut, Shldr.
25	756-04317	Lower Pulley
26	687-02428	Handle Bracket Assembly LH (Includes Ref. #'s 18, 46, & 47)

Ref No.	Part Number	Description
27	715-0221	Dowel Pin
28	618-04670	Transmission Assembly
29	687-02429	Handle Bracket Assembly RH (Includes Ref. #'s 18, 46, & 47)
30	756-04315A	Pulley, Half
31	732-04313	Extension Spring
32	748-0376C	Blade Adapter
33	710-1044	Screw, 3/8-24 x 1.50
34	736-0524B	Blade Bell Support
35	742-0741	21" Mulching Blade
36	736-0526	Washer, Wave, .88 x 1.31 x .029
37	710-0599	TT Screw, 1/4-20 x .500
38	731-06112	Engine Baffle
39	656-04046	Lower Pulley Assembly
40	710-0653	Screw, TT, 1/4-20 x .375
41	710-04774	Screw, 1/4-15 x 1.25
42	736-0504	Washer, Wave, .510 x .750 x .017
43	750-05022	Spchr., 7/8 x 1.265
44	711-04822A	Shf., .500 Dia. X 2.456
45	731-06284	Baffle
46	748-04177	Bearing Support
47	732-0708	Bearing Retainer
48	736-3012A	Washer, Wave, .390 x .625 x .016
49	750-05029	Spacer, .499 x .685 x .380
50	750-05031	Spacer, .499 x .860 x .380
51	736-0314	Washer, Thrust, .375 x .70 x .030