



| Ref | Part Number | Description |
|-----|----------------|------------------------------------|
| 1 | 781-04180-0637 | Log Tray Bracket |
| 2 | 710-0376 | Hex Screw, 5/16-18 x 1.00 |
| 3 | 781-04179-0637 | Log Tray Bracket |
| 4 | 710-04484 | Self-Tapping Screw, 5/16-18 x .750 |
| 5 | 719-0550A | Wedge Assembly |
| 6 | 712-3022 | Lock Nut, 1/2-13 |
| 7 | 710-1018 | Hex Cap Screw, 1/2-20 x 2.75 |
| 8 | 710-1806 | Hex Cap Screw, 1/2-13 x 3.25 |
| 9 | 781-0351 | Adjustable Gib |
| 10 | 712-0711 | Hex Jam Nut, 3/8-24 |
| 11 | 710-0459A | Hex Cap Screw, 3/8-24 x 1.5 |
| 12 | 781-0790-0637 | Back Plate |
| 13 | 912-3058 | Hex Lock Nut, 1/2-20 |
| 14 | 737-04093 | Inlet Filter |
| 15 | 710-04683 | Hex Washer Screw, 3/8-16 x 1.000 |
| 16 | 781-0525-0638 | Dislodger |
| 17 | 710-0650 | Self-Tapping Screw, 5/16-18 x .875 |
| 18 | 681-04030 | Hitch Coupler, 2" |
| 19 | 713-0433A | Chain |
| 20 | 981-04080 | Beam Assembly |
| 21 | 714-0211 | Cotter Pin |
| 22 | 918-0313A | Hydraulic Cylinder, 31/33 Ton |
| 23 | 711-1135 | Clevis Pin |
| 24 | 727-04166 | Hydraulic Hose |
| 25 | 727-0443 | Return Hose, 3/4" ID x 44" |
| 26 | 781-0526A | Hose Guard |
| 27 | 726-0132 | Hose Clamp, 5/8" |
| 28 | 737-0153 | Return Elbow |
| 29 | 737-0192 | 90 Degree Solid Male Adapter |
| 30 | 737-0235 | 3/4" Hose Adapter |
| 31 | 918-0481A | Control Valve |
| 32 | 737-0316 | Filter Housing |
| 33 | 723-0405 | Oil Filter |
| 34 | 727-0502 | High Pressure Hydraulic Hose |
| 35 | 781-0538A | Hose Guard |
| 36 | 914-0470 | Cotter Pin, 1/8" |
| 37 | 738-0805 | Hinge Pin, 1/2 x 4.8" Lg. |
| 38 | 726-0214 | Push Cap |
| 39 | 732-0583 | Compression Spring, 4" |
| 40 | 936-0116 | Flat Washer, .635 ID x .93 OD |
| 41 | 781-0690 | Locking Rod |
| 42 | 737-0348A | Vented Dipstick |
| 43 | 731-2496A | Fender |
| 44 | 736-0371 | Flat Washer, .343 x .880 x .062 |

| Ref | Part Number | Description |
|-----|-----------------|------------------------------------|
| 45 | 710-0602 | Self-Tapping Screw, 5/16-18 x 1.00 |
| 46 | 981-04041B-0637 | Frame Assembly, 7.0 Gal |
| 47 | 736-0242 | Bell Washer, 340 x .872 x .060 |
| 48 | 710-0521 | Hex Cap Screw, 3/8-16 x 3.00 |
| 49 | 710-3180 | Hex Cap Screw, 5/16-18 x 1.75 |
| 50 | 710-3226 | Hex Cap Screw, 5/16-18 x 5.50 |
| 51 | 781-1100-0637 | Front Support Bracket Coupling |
| 52 | 936-0185 | Flat Washer, .375 x .738 x .063 |
| 53 | 711-0396 | Spacer, .385 x .623 x .750 |
| 54 | 710-0347 | Hex Cap Screw, 3/8-16 x 1.75 |
| 55 | 710-3085 | Hex Cap Screw, 3/8-16 x 3.50 |
| 56 | 719-0315 | Coupling Shield |
| 57 | 914-0114 | Key |
| 58 | 712-04063 | Hex Flange Lock Nut, 5/16-18 |
| 59 | 718-04392 | Coupling, .500 |
| — | 718-04393 | Coupling, 1.00 |
| — | 735-04103 | Spider Bushing |
| — | 710-1842 | Set Screw, 1/4-20 x .38 |
| 60 | 781-0162-0637 | Jack Stand |
| 61 | 781-0398-0637 | Support Beam Assembly |
| 62 | 781-0097-0637 | Rear Coupling Support Bracket |
| 63 | 737-0264 | Adapter, 7/8-14 |
| 64 | 918-04128 | Pump |
| 65 | 781-04174-0637 | Fender Mounting Bracket |
| 66 | 727-0451 | Suction Hose |
| 67 | 911-0813 | Clevis Pin, 5/16 x 2.5 |
| 68 | 712-04065 | Flange Lock Nut, 3/8-16 |
| 69 | 936-0169 | Lock Washer, 3/8 |
| 70 | 781-0680B-0638 | Tube |
| 71 | 710-0411 | Hex Cap Screw, 3/8-16 x 4.0 |
| 72 | 634-0186 | Wheel Assembly |
| — | 934-0180-0662 | Wheel/Rim Ass., 16.0 x 4.8 x 8.0 |
| — | 921-0168 | Dust Seal |
| — | 941-0987 | Bearing, .75 |
| 73 | 936-0351 | Flat Washer, .76" ID x 1.5" OD |
| 74 | 712-0359 | Slotted Nut, 3/4-16 |
| 75 | 714-0162 | Cotter Pin, 5/32" x 1-1/4" |
| 76 | 734-0873 | Hub Cap |
| 77 | 732-0194 | Spring Pin |
| 78 | 711-04585 | Clevis Pin |
| 79 | 913-04036 | Valve Handle Link |
| 80 | 914-0111 | Cotter Pin |
| 81 | 720-04088 | Grip |
| 82 | 747-04539 | Hydraulic Valve Control |