


REPLACEMENT PARTS - MODEL Y26CS
4-CYCLE TRIMMER
PPN 41AD26CC900




REPLACEMENT PARTS - MODEL Y26CS

4-CYCLE TRIMMER

PPN 41AD26CC900

<u>Item</u>	<u>Part No.</u>	<u>Description</u>	<u>Item</u>	<u>Part No.</u>	<u>Description</u>
1	753-05449	Engine Cover	26	791-182396	Washer
2	791-181345	Screw	27	753-1238	Clutch Assembly
3	753-05377	Screw	28	791-153592	Clutch Drum
4	753-05209	Valve Cover	29	753-05446	Clutch Cover Assembly (includes 30-32)
5	753-05210	Valve Cover Gasket	30	791-181345	Cover Screw
6	753-05438	Cylinder Assembly (includes 5, 7 & 43)	31	791-182519	Anti-Rotation Screw
7	791-181003	Cylinder Screw	32	753-04291	Clamping Screw Assembly
8	753-05247	Insulator Gasket	33	753-05243	Ignition Module Assembly
9	753-05248	Nut	34	753-05078	Spacer
10	753-05452	Insulator (includes 11)	35	753-05240	Flywheel
11	753-05439	Carburetor Gasket	36	791-181861	Shroud Screw
12	753-1225	Carburetor w/Primer	37	791-182374	Cylinder Gasket
13	791-181751	Carburetor O-Ring	38	791-182377	Oil Pan (includes 39 & 40)
14	753-06061	Air Filter Cover Assembly (includes 16)	39	791-181018	Oil Pan Gasket
15	753-05253	Air Filter Mounting Screw	40	791-181020	Oil Pan Screw
16	753-05442	Air Filter	41	791-182378	Dipstick Assembly (includes 42)
17	753-05289	Fuel Cap	42	791-182290	O-Ring
18	791-181930	Screw	43	753-05266	Throttle Cable
19	791-182366	Clip Nut	*	753-05784	Spark Plug
20	753-05443	Fuel Tank Assembly (includes 17)	*	753-06117	Shortblock Assembly (includes 3-7 & 33-42)
21	753-05444	Muffler Assembly (includes 22 & 23)			
22	753-05244	Muffler Gasket			
23	753-05246	Muffler Mounting Screw			
24	753-05264	Lead Wire			
25	753-06062	Starter Housing Assembly (includes 3)			

REPLACEMENT PARTS - MODEL Y26CS
4-CYCLE TRIMMER
 PPN 41AD26CC900



Item	Part No.	Description
1	753-04234	Throttle Housing Assembly (includes 2-4)
2	791-182690	Throttle Trigger Spring
3	753-04119	Throttle Trigger
4	791-182405	Switch
5	753-05266	Throttle Cable Assembly
6	753-04236	Upper Drive Shaft Housing Assembly
7	791-153064	D-Handle Assembly
8	791-181587	D-Handle Hardware
9	753-1190	Split boom Coupler (includes 10-13)
10	791-182057	Screw
11	791-181617	Bolt
12	791-181981	Adjustment Knob (includes 13)
13	753-04386	Knob Retaining Nut
14	791-182387	Lower Drive Shaft Housing Assembly (includes 16)
15	791-153597	Lower Clamp Assembly (includes 19)
16	791-181852	Lower Flexible Drive Shaft
17	791-180531	Shield Mounting Screw
18	753-05050	Bushing Housing Assembly
19	791-145569	Anti-Rotation Screw
20	791-181659	Shield Assembly (includes 21)
21	753-06048	Blade Assembly
22	753-05278	Adapter
23	753-06130	Spool Assembly