


# REPLACEMENT PARTS - MODEL TB575EC

## 4-CYCLE GAS TRIMMER

PPN 41EDT57C966



# REPLACEMENT PARTS - MODEL TB575EC

## 4-CYCLE GAS TRIMMER


PPN 41EDT57C966

<u>Item</u>	<u>Part No.</u>	<u>Description</u>	<u>Item</u>	<u>Part No.</u>	<u>Description</u>
1	753-06134	Engine Cover Assembly (includes 2 & 3)	24	791-181751	O-Ring
2	753-04595	Cover Screw	25	753-05252	Air Cleaner Cover Assembly (includes 26)
3	791-181003	Screw	26	753-05254	Air Filter
4	753-05901	Rocker Cover	27	753-05253	Screw
5	753-05902	Rocker Cover O-Ring	28	753-06240	Fuel Tank Assembly w/Fuel Lines (includes 29)
6	753-06311	Cylinder Assembly (includes 3 & 5)	29	753-1229	Fuel Cap
7	753-05408	Oil Plug (includes 8)	30	753-05259	Fuel Tank Pads
8	791-182290	Oil Plug O-Ring	31	753-06314	Starter Housing Assembly (includes 3)
9	753-06111	Crankcase Cover	32	753-06281	Clutch Assembly
10	753-05238	Crankcase Cover O-ring	33	753-05263	Clutch Cover (includes 2)
11	753-06313	Crankcase Assembly (includes 10)	34	791-182519	Anti-Rotation Screw
12	753-06221	Flywheel Assembly	35	753-04003	Clamp Screw
13	753-05264	Lead Wires	36	791-180217	Nut
14	753-05243	Module Assembly	37	791-181025	Rocker Cover Screw
15	753-05244	Muffler Gasket	*	753-05297	Spark Arrestor Assembly
16	753-05245	Muffler Assembly (includes 15 & 17)	*	753-06317	Shortblock Assembly (includes 3-6, 8, 10, 11 & 18)
17	753-05246	Muffler Screw			
18	753-05784	Spark Plug			
19	753-05247	Insulator Gasket			
20	753-05248	Nut	*	Items Not Shown	
21	753-05249	Insulator			
22	753-05366	Carburetor Gasket			
23	753-06220	Carburetor			

# REPLACEMENT PARTS - MODEL TB575EC

## 4-CYCLE GAS TRIMMER

PPN 41EDT57C966



Item	Part No.	Description
1	753-04234	Throttle Housing Assembly (includes 2-4)
2	753-04119	Throttle Trigger
3	791-182690	Throttle Trigger Spring
4	791-182405	Switch
5	753-05266	Throttle Cable Assembly
6	753-04236	Upper Drive Shaft Housing Assembly
7	753-06039	Deluxe D-Handle Assembly (includes 8)
8	753-06040	Bolt
9	753-1190	Split Boom Coupler (includes 10-13)
10	791-182057	Screw
11	791-181617	Bolt
12	791-181951	Adjustment Knob (includes 13)
13	753-04386	Knob Retaining Nut
14	753-06139	Lower Drive Shaft Housing Assembly
15	753-05267	Lower Flexible Drive Shaft
16	753-05698	Anti-Rotation Screw
17	753-06124	Gear Box Assembly (includes 16)
18	753-06125	Shield Mounting Screws
19	753-06123	Shield Assembly (includes 20)
20	753-06126	Blade Assembly
21	753-06129	Cutting Head Assembly

\* Items Not Shown