


REPLACEMENT PARTS - MODEL TB516 EC 4-CYCLE LAWN EDGER

PPN 25A-516-966




Item	Part No.	Description	Item	Part No.	Description
1	753-06134	Engine Cover Assembly (includes 2 & 3)	19	753-05366	Carburetor Gasket
2	753-04595	Cover Screw	20	753-06258	Carburetor w/Primer
3	753-05377	Starter Screw	21	791-181751	O-Ring
4	753-05901	Rocker Cover	22	753-05253	Screw
5	753-05902	Rocker Cover O-Ring	23	753-06541	Air Cleaner Cover Assembly (includes 24)
6	753-05408	Oil Plug (includes 7)	24	753-05996	Air Filter
7	791-182290	Oil Plug O-Ring	25	753-06240	Fuel Tank Assembly w/Fuel Lines (includes 26)
8	753-06111	Crankcase Cover	26	753-1229	Fuel Cap
9	753-05238	Crankcase Cover O-ring	27	753-05259	Fuel Tank Pads
10	753-06221	Flywheel Assembly	28	753-06314	Starter Housing Assembly (includes 3)
11	753-05836	Module Assembly	29	791-182396	Washer
12	753-05245	Muffler Assembly (includes 13 & 14)	30	753-06573	Clutch Drum w/Pulley
13	753-05244	Muffler Gasket	31	753-06317	Shortblock Assembly (includes Crankcase, Cylinder, 3-7, 9, 11 & 15)
14	753-05246	Muffler Screw	32	791-181025	Screw
15	753-05784	Spark Plug	33	753-05078	Spacer
16	753-05247	Insulator Gasket	34	753-1238	Clutch (includes 29)
17	753-05248	Nut	35	791-182468	Screw
18	753-05249	Insulator	36	791-182569	Washer

REPLACEMENT PARTS - MODEL TB516 EC

4-CYCLE LAWN EDGER

PPN 25A-516-966



REPLACEMENT PARTS - MODEL TB516 EC
4-CYCLE LAWN EDGER
PPN 25A-516-966

<u>Item</u>	<u>Part No.</u>	<u>Description</u>	<u>Item</u>	<u>Part No.</u>	<u>Description</u>
1	753-06542	Upper Handle	28	753-06559	Screw
2	753-06543	Middle Handle	29	753-05540	Idler Pulley Assembly
3	753-06544	Handle Extension	30	753-05541	Shoulder Screw
4	791-182677	Handle Knob	31	753-05560	Belt
5	791-182678	Washer	32	753-05554	Screw
6	791-182899	Bolt	33	753-05555	Washer
7	753-04429	Cable Guide	34	753-05542	Pulley
8	753-06546	Throttle Cable	35	753-05543	Blade Spindle
9	753-06592	Throttle Lever w/Hardware	36	753-05544	Spindle Plate
10	791-182665	Lead Wire	37	753-05550	Bearing
11	791-182405	On/Off Switch	38	753-05545	Bearing Cup
12	753-05524	Starter Rope Guide	39	753-05546	Washer
13	753-06593	Edger Frame	40	753-05547	Blade Guard
14	753-05525	Lock Nut	41	753-05548	Screw
15	753-05530	Wheel	42	753-06561	Edger Blade
16	753-05529	Wheel Bolt	43	753-05549	Nut
17	753-05556	Spacer	44	753-04595	Screw
18	753-05538	Spacer Screw	45	753-05552	Belt Cover
19	753-05531	Height Adjustment Lever Assembly	46	791-182451	Washer
20	753-05532	Washer	47	753-06562	Spring
21	753-05534	Shoulder Screw	48	753-06563	Bolt
22	753-05535	Nut	49	753-05528	Screw
23	753-05646	Washer	50	753-06565	Bolt
24	753-05536	Pivot Arm	51	753-05383	Nut
25	753-06287	Height Adjustment Spacer	52	753-06566	Spacer
26	753-04202	Spindle Plate Screw	53	753-06577	Nut
27	753-06556	Spindle Spacer			