


REPLACEMENT PARTS - MODEL TB146 EC 4-CYCLE GAS CULTIVATOR PPN 21BK146G966




REPLACEMENT PARTS - MODEL TB146 EC

4-CYCLE GAS CULTIVATOR

PPN 21BK146G966

<u>Item</u>	<u>Part No.</u>	<u>Description</u>	<u>Item</u>	<u>Part No.</u>	<u>Description</u>
1	753-06237	Engine Cover Assembly (includes 2 & 3)	24	753-06020	Air Cleaner Cover Assembly (includes 25)
2	753-04595	Cover Screw	25	753-05996	Air Filter
3	753-05377	Starter Screw	26	753-05233	Air Filter Screw
4	753-05209	Rocker Cover	27	753-06240	Fuel Tank Assembly w/Fuel Lines (includes 28)
5	753-05210	Rocker Cover O-Ring	28	753-1229	Fuel Cap
6	753-05232	Cylinder O-Ring	29	753-05259	Fuel Tank Pads
7	791-182379	Breather Hose	30	753-06239	Starter Housing Assembly (includes 3)
8	753-05408	Oil Plug (includes 9)	31	753-06281	Clutch Assembly
9	791-182290	Oil Plug O-Ring	32	753-05263	Clutch Cover (includes 2)
10	753-06111	Crank Case Cover	33	753-04466	Anti-Rotation Screw
11	753-05238	Crank Case Cover O-Ring	34	753-04003	Clamp Screw
12	753-06396	Flywheel Assembly	35	791-180217	Clamp Nut
13	753-05785	Lead Wires	36	791-181025	Rocker Cover Screw
14	753-05301	Module Assembly	37	791-181003	Screw
15	753-05244	Muffler Gasket	38	753-05078	Spacer
16	753-06238	Muffler Assembly (includes 15 & 17)	39	791-181751	O-ring
17	753-05246	Muffler Screw	*	753-05297	Spark Arrestor Assembly
18	753-05784	Spark Plug	*	753-06225	Shortblock Assembly (includes 3-12 14, 15, 17 & 24)
19	753-05247	Insulator Gasket			
20	753-05248	Insulator Nut			
21	753-05249	Insulator	*		Items Not Shown
22	753-05366	Carburetor Gasket			
23	753-05251	Carburetor w/Primer			

REPLACEMENT PARTS - MODEL TB146 EC 4-CYCLE GAS CULTIVATOR PPN 21BK146G966



Item	Part No.	Description
1	753-04042	Throttle Control
2	753-05940	Torsion Spring
3	791-182405	On/Off Switch
4	753-04044	Foam Grip
5	753-06050	Throttle Cable
6	753-04498	Upper Handle
7	791-182899	Bolt
8	753-04049	Cable Tie
9	753-04499	Flex Shaft
10	791-182677	Knob
11	753-04052	Washer
12	753-04053	Lower Handle
13	753-06012	Screw
14	753-04055	Front Handle
15	753-04056	Lock Nut
16	753-04057	Cotter Pin
17	753-04058	Tailpiece Bracket Assembly
18	753-04059	Clevis Pin

Item	Part No.	Description
19	753-04060	Cap Screw
20	753-04061	Lock Nut
21	753-04062	Push Cap
22	753-04063	Wheel Support Bracket Assembly
23	753-04501	Wheel
24	753-05001	Bolt
25	753-06010	Tine Shield
26	753-06063	Gear Box Assembly
27	753-05986	Tine (Right Outer)
28	753-05987	Tine (Left Inner)
29	753-06015	Tine (Left Outer)
30	753-06016	Tine (Right Outer)
31	753-05988	Edger Tine
32	753-04068	Edger Wheel
33	753-06242	Drive Shaft Housing
34	791-180288	Sleeve Retaining Bolt
35	753-06013	Bow Clip