


REPLACEMENT PARTS - MODEL TB42 BC

2-CYCLE GAS TRIMMER

PPN 41ADZ42C766



Item	Part No.	Description
1	753-06829	Starter Assembly (includes 2 & 3)
2	791-181862	Starter Screw
3	753-06244	Starter Assembly Guard (includes 2)
4	753-06245	Rear Engine Cover (includes 5)
5	791-181345	Cover Screw
6	753-06104	Adapter
7	753-06091	Pawl Assembly
8	753-06246	Flywheel Assembly
9	753-06247	Washer
10	753-06248	Spacer
11	753-05860	Clutch Assembly
12	753-06249	Clutch Cover Assembly (includes 2, 13 -15 and 22)
13	791-182519	Anti-rotation Screw
14	753-04003	Clamp Screw
15	791-180217	Clamp Nut
16	753-06418	Muffler Assembly (includes 17 and 18)
17	753-06294	Muffler Screw
18	753-04619	Muffler Gasket (not shown)
19	753-06856	Fuel Tank Assembly (includes 20 and 21)
20	791-181930	Tank Screw


Item	Part No.	Description
21	753-06857	Fuel Cap
22	791-182366	U-shaped Nut
23	753-05877	Lead Wires
24	753-06251	Throttle Cable
25	753-06912	Module Assembly
26	753-06827	Cylinder Gasket
27	753-05703	Cylinder Bolt
28	753-06193	Spark Plug
29	753-06189	Insulator Assembly (includes 30 and 31)
30	753-06184	Insulator O-Ring
31	753-06185	Carburetor O-Ring
32	753-06190	Carburetor
33	753-06253	Carburetor Gasket
34	753-06913	Air Cleaner Assembly (includes 35)
35	753-06914	Air Cleaner Filter

Items Not Shown
 * 753-06762 Short Block Assembly (includes Crankcase, Cylinder, Piston, 8 - 11, 25 - 28)

REPLACEMENT PARTS - MODEL TB42 BC

2-CYCLE GAS TRIMMER

PPN 41ADZ42C766



Item	Part No.	Description
1	753-05192	Throttle Housing Assembly (includes 2 - 5)
2	753-04991	Throttle Trigger
3	753-05007	Throttle Trigger Spring
4	753-05171	Throttle Trigger Lock-Out
5	791-182405	Switch Assembly
6	753-06251	Throttle Cable Assembly
7	791-610327	Harness Clip
8	753-04236	Upper Drive Shaft Housing Assembly
9	791-181099	J-Handle Assembly
10	791-683295	Handle Bracket Assembly (includes 11 - 16)
11	791-181811	Screw
12	791-181812	Upper Handle Clamp
13	791-181813	Middle Handle Clamp
14	791-181814	Lower Handle Clamp
15	791-181815	Nut
16	791-182519	Anti-Rotation Screw
17	753-1190	Split Boom Coupler (includes 18 - 19)
18	791-182057	Screw
19	791-181617	Bolt
20	791-182541	Lower Drive Shaft Housing Assembly
21	791-613300	Lower Flexible Drive Shaft
22	791-182200	Shield Mount Screw Assembly
23	791-182193	2 piece Gearbox Assembly (includes 24 - 27)
24	791-182195	Gearbox Mounting Hardware
25	791-182519	Anti-Rotation Screw
26	791-182196	Blade Driver
27	753-04348	Palnut
28	791-147492	Blade Shield/Shield Mount
29	791-683304	Shield Mounting Screw
30	753-1191	Shield Assembly (includes 31)
31	791-682061	Blade Assembly
32	791-147490	Retaining Washer
33	791-612483	Spool Shaft
34	791-683301	Outer Spool Assembly (includes 35)
35	791-612026	Retainer
36	791-610636B	Spring
37	791-147495	Inner Reel
38	791-180814B	Bump Head Knob Assembly
39	791-145873B	4-Tooth Blade
40	791-181699	Nut
*	791-180014B	Blade Retaining Kit (includes 32 & 40)
*	791-613226	Locking Rod Tool
*	791-682075B	Shoulder Harness

Optional Accessories

- * 753-04216 Replacement Line, 0.105 Diameter
- * 753-1224 Reel and Line Assembly
- * 753-1161 Bump Head Assembly (includes 33 - 38)

* Items Not Shown