


REPLACEMENT PARTS - MODEL SS418

4-CYCLE GAS TRIMMER


PPN 41ADZ41C912



Item	Part No.	Description
1	753-06134	Engine Cover Assembly (includes 2 & 3)
2	753-04595	Cover Screw
3	753-05377	Housing Screw
4	791-181025	Rocker Cover Screw
5	753-05901	Rocker Cover
6	753-05902	Rocker Cover O-Ring
7	753-06311	Cylinder Assembly (includes 3 - 6 & 8)
8	753-05910	Cylinder O-Ring
9	753-05408	Oil Plug (includes 10)
10	791-182290	Oil Plug O-Ring
11	753-06111	Crankcase Cover
12	753-05238	Crankcase Cover O-Ring
13	753-06221	Flywheel Assembly
14	753-05264	Lead Wires
15	753-05301	Module Assembly
16	753-05244	Muffler Gasket
17	753-05245	Muffler Assembly (includes 16 & 18)
18	753-05246	Muffler Screw
19	753-05784	Spark Plug
20	753-05247	Insulator Gasket

Item	Part No.	Description
21	753-05248	Nut
22	753-06947	Insulator
23	753-06948	Carburetor Gasket
24	753-06220	Carburetor
25	791-181751	O-Ring
26	753-05252	Air Cleaner Cover Assembly (includes 27)
27	753-05254	Air Filter
28	753-05253	Screw
29	753-06797	Fuel Tank Assembly w/Fuel Lines (includes 30)
30	753-1229	Fuel Cap
31	753-05259	Fuel Tank Pads
32	753-05078	Spacer
33	753-06681	Starter Housing Assembly (includes 3)
34	753-06281	Clutch Assembly
35	753-05263	Clutch Cover (includes 2)
36	791-182519	Anti-Rotation Screw
37	753-04003	Clamp Screw
38	791-180217	Nut
39	753-06949	Heatshield Carb.
40	791-181709	Gasket
*	Items Not Shown	
*	753-06317	Shortblock Assembly (includes 3 - 10 & 19)

REPLACEMENT PARTS - MODEL SS418
4-CYCLE GAS TRIMMER
 PPN 41ADZ41C912



Item	Part No.	Description
1	753-06917	Throttle Housing Assembly (includes 2 - 4)
2	753-06918	Throttle Trigger
3	791-182690	Throttle Trigger Spring
4	791-182405	Switch
5	753-05266	Throttle Cable Assembly
6	753-06682	Upper Drive Shaft Housing Assembly
7	753-06039	D-Handle Assembly (includes 8)
8	753-06040	Bolt
9	753-06585	Split Boom Coupler (includes 10 and 11)
10	791-182057	Screw
11	791-181617	Bolt
12	753-07016	Lower Drive Shaft Housing Assembly
13	753-05267	Lower Flexible Drive Shaft
14	753-05698	Anti-Rotation Screw
15	753-06162	Gear Box Assembly (includes 14, 19 - 21)
16	753-06125	Shield Mounting Screw
17	753-06123	Shield Assembly (includes 18)
18	753-06126	Blade Assembly
19	753-05470	Cutting Head Assembly (includes 20 and 21)
20	753-05428	Glide Cap
21	753-04386	Lock Nut