


REPLACEMENT PARTS - MODEL TB146 EC

4-CYCLE GAS CULTIVATOR

PPN 21AK146G766



Item	Part No.	Description
1	753-06237	Engine Cover Assembly (includes 2 & 3)
2	753-04595	Cover Screw
3	753-05377	Starter Screw
4	753-05901	Rocker Cover
5	753-05902	Rocker Cover O-Ring
6	753-05910	Cylinder O-Ring
7	791-182379	Breather Hose
8	753-05408	Oil Plug (includes 9)
9	791-182290	Oil Plug O-Ring
10	753-06111	Crankcase Cover
11	753-05238	Crankcase Cover O-ring
12	753-06221	Flywheel Assembly
13	753-05785	Lead Wires
14	753-05447	Module Assembly
15	753-06238	Muffler Assembly (includes 16 & 17)
16	753-05244	Muffler Gasket

Item	Part No.	Description
17	753-05246	Muffler Screw
18	753-05784	Spark Plug
19	753-05247	Insulator Gasket
20	753-05248	Nut
21	753-05249	Insulator
22	753-05366	Carburetor Gasket
23	753-06258	Carburetor w/Primer
24	753-04030	Carburetor O-Ring
25	753-05507	Air Filter Mounting Screw
26	753-06284	Air Cleaner Cover Assembly (includes 27-31)
27	791-182657	Air Filter Plate
28	791-182097	Breather Tube Assembly
29	791-181000	Air Cleaner O-Ring
30	791-182409	Washer
31	753-05506	Air Filter
32	753-06240	Fuel Tank Assembly w/Fuel Lines (includes 34)
33	753-1229	Fuel Cap
34	753-05259	Fuel Tank Pads
35	753-06666	Starter Housing Assembly (includes 3)
36	753-06281	Clutch Assembly
37	753-05263	Clutch Cover (includes 2)
38	753-04466	Anti-Rotation Screw
39	753-04003	Clamp Screw
40	791-180217	Nut
41	791-181025	Rocker Cover Screw
42	753-05078	Spacer
43	753-06317	Shortblock Assembly (includes 3-9, 11, 14, 18 & 41)

REPLACEMENT PARTS - MODEL TB146 EC

4-CYCLE GAS CULTIVATOR

PPN 21AK146G766

Item	Part No.	Description
1	753-06592	Throttle Control
2	753-06636	Throttle Spring
3	791-182405	On/Off Switch
4	753-06013	Bow Clip
5	753-06050	Throttle Cable
6	753-06818	Upper Handle
7	791-182899	Bolt
8	753-04049	Cable Tie
9	753-04499	Flex Shaft
10	791-182677	Knob
11	753-04052	Washer
12	753-04053	Lower Handle
13	753-06012	Screw
14	753-04056	Lock Nut
15	753-04057	Cotter Pin
16	753-04058	Tailpiece Bracket Assembly
17	753-04059	Clevis Pin
18	753-04060	Cap Screw
19	753-04061	Lock Nut
20	753-04062	Push Cap
21	753-04063	Wheel Support Bracket Assembly
22	753-04501	Wheel
23	753-05001	Bolt
24	753-06010	Tine Shield
25	753-06063	Gear Box Assembly
26	753-05986	Tine (Right Inner)
27	753-05987	Tine (Left Inner)
28	753-06015	Tine (Left Outer)
29	753-06016	Tine (Right Outer)
30	753-06242	Drive Shaft Housing
31	791-180288	Sleeve Retaining Bolt

