



8

Parts List



To order replacement parts, contact
1-800-800-7310
or visit us online at
www.mtdproducts.com

1	747-1161A	Blade Control Handle	26	736-0524B	Blade Bell Support
2	749-1092A	Upper Handle	27	787-01290	Front Adjustment Plate
3	747-04080	Grass Catcher Frame	28	720-0426	Adjustment Lever Knob
4	749-0928A	Lower Handle	29	732-0866	Spring Lever
5	720-0279	Wing Nut	30	738-0507B	Shoulder Screw
6	710-1205	Rope Guide	31	734-04086	Front Wheel, 7" x 1.8"
7	710-1174	Carriage Bolt ,5/16-18 x 2	32	710-04371	Screw, 1/4-15 x 1.250
8	664-04027	Grass Bag Assembly	33	746-0554	Control Cable - 40.5"
9	720-04071	Star Knob	34	731-04998	Trailshield
10	710-0599	Screw, 1/4-20 x .500	35	732-0700	Trailshield Wire
11	726-0240	Cable Tie	36	712-0397	Wing Nut, 1/4-20
12	710-0703	Carriage Bolt ,1/4-20	37	747-0996	Rear Door Pivot Rod
13	731-04134A	Rear Discharge Door	38	732-0866	Spring Lever
14	750-04162	Spacer	39	687-02039A	Pivot Arm Assembly - RH
15	732-04089A	Torsion Spring - LH		687-02040A	Pivot Arm Assembly - LH
16	732-04090A	Torsion Spring - RH	40	710-1652	AB Screw
17	734-04089	Rear Wheel, 12" x 1.8"	41	714-0104	Hairpin Clip
18	731-04150C	Rear Baffle	42	710-0654A	TT Sems Screw, 3/8-16 x 1.0
19	720-0312	Spring Lever Grip	43	687-02099A	Ht. Adj. Assy. Front - LH
20	787-01276	Deck - 21"		687-02100A	Ht. Adj. Assy. Front - RH
21	782-5002B	Front Baffle	44	687-02057	Rear Handle Bracket Assy. - LH
22	748-0377C	Blade Adapter		687-02056	Rear Handle Bracket Assy. - RH
23	742-0741	Mulching Blade	45	712-04065	Flange Lock Nut, 3/8-16
24	710-1257	Hex Screw , 3/8-24 x 2.5	46	687-02192	Handle Bracket Assembly - RH
25	687-02077A	Pivot Arm Assembly -RH		687-02191	Handle Bracket Assembly - LH
	687-02076A	Pivot Arm Assembly - LH	47	710-0216	Hex Screw, 3/8-16 x 0.75