



1.	747-1161A	Blade Control
2.	749-1092A	Upper Handle
3.	746-0957	Blade Control Cable - 37.25"
	746-1130	Blade Control Cable - 40"
	746-0946	Blade Control Cable - 48.25"
4.	710-1205	Eye Bolt
5.	720-0279	Wing Nut
6.	720-0284	Wing Nut
7.	736-0451	Shoulder Washer.320 ID x.93 OD
8.	710-1174	Carriage Bolt 5/16-18 x 2.0
9.	725-0157	Cable Tie
10.	749-04037	Lower Handle
11.	731-0981A†	Hub Cap (Not Shown)
12.	17098	Hinge Clip
13.	731-2537	Trail Shield
14.	682-3062A	Handle Bracket Assembly - RH
15.	682-3063A	Handle Bracket Assembly - LH
16.	712-0431	Lock Nut 3/8 -16
17.	710-0654A	Hex Washer Screw 3/8-16 x 1.0
18.	687-02048	22" Deck Assembly
19.	736-0270	Bell Washer.265 x.75
20.	741-0751	Height Adjuster Bearing
21.	687-02094	Pivot Arm Assembly
22.	748-0376C	Blade Adapter

23.	742-0742A	22" Mulching Blade
24.	710-1044	Hex Cap Screw 3/8-24 x 1.5
25.	736-0524B	Blade Bell Support
26.	738-1172	Shoulder Screw 3/8 - 16 x.302
27.	736-0741	Bell Washer.760 ID x 1.25 OD
28.	734-1988	Front Wheel Assembly 7 x 1.8
29.	720-0426	Height Adjuster Knob
30.	732-1026	Front Spring Lever
31.	747-0710	Hinge Pin
32.	732-1014	Torsion Spring
33.	17032A	Deflector Chute Adapter
34.	731-1034B	Side Discharge Chute Assembly
35.	710-0216	Hex Cap Screw 3/8-16 x .75
36.	741-0717	Thrust Bearing.688 ID x 1.94 OD
37.	687-02080	Rear Pivot Arm Assembly - RH
38.	687-02079	Rear Pivot Arm Assembly - LH
39.	732-0984B	Rear Spring Lever
40.	738-1127	Shoulder Screw 3/8 - 16 x.442
41.	710-0599	Screw 1/4-20 x.50
42.	734-04082	Rear Wheel Assembly 12 x 1.8
43.	631-04045	Mulching Baffle
44.	731-1396A†	Engine Shroud
45.	710-1256†	Screw, #8-18 x 1.25

† If equipped

8

Parts List

